

NO.6 ENGINE DOES NOT RESTART [SKYACTIV-G 2.0]

id1103a1001100

| 6 | ENGINE DOES NOT RESTART |
|-----------------------|---|
| DESCRIPTION | <ul style="list-style-type: none"> • The i-stop warning light (amber) illuminates and engine does not restart while the i-stop function is operating. • Engine does not restart when attempting to resume driving vehicle after stopping, and i-stop warning light (amber) is illuminated. • Engine does not restart even though restart conditions are met. |
| POSSIBLE CAUSE | <p>False detection of engine restart restriction conditions during engine stop</p> <ul style="list-style-type: none"> • False detection of vehicle in unsafe condition while i-stop function is operating <ul style="list-style-type: none"> — False detection of open bonnet (engine stalls and i-stop warning light (amber) illuminates) <ul style="list-style-type: none"> • Bonnet latch switch malfunction • Open circuit in wiring harness between bonnet latch switch terminal A and rear body control module (RBCM) terminal 3L — False detection of open driver's door (when driver's seat belt is unfastened, engine stalls and i-stop warning light (amber) illuminates) <ul style="list-style-type: none"> • Front door latch switch (driver's side) malfunction • Open circuit in wiring harness between front door latch switch (driver's side) and rear body control module (RBCM) — False detection of unfastened driver seat belt (when driver's door is opened, engine stalls and i-stop warning light (amber) illuminates) <ul style="list-style-type: none"> • Driver-side buckle switch malfunction • Short to ground in wiring harness between driver-side buckle switch terminal 4A and SAS control module terminal 2U <p>Engine does not crank when engine is restarted (i-stop warning light (amber) illuminates)</p> <ul style="list-style-type: none"> • Engine starting system malfunction <p>Cannot recognize signal for conditions permitting engine restart</p> <ul style="list-style-type: none"> • False detection of i-stop operation not switched OFF even though switched OFF <ul style="list-style-type: none"> — i-stop OFF switch malfunction • False detection of brake pedal non-operation even though operated <ul style="list-style-type: none"> — Brake fluid pressure sensor (built-into DSC HU/CM) malfunction • Falsely detects that climate control unit detects driver-side air mix door position at MAX HOT or MAX COLD (vehicles with full-auto air conditioner) <ul style="list-style-type: none"> — Driver-side air mix actuator malfunction — Driver-side air mix actuator position sensor malfunction — Driver-side air mix door link stuck • False detection of assured power brake unit vacuum (assist force) even though vacuum decreases <ul style="list-style-type: none"> — Power brake unit vacuum sensor malfunction — Short or open circuit in wiring harness between the following terminals: <ul style="list-style-type: none"> • Power brake unit vacuum sensor terminal C—PCM terminal 2BG • Power brake unit vacuum sensor terminal B—PCM terminal 2Q • Power brake unit vacuum sensor terminal A—PCM terminal 2AH • Cannot recognize steering wheel angle and speed even though steering wheel is turned. (ATX, D or M position) <ul style="list-style-type: none"> — Steering angle sensor malfunction — Short or open circuit in wiring harness between steering angle sensor and start stop unit terminals 1U, 1T, 1W or 1S <p>Engine system malfunction (engine does not start even though cranking for 3 s or more when engine is restarted) (i-stop warning light (amber) illuminates)</p> <ul style="list-style-type: none"> • Piston-stop position malfunction while i-stop function is operating <ul style="list-style-type: none"> — CKP sensor malfunction — Throttle value operation malfunction (drive-by-wire control malfunction) — Intake-air system related malfunction (air suction, vacuum hose breakage) — Purge control malfunction • Mechanical (engine) malfunction <ul style="list-style-type: none"> — Valve timing malfunction — Improper operation of electric variable valve timing control system (PCM DTC is stored.) — Improper operation of hydraulic variable valve timing control system |

Diagnostic Procedure

| STEP | INSPECTION | RESULTS | ACTION |
|------|--|---------|---|
| 1 | VERIFY DTC <ul style="list-style-type: none"> Retrieve the PCM, TCM, front body control module (FBCM), rear body control module (RBCM) and climate control unit DTCs using the M-MDS. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0].) (See ON-BOARD DIAGNOSTIC SYSTEM DTC INSPECTION [FW6A-EL, FW6AX-EL].) (See DTC INSPECTION [FRONT BODY CONTROL MODULE (FBCM)].) (See DTC INSPECTION [REAR BODY CONTROL MODULE (RBCM)].) (See DTC DISPLAY [FULL-AUTO AIR CONDITIONER].) Are any DTCs present? | Yes | Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0].) (See ON-BOARD DIAGNOSTIC SYSTEM DTC TABLE [FW6A-EL, FW6AX-EL].) (See DTC TABLE [FRONT BODY CONTROL MODULE (FBCM)].) (See DTC TABLE [REAR BODY CONTROL MODULE (RBCM)].) (See DTC TABLE [FULL-AUTO AIR CONDITIONER].) |
| | | No | Go to the next step. |
| 2 | VERIFY i-stop WARNING LIGHT (AMBER) CONDITION <ul style="list-style-type: none"> Does the i-stop warning light (amber) illuminate? | Yes | Go to Step 12. |
| | | No | Go to the next step. |
| 3 | DETERMINE IF MALFUNCTION CAUSE IS i-stop OFF SWITCH SIGNAL OR OTHER <ul style="list-style-type: none"> Switch the ignition to off. Disconnect the instrument cluster connector. Inspect for continuity between instrument cluster terminal V and body ground when the i-stop OFF switch is pressed. Is there continuity? | Yes | Go to Step 5. |
| | | No | Go to the next step. |
| 4 | INSPECT i-stop OFF SWITCH <ul style="list-style-type: none"> Inspect the i-stop OFF switch. (See i-stop OFF SWITCH INSPECTION [SKYACTIV-G 2.0].) Is there any malfunction? | Yes | Replace the cluster switch. (See SWITCH PANEL REMOVAL/INSTALLATION.) |
| | | No | Inspect the wiring harness between the following terminals for open circuit: <ul style="list-style-type: none"> Cluster switch terminal B—Instrument cluster terminal V Cluster switch terminal C—Instrument cluster terminal T — If there is any malfunction: <ul style="list-style-type: none"> Repair or replace the suspected wiring harness. |
| 5 | DETERMINE IF MALFUNCTION CAUSE IS STEERING ANGLE SENSOR SIGNAL OR OTHER <ul style="list-style-type: none"> Start the engine and it at idle. Access the EPS control module PID STR_ANG using the M-MDS. (See ELECTRIC POWER STEERING (EPS) ON-BOARD DIAGNOSIS.) Is the PID value normal? | Yes | Go to Step 7. |
| | | No | Go to the next step. |
| 6 | INSPECT STEERING ANGLE SENSOR <ul style="list-style-type: none"> Inspect the steering angle sensor. (See STEERING ANGLE SENSOR INSPECTION.) Is there any malfunction? | Yes | Replace the steering angle sensor. (See STEERING ANGLE SENSOR REMOVAL/INSTALLATION.) |
| | | No | Inspect the wiring harness between the following terminals for a short or open circuit: <ul style="list-style-type: none"> Steering angle sensor terminal A—Start stop unit terminal 1U Steering angle sensor terminal B—Start stop unit terminal 1T Steering angle sensor terminal C—Start stop unit terminal 1W Steering angle sensor terminal D—Start stop unit terminal 1S — If there is any malfunction: <ul style="list-style-type: none"> Repair or replace the suspected wiring harness. |

| STEP | INSPECTION | RESULTS | ACTION |
|------|---|---------|--|
| 7 | INSPECT BRAKE FLUID PRESSURE SENSOR <ul style="list-style-type: none"> Inspect the brake fluid pressure sensor. (See BRAKE FLUID PRESSURE SENSOR INSPECTION.) Is there any malfunction? | Yes | Replace the DSC HU/CM. (See DSC HU/CM REMOVAL/INSTALLATION.) |
| | | No | Go to the next step. |
| 8 | DETERMINE IF MALFUNCTION CAUSE IS DRIVER-SIDE AIR MIX ACTUATOR SIGNAL OR OTHER <ul style="list-style-type: none"> Measure the voltage at the climate control unit terminal 1N (wiring harness-side) when the driver-side temperature setting is MAX HOT and MAX COLD. Is the voltage normal? (See CLIMATE CONTROL UNIT INSPECTION [FULL-AUTO AIR CONDITIONER].) | Yes | Go to Step 10. |
| | | No | Go to the next step. |
| 9 | INSPECT DRIVER-SIDE AIR MIX ACTUATOR <ul style="list-style-type: none"> Inspect the driver-side air mix actuator. (See AIR MIX ACTUATOR INSPECTION [FULL-AUTO AIR CONDITIONER].) Is there any malfunction? | Yes | Replace the driver-side air mix actuator. (See AIR MIX ACTUATOR REMOVAL/INSTALLATION [FULL-AUTO AIR CONDITIONER].) |
| | | No | Inspect the air mix actuator and linkage for sticking. (See A/C UNIT DISASSEMBLY/ASSEMBLY.) <ul style="list-style-type: none"> If there is any malfunction: <ul style="list-style-type: none"> Repair or replace the malfunctioning part according to the inspection results. |
| 10 | DETERMINE IF MALFUNCTION CAUSE IS POWER BRAKE UNIT VACUUM SENSOR SIGNAL OR OTHER <ul style="list-style-type: none"> Turn off the i-stop system with i-stop OFF switch. Start the engine and run it is idling. Stop the engine. Switch the ignition ON (engine off). Access the PCM PID BBP using the M-MDS while the brake pedal has been depressed several times. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0].) Does the monitor value decrease every time the brake pedal is depressed? | Yes | Repeat the inspection from Step 1. <ul style="list-style-type: none"> If the malfunction is not resolved, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0].) Go to Step 23. |
| | | No | Go to the next step. |
| 11 | INSPECT POWER BRAKE UNIT VACUUM SENSOR <ul style="list-style-type: none"> Inspect the power brake unit vacuum sensor. (See POWER BRAKE UNIT INSPECTION.) Is there any malfunction? | Yes | Replace the power brake unit vacuum sensor. (See POWER BRAKE UNIT VACUUM SENSOR INSPECTION [SKYACTIV-G 2.0].) |
| | | No | Inspect the wiring harness between the following terminals for a short or open circuit: <ul style="list-style-type: none"> Power brake unit vacuum sensor terminal C—PCM terminal 2BG Power brake unit vacuum sensor terminal B—PCM terminal 2Q Power brake unit vacuum sensor terminal A—PCM terminal 2AH <ul style="list-style-type: none"> If there is any malfunction: <ul style="list-style-type: none"> Repair or replace the suspected wiring harness. If there is no malfunction: <ul style="list-style-type: none"> Replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0].) |
| 12 | VERIFY IF ENGINE STALLS AFTER CRANKING DURING ENGINE RESTART <ul style="list-style-type: none"> Does the engine restart by i-stop engine start? | Yes | Go to Step 19. |
| | | No | Go to the next step. |

| STEP | INSPECTION | RESULTS | ACTION |
|------|--|---------|---|
| 13 | DETERMINE IF MALFUNCTION CAUSE IS FRONT DOOR LATCH SWITCH (DRIVER'S SIDE) SIGNAL OR OTHER <ul style="list-style-type: none"> Switch the ignition ON (engine off or on). Access the rear body control module (RBCM) PID DOOR_D using the M-MDS. (See PID/DATA MONITOR INSPECTION [REAR BODY CONTROL MODULE (RBCM)].) Are the DOOR_D PID values congruent with the opening and closing of the driver's door? (See PID/DATA MONITOR TABLE [REAR BODY CONTROL MODULE (RBCM)].) | Yes | Go to Step 15. |
| | | No | Go to the next step. |
| 14 | INSPECT FRONT DOOR LATCH SWITCH (DRIVER'S SIDE) <ul style="list-style-type: none"> Inspect the front door latch switch (driver's side). (See FRONT DOOR LATCH SWITCH INSPECTION.) Is there any malfunction? | Yes | Replace the front door latch and lock actuator (driver's side). (See FRONT DOOR LATCH AND LOCK ACTUATOR REMOVAL/INSTALLATION.) |
| | | No | Repair or replace the wiring harness between front door latch switch (driver's side) and rear body control module (RBCM) for a possible open circuit. |
| 15 | DETERMINE IF MALFUNCTION CAUSE IS DRIVER-SIDE BUCKLE SWITCH SIGNAL OR OTHER <ul style="list-style-type: none"> Switch the ignition ON (engine off or on). Access the SAS control module PID SEAT_B_D using the M-MDS. (See PID/DATA MONITOR INSPECTION.) Is the SEAT_B_D PID value congruent with the seat belt condition? (See PID/DATA MONITOR TABLE.) | Yes | Go to Step 17. |
| | | No | Go to the next step. |
| 16 | INSPECT DRIVER-SIDE BUCKLE SWITCH <ul style="list-style-type: none"> Inspect the driver-side buckle switch. (See BUCKLE SWITCH INSPECTION.) Is there any malfunction? | Yes | Replace the driver-side buckle switch. (See FRONT BUCKLE REMOVAL/INSTALLATION.) |
| | | No | Repair or replace the wiring harness between driver-side buckle switch terminal 4A and SAS control module terminal 2U for a possible short to ground. |
| 17 | DETERMINE IF MALFUNCTION CAUSE IS BONNET LATCH SWITCH SIGNAL OR OTHER <ul style="list-style-type: none"> Switch the ignition ON (engine off). Access the rear body control module (RBCM) PID HOOD_SW using the M-MDS. (See PID/DATA MONITOR INSPECTION [REAR BODY CONTROL MODULE (RBCM)].) Is the HOOD_SW PID value normal? (See PID/DATA MONITOR TABLE [REAR BODY CONTROL MODULE (RBCM)].) | Yes | Repeat the inspection from Step 1. • If the malfunction is not resolved, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0].) Go to Step 23. |
| | | No | Go to the next step. |
| 18 | INSPECT BONNET LATCH SWITCH <ul style="list-style-type: none"> Inspect the bonnet latch switch. (See BONNET LATCH SWITCH INSPECTION.) Is there any malfunction? | Yes | Replace the bonnet latch switch. (See BONNET LATCH AND RELEASE LEVER REMOVAL/INSTALLATION.) |
| | | No | Repair or replace the wiring harness between bonnet latch switch terminal A and rear body control module (RBCM) terminal 3L for a possible open circuit. |
| 19 | DETERMINE IF MALFUNCTION IS CAUSED BY ROUGH IDLING OR A PISTON-STOP POSITION CONTROL MALFUNCTION <ul style="list-style-type: none"> Start the engine and warm it up completely. Verify the idling condition. Is the engine idling rough? | Yes | Inspect the following: <ul style="list-style-type: none"> Air suction into intake-air system Vacuum hose leakage Purge system Electric variable valve timing system Hydraulic variable valve timing system <ul style="list-style-type: none"> If there is any malfunction: <ul style="list-style-type: none"> Repair or replace the malfunctioning part according to the inspection results. |
| | | No | Go to the next step. |

| STEP | INSPECTION | RESULTS | ACTION |
|------|---|---------|---|
| 20 | INSPECT CKP SENSOR SIGNAL WAVE <ul style="list-style-type: none"> Start the engine and idle it. Verify the PCM terminal 1AD output signal wave pattern using an oscilloscope. (See PCM INSPECTION [SKYACTIV-G 2.0].) Is the output wave pattern normal? | Yes | Go to Step 22. |
| | | No | Go to the next step. |
| 21 | INSPECT CKP SENSOR PULSE WHEEL <ul style="list-style-type: none"> Visually inspect the CKP sensor pulse wheel. Are there any cracks or bending in the pulse wheel? | Yes | Replace the crankshaft pulley. (See CRANKSHAFT POSITION (CKP) SENSOR REMOVAL/INSTALLATION [SKYACTIV-G 2.0].) |
| | | No | Inspect the wiring harness between the following terminals: <ul style="list-style-type: none"> CKP sensor terminal A—PCM terminal 1BN CKP sensor terminal C—PCM terminal 1AD CKP sensor terminal B—PCM terminal 1AH — If there is any malfunction: <ul style="list-style-type: none"> Repair or replace the suspected wiring harness. — If there is no malfunction: <ul style="list-style-type: none"> Replace the CKP sensor. (See CRANKSHAFT POSITION (CKP) SENSOR REMOVAL/INSTALLATION [SKYACTIV-G 2.0].) |
| 22 | INSPECT DRIVE-BY-WIRE CONTROL SYSTEM OPERATION <ul style="list-style-type: none"> Perform the Drive-by-wire Control System Inspection. (See ENGINE CONTROL SYSTEM OPERATION INSPECTION [SKYACTIV-G 2.0].) Is the drive-by-wire control system normal? | Yes | Repeat the inspection from Step 1. <ul style="list-style-type: none"> If the malfunction is not resolved, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0].) Go to the next step. |
| | | No | Repair or replace the malfunctioning part according to the inspection results. |
| 23 | Verify the test results. <ul style="list-style-type: none"> If normal, return to the diagnostic index to service any additional symptoms. (See SYMPTOM DIAGNOSTIC INDEX [SKYACTIV-G 2.0].) If a malfunction remains, inspect the related Service Information and perform the repair or diagnosis. <ul style="list-style-type: none"> If the vehicle is repaired, troubleshooting is completed. If the vehicle is not repaired or additional diagnostic information is not available, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0].) | | |