
ROLLOVER VALVE INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5]

id0116zb804500

Note

- The rollover valve cannot be disassembled and inspected as it is built into the fuel tank.
1. Perform the fuel tank inspection. (See FUEL TANK INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
 - If there is any malfunction, replace the fuel tank. (See FUEL TANK REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)