

## MAINTENANCE MONITOR OPERATION PROCEDURE

id092200036700

### Note

- When any of the display conditions is met from the preset maintenance period, the maintenance monitor displays a message.  
**Display condition**
  - Day-setting: Remaining days are 15 days or less
  - Distance setting: Remaining distance is 500 km/250 mile
- The instrument cluster displays a message for which the display conditions are met 0.8 after the ignition is switched ON (engine off or on).
- If several display conditions are met, the instrument cluster displays a message at approx. 5 s intervals according to the following order of precedence.
  - Scheduled Maintenance
  - Tire Rotation
  - Tire Pressure
  - Engine Oil
- The instrument cluster stores the maintenance monitor setting content, and the elapsed time and traveled distance from when the setting was made. The stored setting information is not cleared even if the battery is removed.
- Because the maintenance monitor setting information stored in the instrument cluster cannot be written to a new instrument cluster, if the instrument cluster is replaced, the maintenance monitor is the initial set value. Before replacing the instrument cluster, explain to the customer that the maintenance monitor is reset to the initial setting.

### Scheduled Maintenance Setting Procedure

- Switch the ignition ON (engine off or on).
- Select "Setting" by operating the up/down switch and INFO switch for the steering switch.
- Select "Maintenance" by operating the up/down switch and INFO switch for the steering switch.
- Select "Scheduled" by operating the up/down switch and INFO switch for the steering switch.
- Select the following items and change the setting.

LCD	Function	Initial setting	Setting contents	Control unit
Set Time	Set days until scheduled maintenance is displayed.	<b>European specs.</b> <ul style="list-style-type: none"><li>12 months</li></ul> <b>Except european specs.</b> <ul style="list-style-type: none"><li>6 months</li></ul>	1-36 month	Instrument cluster
Set Distance	Set distance until scheduled maintenance is displayed.	<b>European specs.</b> <ul style="list-style-type: none"><li>20,000 km/12,500 miles</li></ul> <b>Except european specs.</b> <ul style="list-style-type: none"><li>10,000 km/6,250 miles</li></ul>	0-99500 km(0-99750miles)	Instrument cluster
OFF	Turn off scheduled maintenance display.	—	—	Instrument cluster

### Tire Rotation Setting Procedure

- Switch the ignition ON (engine off or on).
- Select "Setting" by operating the up/down switch and INFO switch for the steering switch.
- Select "Maintenance" by operating the up/down switch and INFO switch for the steering switch.
- Select "Tire Rotation" by operating the up/down switch and INFO switch for the steering switch.
- Select the following items and change the setting.

LCD	Function	Initial setting	Setting contents	Control unit
Set Distance	Set distance until tire rotation is displayed.	10,000 km/6,250 miles	0-99500 km(0-99750miles)	Instrument cluster
OFF	Turn off tire rotation display.	—	—	Instrument cluster

### Tire Pressure Setting Procedure

- Switch the ignition ON (engine off or on).
- Select "Setting" by operating the up/down switch and INFO switch for the steering switch.
- Select "Maintenance" by operating the up/down switch and INFO switch for the steering switch.
- Select "Tire Pressure" by operating the up/down switch and INFO switch for the steering switch.
- Select the following items and change the setting.

LCD	Function	Initial setting	Setting contents	Control unit
Set Time	Set day until tire pressure is displayed.	<ul style="list-style-type: none"> <li>European specs. 12 months</li> <li>Except european specs. 6 months</li> </ul>	1-36 month	Instrument cluster
OFF	Turn off tire pressure display.	—	—	Instrument cluster

### Engine Oil Maintenance Monitor Setting Procedure

1. Switch the ignition ON (engine off or on).
2. Select "Setting" by operating the up/down switch and INFO switch for the steering switch.
3. Select "Maintenance" by operating the up/down switch and INFO switch for the steering switch.
4. Select "Oil Change" by operating the up/down switch and INFO switch for the steering switch.
5. Select the following items and change the setting.

LCD	Function	Initial setting	Setting contents	Control unit
Set Distance	Set distance until engine oil maintenance monitor is displayed.	<ul style="list-style-type: none"> <li>10,000 km/6,250 miles (Except Chinese specs.)</li> <li>5,000 km (Chinese specs.)</li> </ul>	0-99500 km(0-99750miles)	Instrument cluster
OFF	Turn off engine oil maintenance monitor display.	—	—	Instrument cluster

### Maintenance Monitor Reset Procedure

#### Note

- This procedure is for returning all of the set content in the maintenance monitor, engine oil maintenance monitor, back to the initial settings.

1. Switch the ignition ON (engine off or on).
2. Select "Setting" by operating the up/down switch and INFO switch for the steering switch.
3. Select the following items and change the setting.

LCD	Function	Initial setting	Setting contents	Control unit
Restore Defaults	Return the maintenance monitor setting content to the initial value.	No	No/Yes	Instrument cluster

### Maintenance Monitor Display/Non-display Setting Procedure

#### Note

- This procedure is for setting all maintenance monitors, engine oil maintenance monitor, to display/non-display. If display/non-display is set for each item, select "OFF" using the setting procedure for each item.

1. Switch the ignition ON (engine off or on).
2. Select "Setting" by operating the up/down switch and INFO switch for the steering switch.
3. Select "Maintenance" by operating the up/down switch and INFO switch for the steering switch.
4. Select the following items and change the setting.

LCD	Function	Initial setting	Setting contents	Control unit
Messages	Set maintenance monitor display (ON)/non-display (OFF).  <b>Note</b> • If the monitor is set to "OFF", the maintenance content is not displayed, however, the set value is counted.	ON	ON/OFF	Instrument cluster