
STEERING ANGLE SENSOR REMOVAL/INSTALLATION

id091800813600

Note

- If the steering angle sensor is removed from the clock spring, the steering angle sensor absolute angle could change, therefore, do not remove the steering angle sensor from the clock spring.
- If the steering angle sensor is replaced, replace it together with the clock spring. (See CLOCK SPRING REMOVAL/INSTALLATION.)