


DTC B11E9:11 [REAR BODY CONTROL MODULE (RBCM)]

id0902p4014600


System malfunction location	Rear door latch switch (LH) circuit malfunction
Detection condition	<ul style="list-style-type: none"> With the rear door (LH) closed (rear door latch switch (LH) off), the rear body control module (RBCM) detects a short to ground in the rear door latch switch (LH) circuit.
Fail-safe	—
Possible cause	<ul style="list-style-type: none"> Rear door latch and lock actuator (LH) connector or terminal malfunction Rear door latch switch (LH) malfunction Rear body control module (RBCM) connector or terminal malfunction Short to ground in wiring harness between rear body control module (RBCM) terminal 3S and rear door latch and lock actuator (LH) terminal L Rear body control module (RBCM) malfunction

RBCM



3S


REAR DOOR LATCH SWITCH (LH)
(REAR DOOR LATCH AND LOCK ACTUATOR (LH))




DOOR OPEN ON

L J

RBCM
WIRING HARNESS-SIDE CONNECTOR



REAR DOOR LATCH AND LOCK ACTUATOR (LH)
WIRING HARNESS-SIDE CONNECTOR



Diagnostic Procedure

Step	Inspection	Action
1	<p>VERIFY REAR BODY CONTROL MODULE (RBCM) DTCs AGAIN</p> <ul style="list-style-type: none"> Clear rear body control module (RBCM) DTCs using the M-MDS. (See CLEARING DTC [REAR BODY CONTROL MODULE (RBCM)].) Perform the DTC inspection for the rear body control module (RBCM) using the M-MDS. (See DTC INSPECTION [REAR BODY CONTROL MODULE (RBCM)].) Is DTC B11E9:11 displayed? 	<p>Yes: Go to the next step.</p> <p>No: Go to Step 7.</p>

Step	Inspection	Action
2	INSPECT REAR DOOR LATCH AND LOCK ACTUATOR (LH) CONNECTOR <ul style="list-style-type: none"> • Switch the ignition to off. • Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].) • Disconnect the rear door latch and lock actuator (LH) connector. • Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection. • Is the connector normal? 	Yes Go to the next step.
		No Repair or replace the connector, then go to Step 6.
3	INSPECT REAR DOOR LATCH SWITCH (LH) <ul style="list-style-type: none"> • Inspect the rear door latch switch (LH). (See REAR DOOR LATCH SWITCH INSPECTION.) • Is the rear door latch switch (LH) normal? 	Yes Go to the next step.
		No Replace the rear door latch and lock actuator (LH), then go to Step 6. (See REAR DOOR LATCH AND LOCK ACTUATOR REMOVAL/INSTALLATION.)
4	INSPECT REAR BODY CONTROL MODULE (RBCM) CONNECTOR CONDITION <ul style="list-style-type: none"> • Disconnect the rear body control module (RBCM) connector. • Inspect the connector engagement and connection condition and inspect the terminals for damage, deformation, corrosion, or disconnection. • Is the connector normal? 	Yes Go to the next step.
		No Repair or replace the connector, then go to Step 6.
5	INSPECT REAR DOOR LATCH SWITCH (LH) CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> • Verify that the rear body control module (RBCM) connector and rear door latch and lock actuator (LH) connector are disconnected. • Inspect for continuity between rear door latch and lock actuator (LH) terminal L (vehicle wiring harness) and body ground. • Is there continuity? 	Yes Repair or replace the wiring harness which has a short to ground, then go to the next step.
		No Go to the next step.

Step	Inspection	Action
6	VERIFY THAT REPAIRS HAVE BEEN COMPLETED <ul style="list-style-type: none"> Reconnect all the disconnected connectors. Reconnect the disconnected negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].) Clear rear body control module (RBCM) DTCs using the M-MDS. (See CLEARING DTC [REAR BODY CONTROL MODULE (RBCM)].) Perform the DTC inspection for the rear body control module (RBCM) using the M-MDS. (See DTC INSPECTION [REAR BODY CONTROL MODULE (RBCM)].) Is DTC B11E9:11 displayed? 	Yes Repeat the inspection from Step 1. • If the malfunction recurs, replace the rear body control module (RBCM), then go to the next step. (See REAR BODY CONTROL MODULE (RBCM) REMOVAL/INSTALLATION.)
		No Go to the next step.
7	VERIFY IF OTHER DTCs DISPLAYED <ul style="list-style-type: none"> Are any other DTCs displayed? 	Yes Repair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [REAR BODY CONTROL MODULE (RBCM)].)
		No DTC troubleshooting completed.