

---

## REAR SHOCK ABSORBER INSPECTION

id021400801400

1. Remove the rear shock absorber. (See REAR SHOCK ABSORBER REMOVAL/INSTALLATION.)
2. Inspect for damage and oil leakage.
3. Compress and extend the shock piston at least three times. Verify that the operational force does not change and that there is no unusual noise.
  - If not as specified, replace the rear shock absorber.