

## OIL SEAL (DIFFERENTIAL) REPLACEMENT [FW6A-EL, FW6AX-EL]

id0517h2118800


### Transaxle Case Side

1. Remove the front under cover No.2. (See FRONT UNDER COVER No.2 REMOVAL/INSTALLATION.)
2. Drain the ATF. (See AUTOMATIC TRANSAXLE FLUID (ATF) REPLACEMENT [FW6A-EL, FW6AX-EL].)
3. Disconnect the front drive shaft (LH) from the transaxle. (See FRONT DRIVE SHAFT REMOVAL/INSTALLATION.)

#### Caution


- The oil seal is easily damaged by the sharp edges of the drive shaft splines. Do not let the splines contact the oil seal.

4. Remove the oil seal using a flathead screwdriver.



ac5uuw00000215

5. Using the **SSTs** and a hammer, tap a new oil seal in evenly until the **SST (49 U027 003)** contacts the transaxle case.
6. Coat the lip of the oil seal with ATF.
7. Install the front drive shaft (LH) to the transaxle. (See FRONT DRIVE SHAFT REMOVAL/INSTALLATION.)
8. Add the ATF. (See AUTOMATIC TRANSAXLE FLUID (ATF) REPLACEMENT [FW6A-EL, FW6AX-EL].)
9. Install the front under cover No.2. (See FRONT UNDER COVER No.2 REMOVAL/INSTALLATION.)
10. Perform the "Mechanical System Test". (See MECHANICAL SYSTEM TEST [FW6A-EL, FW6AX-EL].)



ac5uuw00000216


### Converter Housing Side (FW6A-EL)

1. Remove the front under cover No.2. (See FRONT UNDER COVER No.2 REMOVAL/INSTALLATION.)
2. Drain the ATF. (See AUTOMATIC TRANSAXLE FLUID (ATF) REPLACEMENT [FW6A-EL, FW6AX-EL].)
3. Disconnect the front drive shaft (RH). (See FRONT DRIVE SHAFT REMOVAL/INSTALLATION.)


#### Caution

- The oil seal is easily damaged by the sharp edges of the drive shaft splines. Do not let the splines contact the oil seal.

4. Remove the oil seal using a flathead screwdriver.



5. Using the **SSTs** and a hammer, tap a new oil seal in evenly until the **SST (49 U027 003)** contacts the transaxle case.
6. Coat the lip of the oil seal with ATF.
7. Install the front drive shaft (RH). (See FRONT DRIVE SHAFT REMOVAL/INSTALLATION.)
8. Add the ATF. (See AUTOMATIC TRANSAXLE FLUID (ATF) REPLACEMENT [FW6A-EL, FW6AX-EL].)
9. Install the front under cover No.2. (See FRONT UNDER COVER No.2 REMOVAL/INSTALLATION.)
10. Perform the "Mechanical System Test". (See MECHANICAL SYSTEM TEST [FW6A-EL, FW6AX-EL].)




#### Converter Housing Side (FW6AX-EL)

1. Remove the front under cover No.2. (See FRONT UNDER COVER No.2 REMOVAL/INSTALLATION.)
2. Drain the ATF. (See AUTOMATIC TRANSAXLE FLUID (ATF) REPLACEMENT [FW6A-EL, FW6AX-EL].)
3. Remove the transfer. (See TRANSFER REMOVAL/INSTALLATION [FW6AX-EL].)


#### Caution

- The oil seal is easily damaged by the sharp edges of the drive shaft splines. Do not let the splines contact the oil seal.

4. Remove the oil seal using a flathead screwdriver.



5. Using the **SSTs** and a hammer, tap a new oil seal in evenly until the **SST (49 U027 003)** contacts the transaxle case.
6. Coat the lip of the oil seal with ATF.
7. Install the transfer. (See TRANSFER REMOVAL/ INSTALLATION [FW6AX-EL].)
8. Add the ATF. (See AUTOMATIC TRANSAXLE FLUID (ATF) REPLACEMENT [FW6A-EL, FW6AX-EL].)
9. Install the front under cover No.2. (See FRONT UNDER COVER No.2 REMOVAL/ INSTALLATION.)
10. Perform the "Mechanical System Test". (See MECHANICAL SYSTEM TEST [FW6A-EL, FW6AX-EL].)



ac5wzw00000913