


DTC P2504:00	Charging system voltage high input
DETECTION CONDITION	<ul style="list-style-type: none"> The PCM determines that the generator output voltage is more than 18.5 V, or battery voltage is more than 16.0 V, for 5 s while the engine is running. Diagnostic support note <ul style="list-style-type: none"> This is a continuous monitor (other). The check engine light does not illuminate. FREEZE FRAME DATA (Mode 2)/Snapshot data is not available. The DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	<ul style="list-style-type: none"> Illuminates the charging system warning light.
POSSIBLE CAUSE	<ul style="list-style-type: none"> Generator connector or terminals malfunction PCM connector or terminals malfunction Short to power supply in wiring harness between generator terminal 2B and PCM terminal 1BE Generator malfunction PCM malfunction



Diagnostic Procedure

STEP	INSPECTION		ACTION
1	VERIFY RELATED SERVICE INFORMATION AVAILABILITY <ul style="list-style-type: none"> Verify related Service Information availability. Is any related Service Information available? 	Yes	Perform repair or diagnosis according to the available Service Information.
		No	Go to the next step.
2	INSPECT GENERATOR CONNECTOR CONDITION <ul style="list-style-type: none"> Switch the ignition to off. Disconnect the generator connector. Inspect for poor connection (such as damaged/pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 6.
		No	Go to the next step.

STEP	INSPECTION		ACTION
3	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> • Disconnect the PCM connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 6.
		No	Go to the next step.
4	INSPECT GENERATOR CONTROL CIRCUIT FOR SHORT TO POWER SUPPLY <ul style="list-style-type: none"> • Verify that the generator and PCM connectors are disconnected. • Switch the ignition ON (engine off or on). • Measure the voltage at the generator terminal 2B (wiring harness-side). • Is the voltage 0 V? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible short to power supply, then go to Step 6.
5	INSPECT GENERATOR <ul style="list-style-type: none"> • Switch the ignition to off. • Inspect the generator. (See GENERATOR INSPECTION [SKYACTIV-G 2.0].) • Is there any malfunction? 	Yes	Repair or replace the malfunctioning part according to the inspection results, then go to the next step. (See GENERATOR DISASSEMBLY/ASSEMBLY [SKYACTIV-G 2.0].) (See GENERATOR REMOVAL/INSTALLATION [SKYACTIV-G 2.0].)
		No	Go to the next step.
6	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> • Make sure to reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0].) • Perform the KOER self test. (See KOEO/KOER SELF TEST [SKYACTIV-G 2.0].) • Is the same DTC present? 	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0].) Go to the next step.
		No	Go to the next step.
7	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> • Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0].) • Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0].)
		No	DTC troubleshooting completed.