

DTC P2565:00	Regulating valve position sensor circuit high input
DETECTION CONDITION	<ul style="list-style-type: none"> If the input voltage at the PCM terminal 1BP is more than 4.9 V for 1 s, the PCM determines that the regulating valve position sensor circuit has a malfunction. <p>MONITORING CONDITIONS</p> <ul style="list-style-type: none"> Battery voltage: 8—20 V <p>Diagnostic support note</p> <ul style="list-style-type: none"> This is a continuous monitor (CCM). The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle. FREEZE FRAME DATA (Mode 2)/Snapshot data is available. DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	<ul style="list-style-type: none"> Inhibits engine-stop by operating the i-stop function. PCM restricts engine-transaxle integration control.
POSSIBLE CAUSE	<ul style="list-style-type: none"> Regulating valve position sensor connector or terminals malfunction PCM connector or terminals malfunction Short to power supply in wiring harness between regulating valve position sensor terminal B and PCM terminal 1BP Regulating valve position sensor power supply circuit and signal circuit are shorted to each other Open circuit in wiring harness between the following terminals: <ul style="list-style-type: none"> Regulating valve position sensor terminal B—PCM terminal 1BP Regulating valve position sensor terminal A—PCM terminal 1BN Regulating valve position sensor malfunction PCM malfunction
<p style="text-align: center;">⑧</p> <div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;"> <p>REGULATING VALVE POSITION SENSOR</p> <p>REGULATING VALVE POSITION SENSOR WIRING HARNESS-SIDE CONNECTOR</p> </div> <div style="text-align: center;"> <p>PCM</p> </div> </div> <p style="text-align: center;">PCM WIRING HARNESS-SIDE CONNECTOR</p>	

Diagnostic Procedure

STEP	INSPECTION		ACTION
1	VERIFY FREEZE FRAME DATA (MODE 2)/ SNAPSHOT DATA HAS BEEN RECORDED <ul style="list-style-type: none"> Has the FREEZE FRAME DATA (Mode 2)/ snapshot data been recorded? 	Yes	Go to the next step.
		No	Record the FREEZE FRAME DATA (Mode 2)/snapshot data on the repair order, then go to the next step.
2	VERIFY RELATED SERVICE INFORMATION AVAILABILITY <ul style="list-style-type: none"> Verify related Service Information availability. Is any related Service Information available? 	Yes	Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	INSPECT REGULATING VALVE POSITION SENSOR CONNECTOR CONDITION <ul style="list-style-type: none"> Switch the ignition off. Disconnect the regulating valve position sensor connector. Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 9.
		No	Go to the next step.
4	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> Disconnect the PCM connector. Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 9.
		No	Go to the next step.
5	INSPECT REGULATING VALVE POSITION SENSOR CIRCUIT FOR SHORT TO POWER SUPPLY <ul style="list-style-type: none"> Verify that the regulating valve position sensor and PCM connectors are disconnected. Switch the ignition ON (engine off). Measure the voltage at the regulating valve position sensor terminal B (wiring harness-side). Is the voltage 0 V? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible short to power supply, then go to Step 9.
6	INSPECT REGULATING VALVE POSITION SENSOR POWER SUPPLY CIRCUIT AND SIGNAL CIRCUIT FOR SHORT TO EACH OTHER <ul style="list-style-type: none"> Verify that the regulating valve position sensor and PCM connectors are disconnected. Switch the ignition off. Inspect for continuity between regulating valve position sensor terminals C and B (wiring harness-side). Is there continuity? 	Yes	Repair or replace the wiring harness for a possible short to each other, then go to Step 9.
		No	Go to the next step.
7	INSPECT REGULATING VALVE POSITION SENSOR CIRCUIT FOR OPEN CIRCUIT <ul style="list-style-type: none"> Verify that the regulating valve position sensor and PCM connectors are disconnected. Inspect for continuity between the following terminals (wiring harness-side): <ul style="list-style-type: none"> Regulating valve position sensor terminal B— PCM terminal 1BP Regulating valve position sensor terminal A— PCM terminal 1BN Is there continuity? 	Yes	Go to the next step.
		No	Repair or replace the wiring harness for a possible open circuit, then go to Step 9.
8	INSPECT REGULATING VALVE POSITION SENSOR <ul style="list-style-type: none"> Reconnect all disconnected connectors. Inspect the regulating valve position sensor. (See REGULATING VALVE POSITION SENSOR INSPECTION [SKYACTIV-D 2.2].) Is there any malfunction? 	Yes	Replace the regulating valve actuator, then go to the next step. (See TURBOCHARGER REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
		No	Go to the next step.

STEP	INSPECTION	ACTION	
9	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> • Always reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].) • Perform the KOEO or KOER self test. (See KOEO/KOER SELF TEST [SKYACTIV-D 2.2].) • Is the same DTC present? 	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) Go to the next step.
		No	Go to the next step.
10	VERIFY AFTER REPAIR PROCEDURE <ul style="list-style-type: none"> • Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].) • Are any DTCs present? 	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-D 2.2].)
		No	DTC troubleshooting completed.