

## SYMPTOM TROUBLESHOOTING [REAR VEHICLE MONITORING SYSTEM]

id0903z7378800

No.	Troubleshooting item	Description
1	RVM INDICATOR LIGHT (GREEN)/RVM WARNING INDICATOR LIGHT DOES NOT ILLUMINATE WHEN IGNITION IS SWITCHED ON [REAR VEHICLE MONITORING SYSTEM]	<ul style="list-style-type: none"> <li>The RVM indicator light (green) does not illuminate when the ignition is switched ON.</li> <li>The RVM warning indicator light does not illuminate when the ignition is switched ON.</li> <li>No communication with M-MDS.</li> </ul>
2	RVM INDICATOR LIGHT (GREEN) DOES NOT TURN OFF WHEN REAR VEHICLE MONITORING SYSTEM IS OFF [REAR VEHICLE MONITORING SYSTEM]	<ul style="list-style-type: none"> <li>The RVM indicator light (green) does not turn off even though the RVM switch turns off after the ignition is switched ON.</li> </ul>
3	RVM INDICATOR LIGHT (GREEN) DOES NOT ILLUMINATE [REAR VEHICLE MONITORING SYSTEM]	<ul style="list-style-type: none"> <li>The RVM indicator light (green) does not illuminate even though the RVM switch turns on after the ignition is switched ON.</li> </ul>
4	RVM WARNING INDICATOR LIGHT ILLUMINATES WHILE NOT UNDER ILLUMINATION CONDITIONS [REAR VEHICLE MONITORING SYSTEM]	<ul style="list-style-type: none"> <li>The RVM warning indicator light illuminates without satisfying its illumination conditions (<b>vehicle speed is 30 km/h {19 mph} or more</b>, turn switch is off, and a vehicle is in the detection area).</li> </ul>
5	RVM WARNING INDICATOR LIGHT DOES NOT ILLUMINATE UNDER ILLUMINATION CONDITIONS [REAR VEHICLE MONITORING SYSTEM]	<ul style="list-style-type: none"> <li>The RVM warning indicator light flashes/does not illuminate while under the illumination conditions (<b>Vehicle speed above 30 km/h {19 mph}</b>, turn switch is off, and vehicle in detection area).</li> </ul>
6	RVM WARNING INDICATOR LIGHT FLASHES WHILE NOT UNDER FLASHING CONDITIONS (TURN SIGNALS OFF, OR NO VEHICLE IN ALERT AREA) [REAR VEHICLE MONITORING SYSTEM]	<ul style="list-style-type: none"> <li>The RVM warning indicator light flashes while not under the flash conditions (<b>Vehicle speed above 30 km/h {19 mph}</b>, turn switch is on, and vehicle in detection area).</li> <li>RVM warning indicator light flashes even though turn switch is off.</li> </ul>
7	RVM WARNING INDICATOR LIGHT DOES NOT FLASH WHILE UNDER FLASHING CONDITIONS (TURN SIGNAL IS BEING OPERATED) [REAR VEHICLE MONITORING SYSTEM]	<ul style="list-style-type: none"> <li>The RVM warning indicator light does not flash/ remains illuminated while under the flash conditions (<b>vehicle speed 30 km/h {19 mph} or more</b>, turn switch is on, and vehicle in detection area).</li> <li>RVM warning indicator light does not flash/ illuminates as is even though turn switch is on.</li> </ul>
8	REAR VEHICLE MONITORING WARNING ALARM DOES NOT SOUND WHILE RVM WARNING INDICATOR LIGHT IS FLASHING [REAR VEHICLE MONITORING SYSTEM]	<ul style="list-style-type: none"> <li>The rear vehicle monitoring warning chime does not sound when the vehicle is in the detection area on the side in which the turn switch is on, and the RVM warning indicator light is flashing.</li> </ul>
9	BRIGHTNESS LEVEL OF RVM WARNING INDICATOR LIGHTS IS TOO HIGH OR LOW [REAR VEHICLE MONITORING SYSTEM]	<ul style="list-style-type: none"> <li>RVM warning indicator light illumination brightness is weak during the afternoon (headlights off). (Appropriate brightness during nighttime)</li> <li>RVM warning indicator light illumination brightness is strong during the night (headlights on). (Appropriate brightness at night)</li> </ul>