
SUNROOF SYSTEM INITIALIZATION PROCEDURE

id091500858000

- If the following operations have been performed, initial setting is reset, and except tilt up operation are disabled. Therefore, performing initial setting is necessary.
 - Negative battery cable is disconnected. (See NEGATIVE BATTERY CABLE DISCONNECTION/ CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5 (WITHOUT i-stop)].) (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION [SKYACTIV-D 2.2].)
 - Sunroof switch connector is disconnected.
 - Sunroof system power supply fuse is removed.
- 1. Switch the ignition ON (engine off or on).
- 2. Press the tilt up switch to fully tilt up the glass panel.