

5. MAIN Electrical Parts List

Part Code	Design Loc	Description
0406-001505	ZD5001	DIODE-TVS
0406-001514	ZD5007	DIODE-TVS
0406-001592	ZD5020	DIODE-TVS
0406-001623	ZD5000,ZD5016	DIODE-TVS
0406-001625	ZD5019	DIODE-TVS
0406-001642	ZD5012,ZD5013,ZD5014	DIODE-TVS
0406-001695	ZD5015	DIODE-TVS
0406-001708	ZD5003	DIODE-TVS
0406-001709	D5000,D5001,ZD5004	DIODE-TVS
0406-001709	ZD5005,ZD5006	DIODE-TVS
0406-001728	D4000	DIODE-TVS
0406-001730	D4001	DIODE-TVS
0601-003582	LED400	DIODE-LED
1001-001870	U2005	IC-RF SWITCH
1001-001912	U1000	IC-RF SWITCH
1001-001971	U1002	IC-IF/RF AMP
1201-003786	U2000	IC-GPS AMP
1201-003812	PAM1001	IC-IF/RF AMP
1201-003915	PAM1000	IC-IF/RF AMP
1203-008149	U600	IC-LCD BLIC
1203-008416	U4000	IC-POWER AMP
1203-008722	U4001	IC-CHARGER
1205-005175	U4003	IC-MUIC
1205-005296	U2001	IC-BT/WIFI
1205-005310	U2002	IC-GPS
1205-005315	U4002	IC-Load Switch
1205-005495	U2009	IC-TRANSCIVER
1205-005498	U3000	IC-MODEM
1209-002151	U602	IC- ACCELEROMETER SENSOR
1108-000612	UME3000	IC-eMMC MEMORY
1404-001694	TH4000,TH4001	THERMISTOR-NTC
1405-001183	ZD5008,ZD5010	VARISTOR
2007-000169	R4030	R-CHIP
2007-003025	R608	R-CHIP
2007-007107	R4023	R-CHIP
2007-007190	R4005,R4006	R-CHIP
2007-007318	R4021,R5012	R-CHIP
2007-007741	R3006,R3027	R-CHIP
2007-007741	R3034,R3035,R5008	R-CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2007-007741	R5010,R5015,R5016	R-CHIP
2007-007861	R4000,R4001	R-CHIP
2007-008047	R1002,R1003	R-CHIP
2007-008294	R618	R-CHIP
2007-008420	R1000	R-CHIP
2007-008531	R3037,R4012,R4026	R-CHIP
2007-008587	R4017,R4018,R5004	R-CHIP
2007-008648	R4009	R-CHIP
2007-009157	R5027,R609	R-CHIP
2007-009158	R4002,R4003	R-CHIP
2007-009212	R4010,R4011,R4013	R-CHIP
2007-009212	R4014,R4016,R4025	R-CHIP
2007-009212	R5001,R5011,R5022	R-CHIP
2007-009212	R607	R-CHIP
2007-009315	R4027,R4029	R-CHIP
2007-009352	R614,R615	R-CHIP
2007-009402	R1004	R-CHIP
2007-009408	R4007,R4008,R603	R-CHIP
2007-009766	R4004	R-CHIP
2007-009801	R4019	R-CHIP
2007-009805	R1001	R-CHIP
2007-009920	R3019,R3030	R-CHIP
2007-009924	R4032	R-CHIP
2007-009969	R5023	R-CHIP
2007-010233	R3015,R3017,R3018	R-CHIP
2007-010848	R4022	R-CHIP
2007-011043	R3024	R-CHIP
2203-000233	C2055	C-CER,CHIP
2203-000425	C605	C-CER,CHIP
2203-000679	C2004	C-CER,CHIP
2203-000854	C4075,C4083,C607	C-CER,CHIP
2203-001072	C4088	C-CER,CHIP
2203-001153	C4076,C4082	C-CER,CHIP
2203-001383	C1007	C-CER,CHIP
2203-005249	C604	C-CER,CHIP
2203-005682	C1004,C1010,C1048	C-CER,CHIP
2203-005682	C1083,C2015,C2016	C-CER,CHIP
2203-005682	C2091,C2097,C5010	C-CER,CHIP
2203-005682	C5024,C5031,C5037	C-CER,CHIP
2203-005682	C5038	C-CER,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2203-005717	C2001,C2025,C2027	C-CER,CHIP
2203-005725	C1005,C1088,C2031	C-CER,CHIP
2203-005725	C2090,L1000	C-CER,CHIP
2203-005729	C5021	C-CER,CHIP
2203-005731	C5028	C-CER,CHIP
2203-005732	C4074,C5022,C5026	C-CER,CHIP
2203-005736	C1020,C1039,C1040	C-CER,CHIP
2203-005736	C1084,C2005,C2006	C-CER,CHIP
2203-005736	C2007,C2008,C2014	C-CER,CHIP
2203-005736	C2038,C2042,C2051	C-CER,CHIP
2203-005736	C2069,C2088,C2099	C-CER,CHIP
2203-005736	C2100,C2101,C4089	C-CER,CHIP
2203-005736	L1024	C-CER,CHIP
2203-005742	C1087	C-CER,CHIP
2203-005777	C1046,C1080,C1085	C-CER,CHIP
2203-005789	C1006,C1047	C-CER,CHIP
2203-005792	C1030,C1037,C1058	C-CER,CHIP
2203-006048	C1026,C4050,C612	C-CER,CHIP
2203-006121	C1027	C-CER,CHIP
2203-006123	C1041	C-CER,CHIP
2203-006137	C4048	C-CER,CHIP
2203-006187	C1031,C1035,C2053	C-CER,CHIP
2203-006187	C2074	C-CER,CHIP
2203-006194	C3010	C-CER,CHIP
2203-006305	C2035,C2043,C2057	C-CER,CHIP
2203-006305	C2060,C2078,C4000	C-CER,CHIP
2203-006305	C4009	C-CER,CHIP
2203-006379	C4067,C4068	C-CER,CHIP
2203-006399	C1014,C1015,C2021	C-CER,CHIP
2203-006399	C2022,C2023,C3018	C-CER,CHIP
2203-006399	C3021,C3026,C3027	C-CER,CHIP
2203-006399	C3039,C3053,C4008	C-CER,CHIP
2203-006399	C4015,C4017,C4021	C-CER,CHIP
2203-006399	C4041,C4042,C5016	C-CER,CHIP
2203-006399	C610,C625	C-CER,CHIP
2203-006400	C1019,C1081,C2002	C-CER,CHIP
2203-006400	C2011,C2085,C2092	C-CER,CHIP
2203-006410	C1051	C-CER,CHIP
2203-006423	C1032,C1034,C1072	C-CER,CHIP
2203-006423	C1075,C1077,C2058	C-CER,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2203-006423	C2059,C2061,C2079	C-CER,CHIP
2203-006423	C3000,C3001,C3003	C-CER,CHIP
2203-006423	C3004,C3006,C3009	C-CER,CHIP
2203-006423	C3014,C3016,C3017	C-CER,CHIP
2203-006423	C3023,C3031,C3032	C-CER,CHIP
2203-006423	C3033,C3034,C3035	C-CER,CHIP
2203-006423	C3036,C3037,C3040	C-CER,CHIP
2203-006423	C3041,C3042,C3043	C-CER,CHIP
2203-006423	C3046,C3049,C3051	C-CER,CHIP
2203-006423	C3058,C3062,C4011	C-CER,CHIP
2203-006423	C4080,C5000,C5027	C-CER,CHIP
2203-006423	C5029,C621,C622	C-CER,CHIP
2203-006556	C1024,C2032	C-CER,CHIP
2203-006562	C1078,C4047,C4069	C-CER,CHIP
2203-006562	C4073	C-CER,CHIP
2203-006611	C2064	C-CER,CHIP
2203-006665	C1044,C2070	C-CER,CHIP
2203-006668	C4053	C-CER,CHIP
2203-006707	C2104	C-CER,CHIP
2203-006815	C1079,C5005,C5007	C-CER,CHIP
2203-006839	C4025,C4026,C4030	C-CER,CHIP
2203-006839	C5009,C5020,C603	C-CER,CHIP
2203-006846	C2077	C-CER,CHIP
2203-006872	C2024,C2028,C3022	C-CER,CHIP
2203-006872	C3038,C4001,C4002	C-CER,CHIP
2203-006872	C4006,C4014,C4016	C-CER,CHIP
2203-006872	C4019,C4020,C4022	C-CER,CHIP
2203-006872	C4029,C4040,C609	C-CER,CHIP
2203-006872	C615,C618,C624	C-CER,CHIP
2203-006890	C2040,C3011,C3015	C-CER,CHIP
2203-006890	C4036,C4061,C4063	C-CER,CHIP
2203-006890	C4066,C4085	C-CER,CHIP
2203-006979	C2037,C3057,C5006	C-CER,CHIP
2203-007240	C3007,C4060,C4062	C-CER,CHIP
2203-007240	C4064,C4065	C-CER,CHIP
2203-007270	C4054	C-CER,CHIP
2203-007271	C2026,C2036,C2089	C-CER,CHIP
2203-007271	C3005,C3012,C4023	C-CER,CHIP
2203-007271	C4043,C4059,C4071	C-CER,CHIP
2203-007271	C4078,C4079	C-CER,CHIP

5. MAIN Electrical Parts List

2203-007317	C2041,C2056,C3028	C-CER,CHIP
2203-007317	C3029,C3050,C3052	C-CER,CHIP
2203-007317	C4003,C4005,C4007	C-CER,CHIP
2203-007317	C4049,C4052,C5023	C-CER,CHIP
2203-007317	C617	C-CER,CHIP
2203-007369	C2033	C-CER,CHIP
2203-007393	C1017,C4024,C4027	C-CER,CHIP
2203-007393	C4031,C4032,C4033	C-CER,CHIP
2203-007393	C4034,C4035,C4037	C-CER,CHIP
2203-007393	C4038,C4077	C-CER,CHIP
2203-007449	C1000,C1001,C1028	C-CER,CHIP
2203-007449	C1076,C2000,C2003	C-CER,CHIP
2203-007449	C2029,C2030,C2034	C-CER,CHIP
2203-007449	C3019,C3020,C3024	C-CER,CHIP
2203-007449	C3025,C4010,C4012	C-CER,CHIP
2203-007449	C4018,C4055,C4056	C-CER,CHIP
2203-007449	C4057,C4058,C4070	C-CER,CHIP
2203-007449	C4084,C5012,C611	C-CER,CHIP
2203-007474	C3008,C3013,C4046	C-CER,CHIP
2203-007474	C608	C-CER,CHIP
2203-007634	C4081,C606	C-CER,CHIP
2203-008097	C2080,C2081,C2082	C-CER,CHIP
2203-008242	C3002,C4013,C4039	C-CER,CHIP
2203-008242	C4044	C-CER,CHIP
2203-008529	C602,C628	C-CER,CHIP
2203-008654	C4072	C-CER,CHIP
2203-008790	C4004	C-CER,CHIP
2203-008860	C1018	C-CER,CHIP
2203-009733	C4028,C4045	C-CER,CHIP
2703-002267	L1004	INDUCTOR-SMD
2703-002309	L5005	INDUCTOR-SMD
2703-002649	L2001	INDUCTOR-SMD
2703-002958	L2004	INDUCTOR-SMD
2703-002960	C1045,L1012,L2012	INDUCTOR-SMD
2703-002960	L2016	INDUCTOR-SMD
2703-003878	L5006	INDUCTOR-SMD
2703-004012	L1008,L1014,L1046	INDUCTOR-SMD
2703-004012	L1054,L2010,L2017	INDUCTOR-SMD
2703-004013	L2019	INDUCTOR-SMD
2703-004014	L1006,L1048,L1055	INDUCTOR-SMD

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2703-004032	L1021	INDUCTOR-SMD
2703-004034	L1005,L1013	INDUCTOR-SMD
2703-004035	L1011,L1052,L2008	INDUCTOR-SMD
2703-004036	L1018	INDUCTOR-SMD
2703-004037	L1003,L1015,L2003	INDUCTOR-SMD
2703-004038	L1026,L1047,L1051	INDUCTOR-SMD
2703-004038	L2013,L2014	INDUCTOR-SMD
2703-004259	L1027,L1030	INDUCTOR-SMD
2703-004299	L1032	INDUCTOR-SMD
2703-004318	L4003,L4006,L4007	INDUCTOR-SMD
2703-004328	L1017	INDUCTOR-SMD
2703-004366	L1041	INDUCTOR-SMD
2703-004367	L1033	INDUCTOR-SMD
2703-004368	L1031,L1035,L1042	INDUCTOR-SMD
2703-004599	L4004,L4005	INDUCTOR-SMD
2703-004763	L1044	INDUCTOR-SMD
2703-004764	L1020,L1043	INDUCTOR-SMD
2703-004862	L1040,L1053	INDUCTOR-SMD
2703-004911	L1002	INDUCTOR-SMD
2703-004976	L2020	INDUCTOR-SMD
2703-005058	L1022,L1023,L1025	INDUCTOR-SMD
2703-005086	L2021	INDUCTOR-SMD
2703-005116	L4008	INDUCTOR-SMD
2703-005118	L603	INDUCTOR-SMD
2703-005340	L4001,L4002	INDUCTOR-SMD
2703-005366	L2022	INDUCTOR-SMD
2801-004820	OSC4000	CRYSTAL-SMD
2805-001113	OSC2000	OSCILLATOR-TCXO
2809-001411	OSC2001	OSCILLATOR-VCTCXO
2901-001798	F600,F601,F602	FILTER-SAW
2904-002169	F2000,F2002	FILTER-SAW
2904-002257	F1001,F2003	FILTER-SAW
2904-002285	F1006	FILTER-SAW
2904-002314	F2001	FILTER-SAW
2910-000253	F1005	FILTER-SAW
2911-000409	F1002	FILTER-SAW
2911-000419	U2007	FILTER-SAW
3003-001233	MIC5000	Main MIC
3301-001438	L2007	BEAD-SMD
3301-001534	L604	BEAD-SMD

5. MAIN Electrical Parts List

3301-001787	L5014,L5015	BEAD-SMD
3301-001820	L3000	BEAD-SMD
3301-001885	L5001,L5004,L5011	BEAD-SMD
3301-001895	L1016,L600	BEAD-SMD
3301-001917	L5000,L5007,L5008	BEAD-SMD
3301-001917	L5010,L5013	BEAD-SMD
3301-002063	L602	BEAD-SMD
3301-002223	L601,L605,L606	BEAD-SMD
3301-002236	L1019,L2011,L2015	BEAD-SMD
3301-002237	L5016,L5017	BEAD-SMD
3301-002238	L2000	BEAD-SMD
3301-002242	L5002,L5003	BEAD-SMD
3301-002254	L4000,L4009,L4010	BEAD-SMD
3301-002287	L1001,L5009	BEAD-SMD
3404-001540	TAC5000,TAC5001	TACT-SWITCH
3404-001540	TAC5002	TACT-SWITCH
3404-001542	CN5000	TACT-SWITCH
3705-001708	RFS1000	CONNECTOR-COAXIAL
3708-003254	CAM601	VGA ZIP CONNECTOR
3709-001877	CD5000	SD CARD SOCKET
3709-001878	SIM5002	SIM CARD SOCKET
3710-003306	CAM600	CAM SOCKET
3711-007107	HDC600	HEADER-BOARD TO BOARD
3711-008670	BTC4000	CONNECTOR-BATTERY
3712-001604	ANT1000,ANT1001	CONNECTOR-TERMINAL
3712-001604	ANT2000,ANT2001	CONNECTOR-TERMINAL
3712-001604	ANT2002	CONNECTOR-TERMINAL
3712-001621	ANT4000,ANT4001	CONNECTOR-TERMINAL
3712-001621	ANT5000,ANT5001	CONNECTOR-TERMINAL
3722-003678	IFC4000	CONNECTOR-IF
3722-003984	EAR5000	EAR JACK SOCKET
4709-002193	F1000	FREQ-DISTRIBUTER
GH61-10812A	CN1000,CN1001	SUS-SCREW PLATE

Please consult the GSPN website (Samsung Portal) for the most recent version of the product's part list.