

5. MAIN Electrical Parts List

Parts Code	Design LOC	Description
0202-002125	R10005,R5069	PB-SHORT-0603
0202-002126	R7038,R7039,R7040	PB-SHORT-1005
0401-001110	D7004	DIODE
0404-001250	D4000,D7003	DIODE
0406-001592	ZD11000,ZD11001,ZD11002,ZD11003, ZD11004,ZD11006,ZD11007,ZD11008	DIODE
0406-001728	ZD7000	DIODE
0406-001729	ZD7001,ZD7002	DIODE
0406-001797	ZD4004,ZD4005	DIODE
0406-001805	ZD7003	DIODE
0505-003234	Q7000	FET
0601-003749	LED9000	LED
0903-002233	U9000	IC
1001-001755	U4029	IC
1001-001975	U1301	IC
1001-002038	U3049,U3050	IC
1001-002045	U7040	IC
1001-002067	U2003	IC
1009-001074	U4040	IC
1105-003019	UCP500UP	IC
1107-002650	UME6000	IC
1109-001597	U3001	IC
1201-003729	U2101	IC
1201-004114	U1010	IC
1201-004164	U1002	IC
1201-004208	U1004	IC
1201-004211	U3000	IC
1203-008472	U9014	IC
1203-008719	U11000	IC
1203-008811	U7030	IC
1203-008857	U7002	IC
1203-009035	U9024	IC
1203-009080	U4050	IC
1203-009156	U7031	IC
1203-009168	U7084	IC
1203-009176	U7027	IC
1203-009177	U7044	IC
1204-003772	U2001	IC
1205-005217	U10000,U10001	IC

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

1205-005731	U4025	IC
1205-005738	U5007	IC
1205-005745	U8000	IC
1205-006026	U2102	IC
1205-006028	UCP500	IC
1205-006065	U7008	IC
1209-002513	U4004	IC
1209-002567	U4038	IC
1209-002578	U4001	IC
1209-002590	U4000	IC
1209-002647	U4002	IC
1404-001724	TH1000,TH3000,TH5000, TH7001,TH9000	THERMISTOR
1405-001395	V3005,V7006,V7010,V7011, V7013,V7014, V7015	VARISTOR
1405-001403	V3004	VARISTOR
1405-001404	V7003,V7004	VARISTOR
1405-001415	V2002	VARISTOR
1405-001420	V2000,V7001	VARISTOR
1405-001424	V2001	VARISTOR
1405-001425	V2003	VARISTOR
1405-001458	V7000,V7002,V7005,V7007, V7008,V7009, V7012,V7016	VARISTOR
2007-007193	R4007,R4008	R-CHIP
2007-007318	R11009	R-CHIP
2007-007334	R7016	R-CHIP
2007-007741	R10003,R10011,R3040,R3041, R4010,R4017,R7043,R7044,R7065	R-CHIP
2007-008052	R10002	R-CHIP
2007-008263	R5013	R-CHIP
2007-008531	R10001,R10004,R11013,R4023, R7002,R7004,R7005	R-CHIP
2007-008774	R4011,R4020,R4031,R4032	R-CHIP
2007-008798	R11005,R3002	R-CHIP
2007-008809	R7064	R-CHIP
2007-009111	R3000,R3003,R4021	R-CHIP
2007-009154	R4005	R-CHIP
2007-009157	R11030,R11031,R4000,R5054,R5063, R5064, R7006,R7021,R7022,R7904	R-CHIP
2007-009182	R7066	R-CHIP
2007-009201	R8001,R8002,R8003	R-CHIP
2007-009212	R5039,R5040,R6000,R7008,R7033, R7034,R7035,R7037,R7052,R7060, R9204,R9205	R-CHIP
2007-009233	R7017,R7018	R-CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2007-009352	R5053	R-CHIP
2007-009408	R4006	R-CHIP
2007-009805	R1000,R2012	R-CHIP
2007-009866	R10000,R4027,R4028,R4033, R4034,R7014,R7024	R-CHIP
2007-009879	R5009,R5011,R5019,R5020	R-CHIP
2007-009924	R4001,R4003	R-CHIP
2007-009954	R9004	R-CHIP
2007-009969	R4002,R4004	R-CHIP
2007-010202	R7000	R-CHIP
2007-010685	R7048,R7049	R-CHIP
2007-011043	R5037	R-CHIP
2007-011378	R3020,R3021,R3022,R3023	R-CHIP
2007-011532	R2013,R2014	R-CHIP
2007-011542	R9000	R-CHIP
2007-011546	R5031,R5032,R5049, R5050,R5051,R5052	R-CHIP
2007-011548	R5028,R5033	R-CHIP
2007-011591	R5000,R5002,R5004,R5005,R5006, R5010,R5012,R5017,R5018,R5021, R5023,R5024,R5027,R5034,R5035, R5036,R5038,R5041,R5042,R5043, R5044,R5045,R5046,R5047,R5048, R5060,R7010,R7011	R-CHIP
2007-011594	R5001,R5003,R5014, R5026,R5029,R5030	R-CHIP
2007-011615	R5015,R5016	R-CHIP
2007-011648	R2009	R-CHIP
2007-012197	R7009	R-CHIP
2203-000138	C7304,C7305	C-CERAMIC,CHIP
2203-000311	C4010,C4021	C-CERAMIC,CHIP
2203-000438	C7148	C-CERAMIC,CHIP
2203-000489	C7156	C-CERAMIC,CHIP
2203-000679	C7045,C7140	C-CERAMIC,CHIP
2203-000725	C7149	C-CERAMIC,CHIP
2203-001033	C7042	C-CERAMIC,CHIP
2203-001072	C4223,C4224	C-CERAMIC,CHIP
2203-005682	C1005,L1041	C-CERAMIC,CHIP
2203-005719	L2301	C-CERAMIC,CHIP
2203-005726	C1034,C8026	C-CERAMIC,CHIP
2203-005727	C2166	C-CERAMIC,CHIP
2203-005729	C1126,C2168	C-CERAMIC,CHIP
2203-005732	C1040	C-CERAMIC,CHIP
2203-005734	C4015,C9004	C-CERAMIC,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2203-005736	C10003,C10004,C1001,C10014, C10016,C10017,C10018,C10020, C10021,C1012,C1031,C1046,C1074, C1089,C1090,C1143,C2013,C2022, C2023,C2028,C2029,C2059,C2060, C2114,C2138,C2140,C2144,C2162, C2163,C2167,C2182,C2212,C3001, C3011,C3012,C3015,C3018,C3064, C3066,C7027,C7119,L1058,L1119, L2007,L2058,L2060	C-CERAMIC,CHIP
2203-005777	C1021,L1026,L1028	C-CERAMIC,CHIP
2203-005779	C10002,C10015,C10038	C-CERAMIC,CHIP
2203-005789	C1036,C1123,C2009,C3013,L1002, L1010,L1016,L1025,L1031,L1047, L1057,L1072,L2003,L2040,L2054,L3012	C-CERAMIC,CHIP
2203-005792	C1124,C3008,C3016, L2027,L3045	C-CERAMIC,CHIP
2203-005806	C1007,C1044,C1049, C1050,C1125	C-CERAMIC,CHIP
2203-006121	C2000	C-CERAMIC,CHIP
2203-006123	L2105	C-CERAMIC,CHIP
2203-006305	C2119,L2302	C-CERAMIC,CHIP
2203-006318	C1023,C1025,L1032, L1091,L2002,L2017	C-CERAMIC,CHIP
2203-006400	C1092,C2115,C4016,C4018, C7050,C7110,C7133	C-CERAMIC,CHIP
2203-006410	C3025,L1090	C-CERAMIC,CHIP
2203-006556	C7120	C-CERAMIC,CHIP
2203-006611	L1019	C-CERAMIC,CHIP
2203-006665	L1092	C-CERAMIC,CHIP
2203-006707	C2072,L3008	C-CERAMIC,CHIP
2203-006839	C4009,C6039,C7022, C7035,C7054,C7094	C-CERAMIC,CHIP
2203-006844	C4011,C4012,C4027,C4028	C-CERAMIC,CHIP
2203-006979	C2150	C-CERAMIC,CHIP
2203-007194	C11014,C2152	C-CERAMIC,CHIP
2203-007210	C11004,C11005,C4227,C6017	C-CERAMIC,CHIP
2203-007270	C7052,C7068	C-CERAMIC,CHIP
2203-007317	C7153,C8021,C8024,C9016, C9034,C9111,C9206	C-CERAMIC,CHIP
2203-007391	C2136,C2137,C2160,C2161,C4004, C7100,C7101,C7141,C7142,C7145, C8001,C8010,C8016,C8029,C9031	C-CERAMIC,CHIP
2203-007393	C10007,C2010,C2014,C2015,C2016, C2018,C2031,C2032,C3004,C3022, C3024,C3028,C3063,C4005,C4008, C4025,C4034,C4057,C4058,C7001, C7005,C7006,C7010,C7013,C7025, C7070,C7138,C7146,C9029,C9043, C9046	C-CERAMIC,CHIP
2203-007425	C7023	C-CERAMIC,CHIP
2203-007456	C4056	C-CERAMIC,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2203-007474	C10009,C10010,C10019,C7049, C7061,C7062, C7066,C7067,C7092, C7095,C7122,C9039, C9040	C-CERAMIC,CHIP
2203-007486	C4055	C-CERAMIC,CHIP
2203-007544	C7105,C7108,C7111,C7112, C7128,C7155, C7157	C-CERAMIC,CHIP
2203-007621	C1400,C2003,C2004,C2005,C2008, C2073,C2074,C2075,C2079,C2080, C2082,C2083 C2084,C2085,C2088, C2089,C2097,C2098,C2099,C2100, C2101,C2104,C2105,C2106,C2154, C2155,C2156, C2157,C2158,C2200, C2201,C2202,C2203,C2204,C2205, C2206,C2207,C2208,C2209,C2210, C3000,C3002, C3003,C3005,C3029, C3030,C3038,C4002,C4030,C4031, C4037,C4228,C4229,C5000,C5001, C5003,C5004 C6012,C6041,C7014, C7058,C7091,C7115,C8002,C8003, C8005,C8006,C8007,C8011,C8012, C8013,C8014,C8015,C8017,C8018, C8019,C8022,C8025,C8030,C8031, C8033 C9065,C9207,C9208	C-CERAMIC,CHIP
2203-007781	C7069	C-CERAMIC,CHIP
2203-007796	C10005,C10022,C1057,C11003,C3019, C4000,C4013,C4022,C5002,C5005, C6000,C6001 C6002,C6003,C6004, C6005,C6007,C6014,C6021,C6022, C6023,C6024,C6025,C6026,C6027, C6028,C6029,C6032,C6033,C6046, C6047,C6048,C6055,C6056,C6057, C6064,C6066,C6067,C6068,C6069, C6070,C6071,C6072,C6073,C6074, C6075,C6076,C6077,C6078,C6080, C6081,C6082,C6085,C6086,C6087, C6090,C6091,C6092,C6096,C7008, C7018,C7020,C7033,C7034,C7047, C7051,C7053,C7056,C7057,C7059, C7060,C7063,C7071,C7074,C7079, C7087,C7107,C7129,C7151,C7154, C8000,C8009,C8023,C8032,C9041, C9042	C-CERAMIC,CHIP
2203-007809	C7147	C-CERAMIC,CHIP
2203-008097	C7114	C-CERAMIC,CHIP
2203-008158	C7098,C7099,C7106,C7109	C-CERAMIC,CHIP
2203-008242	C10024,C10025,C10030,C10034, C11026,C4001,C4003,C6015,C6016, C6040,C7116,C7127,C9000,C9011, C9012,C9014,C9018,C9019,C9021, C9051,C9052,C9109,C9113	C-CERAMIC,CHIP
2203-008243	C7118,C7137	C-CERAMIC,CHIP
2203-008394	C1069	C-CERAMIC,CHIP
2203-008403	C3090,C3091	C-CERAMIC,CHIP
2203-008466	C10040,C10041,C10042,C10043, C2017,C7090,C7096,C7097	C-CERAMIC,CHIP
2203-008470	C6020,C6058	C-CERAMIC,CHIP
2203-008572	C7009,C7028,C7029,C7030, C7113,C7132	C-CERAMIC,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2203-008844	C9001,C9002,C9003	C-CERAMIC,CHIP
2203-008860	C2173,C7007,C7011,C7012,C7015, C7016,C7021,C7024,C7026,C7036, C7039,C7048,C7077,C7080,C7081, C7082,C7083,C7084,C7086,C7088	C-CERAMIC,CHIP
2203-009025	C2153	C-CERAMIC,CHIP
2203-009064	C6036,C6037	C-CERAMIC,CHIP
2203-009167	C4017,C4020	C-CERAMIC,CHIP
2203-009444	C7104	C-CERAMIC,CHIP
2203-009600	C4026,C4039	C-CERAMIC,CHIP
2203-009618	C2012,C2021,C9005,C9037	C-CERAMIC,CHIP
2203-009733	C10000,C10001,C10008,C10011, C10012,C10013,C1095,C4060,C7002, C7003,C7004,C7032,C7037,C7038, C7040,C7041,C7044,C7064,C7065, C7072,C7073,C7075,C7078,C7085, C7102,C7103,C7126,C7136,C7139, C9044,C9200	C-CERAMIC,CHIP
2203-009735	C6006,C6008,C6011,C6030,C6031, C6034,C6035,C6038,C6042,C6043, C6044,C6045,C6049,C6050,C6051, C6052,C6053,C6054,C6060,C6061, C6083,C6084,C6088,C6089	C-CERAMIC,CHIP
2203-009736	C2002,C2007,C2077,C2081,C2087, C6010,C7130,C7134,C7135,C8020, C9017	C-CERAMIC,CHIP
2203-009858	C7093	C-CERAMIC,CHIP
2203-009987	C9015,C9033,C9035,C9036	C-CERAMIC,CHIP
2203-010127	C10006,C1002,C10023,C10026, C10032,C10039,C1045,C1094,C11001, C11028,C2011,C2020,C4006,C4007, C7019,C7117,C9006,C9008,C9022, C9023,C9024,C9025,C9026,C9028, C9032,C9038,C9048,C9049,C9050, C9088	C-CERAMIC,CHIP
2409-001387	TA7000,TA7001	CAPACITOR
2409-001400	TA7002,TA7003	CAPACITOR
2703-002903	C1129,L1061,L1093, L2033,L2306	INDUCTOR-SMD
2703-002907	C1132,L1097	INDUCTOR-SMD
2703-002955	C3027,L1042,L2076, L2091,L3009,L3033	INDUCTOR-SMD
2703-002958	L1007	INDUCTOR-SMD
2703-002959	L10002,L10005,L10011	INDUCTOR-SMD
2703-003970	L2066	INDUCTOR-SMD
2703-004000	L1038	INDUCTOR-SMD
2703-004001	L2077,L3016,L3021,L3022	INDUCTOR-SMD
2703-004012	C1029,C2145,L1005, L1077,L2061,L2092	INDUCTOR-SMD
2703-004013	C1047,C1059,C1070,C1072,C2141, L1053,L1065,L3007,L3014,L3018	INDUCTOR-SMD
2703-004014	C1030,C2027,C3017,C3059,L1102, L2015,L3002,L3043	INDUCTOR-SMD

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2703-004018	C2303	INDUCTOR-SMD
2703-004032	L2005,L2013	INDUCTOR-SMD
2703-004033	L1034,L1051,L2029, L2062,L3025	INDUCTOR-SMD
2703-004034	C1048,C2146,C3009, L1015,L1110,L1600	INDUCTOR-SMD
2703-004035	L1109	INDUCTOR-SMD
2703-004036	C2302,L1098,L3013	INDUCTOR-SMD
2703-004037	C1098,L1030,L1076, L1103,L3044	INDUCTOR-SMD
2703-004038	C2139,L1100,L1124,L2030	INDUCTOR-SMD
2703-004286	L1000,L1014,L1118,L2063	INDUCTOR-SMD
2703-004289	L2018	INDUCTOR-SMD
2703-004317	C2019,C3007,L2084, L3000,L3001	INDUCTOR-SMD
2703-004328	C1032,L2010,L2022	INDUCTOR-SMD
2703-004363	L2006,L2078	INDUCTOR-SMD
2703-004364	L1003,L1036	INDUCTOR-SMD
2703-004366	C1026,C1101,C3023, L1052,L1054,L2041	INDUCTOR-SMD
2703-004703	L2028	INDUCTOR-SMD
2703-004853	L2042,L7011,L7014, L7018,L7024	INDUCTOR-SMD
2703-004862	L1012,L1013	INDUCTOR-SMD
2703-004947	L9001	INDUCTOR-SMD
2703-005058	C2094,L1035,L2011	INDUCTOR-SMD
2703-005087	C1024,C2172	INDUCTOR-SMD
2703-005200	L3023,L3024	INDUCTOR-SMD
2703-005340	L2009	INDUCTOR-SMD
2703-005438	L3042	INDUCTOR-SMD
2703-005555	L4000,L4001	INDUCTOR-SMD
2703-005581	L7010,L7019	INDUCTOR-SMD
2703-005660	L7000,L7002,L7004,L7005,L7006, L7007,L7008,L7009,L7015,L7020, L7021,L7022,L7023,L7029	INDUCTOR-SMD
2703-005661	L7001,L7003,L7016,L7017,L7028 L9002,L9003,L9005	INDUCTOR-SMD
2703-005705	L2008	INDUCTOR-SMD
2801-005481	OSC7000	CRYSTAL-UNIT
2903-001535	F3003	FILTER-CERAMIC
2903-001576	F3002,F3004,F3005	FILTER-CERAMIC
2904-002161	F1004	FILTER-SAW
2904-002296	F2002	FILTER-SAW
2904-002305	F1005	FILTER-SAW
2904-002356	F2008	FILTER-SAW
2904-002362	F1003,F2001	FILTER-SAW

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2904-002377	F2301	FILTER-SAW
2904-002391	F2009	FILTER-SAW
2904-002393	F3000	FILTER-SAW
2904-002395	F2302	FILTER-SAW
2904-002400	F2006	FILTER-SAW
2910-000406	F1001	FILTER
2910-000410	F1002	FILTER
2911-000454	U2000,U2100	FILTER
2911-000466	U2091	FILTER
3003-001243	MIC8001	MIC-CONDENSOR
3301-001534	L8001,L8002	CORE-FERRITE BEAD
3301-001869	L8003	CORE-FERRITE BEAD
3301-001989	L10013,L10014	CORE-FERRITE BEAD
3301-002223	L10000,L10001,L10003,L10010	CORE-FERRITE BEAD
3301-002235	L2004,L4003,L4004	CORE-FERRITE BEAD
3301-002237	L1006,L1009,L1017,L11001,L11002, L2034, L2037,L8000	CORE-FERRITE BEAD
3301-002243	L2020	CORE-FERRITE BEAD
3301-002244	L2021	CORE-FERRITE BEAD
3301-002279	L10004,L10006,L10007	CORE-FERRITE BEAD
3301-002309	L2056	CORE-FERRITE BEAD
3301-002312	R3006	CORE-FERRITE BEAD
3301-002331	L4002,L7012,L7013	CORE-FERRITE BEAD
3301-002356	L8004,L8005,L8006	CORE-FERRITE BEAD
3705-001937	RFS1000,RFS1001,RFS3001	CONNECTOR-COAXIAL
3711-007173	HDC11000	CONNECTOR-HEADER
3711-008847	BTC7000	CONNECTOR-HEADER
3711-009356	HDC10000	CONNECTOR-HEADER
3711-009359	HDC10002,HDC11001,HDC11002	CONNECTOR-HEADER
3711-009407	HDC10003	CONNECTOR-HEADER
3711-009408	HDC4000	CONNECTOR-HEADER
3712-001633	ANT7003,ANT7004,ANT7005,ANT7006	CONNECTOR
3712-001694	ANT2001,ANT2006,ANT2008,ANT2012, ANT2013,ANT2015,ANT3001,ANT3002, ANT3004,ANT7000,ANT7001,ANT7002, ANT7007,ANT7008,ANT7009,ANT7010, ANT7011,ANT7012,ANT7013,ANT7019	CONNECTOR
3712-001731	ANT3003	CONNECTOR
4709-002285	F3001	RF-MODULE
4709-002529	F1000	RF-MODULE
4709-002709	U3048	RF-MODULE
GH60-00010A	CLIP7001	CLIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

GH62-00042A	CN7000,CN7001,CN7002	Contact
GH63-14237A	SC3005	Shield Can
GH63-15200A	SC3010	Shield Can
GH63-16568A	SC3000	Shield Can
GH63-16810A	SC3001	Shield Can
GH63-16811A	SC3002	Shield Can
GH63-16812A	SC3008	Shield Can
GH63-16813A	SC3003	Shield Can
GH63-16814A	SC3004	Shield Can
GH63-16815A	SC3006	Shield Can
GH63-16816A	SC3007	Shield Can
GH63-16821A	SC3009	Shield Can
GH02-18192A	SC3001SP	TAPE ABSORBER

Please consult the GSPN website (Samsung Portal) for the most recent version of the product's part list.