

5. MAIN Electrical Parts List

Parts code	Desing Loc	Description
R4009,R4027,R9028	0202-002125	-
U12031	0202-002125	-
D8001	0401-001110	Diode
D8000,D9000	0404-001250	Diode
ZD9005	0406-001561	Diode
ZD9003	0406-001709	Diode
ZD8005,ZD8007	0406-001729	Diode
ZD9001,ZD9004	0406-001781	Diode
ZD11011,ZD11018	0406-001787	Diode
ZD9007,ZD9008,ZD9009	0406-001787	Diode
ZD9010	0406-001787	Diode
ZD11009,ZD11010	0406-001804	Diode
ZD11014,ZD11015	0406-001804	Diode
ZD11016,ZD11017	0406-001804	Diode
ZD11021,ZD11022	0406-001804	Diode
ZD8003	0406-001805	Diode
ZD11012,ZD11013	0406-001809	Diode
ZD11007,ZD11020	0406-001826	Diode
LED10000	0601-003707	LED
U8036	0801-003639	IC
U10007	0903-002233	IC
U9036	1001-001755	IC
U1005	1001-001975	IC
U8025	1001-002045	IC
U1002,U1003,U1004	1001-002075	IC
U2000	1001-002075	IC
U11026,U5018	1009-001076	IC
UME4000	1107-002611	IC
U5008	1201-003735	IC
PAM1001	1201-004114	IC
PAM1000	1201-004157	IC
U9015,U9017	1201-004178	IC
U1006	1201-004210	IC
U12008	1202-001120	IC
U10002	1203-008472	IC
U4000	1203-008729	IC
U8008	1203-008802	IC
U5012	1203-008811	IC

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

U12014,U5011,U8035	1203-008867	IC
U12006	1203-009032	IC
U10000	1203-009035	IC
U9048	1203-009080	IC
U8031	1203-009156	IC
U8033	1203-009168	IC
U8015	1203-009187	IC
U12019	1203-009191	IC
U1008	1204-003761	IC
U1001	1204-003773	IC
U12023	1205-005217	IC
U9025	1205-005729	IC
U5025	1205-005871	IC
U5004	1205-005880	IC
U3000	1205-006032	IC
UCP5000	1205-006121	IC
U5024	1209-002513	IC
U5021	1209-002558	IC
U5023	1209-002567	IC
U5020	1209-002578	IC
U11022	1209-002607	IC
U5100	1209-002608	IC
U5101	1209-002619	THERMISTOR
TH11000,TH5000	1404-001724	THERMISTOR
TH6000,TH8000,TH8001	1404-001724	THERMISTOR
TH8002,U4002	1404-001724	THERMISTOR
V1003,V2013,V5011	1405-001395	VARISTOR
V7004,V7009,V7010	1405-001395	VARISTOR
V7011,V7014,V7019	1405-001395	VARISTOR
V7026,V7028	1405-001395	VARISTOR
V11001	1405-001404	VARISTOR
V1002	1405-001412	VARISTOR
U12029,V2000,V2001	1405-001415	VARISTOR
V2015,V3000,V5007	1405-001415	VARISTOR
V11000,V11006,V11008	1405-001420	VARISTOR
V5002,V5012,V7012	1405-001420	VARISTOR
V7023	1405-001420	VARISTOR
V5001	1405-001423	VARISTOR
V11002,V11003,V11004	1405-001428	VARISTOR

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

V11017,V7031	1405-001428	VARISTOR
V11012,V11013,V11014	1405-001445	VARISTOR
V1001	1405-001450	VARISTOR
V11007,V11015,V11016	1405-001458	VARISTOR
R11016,R11018,R11019	2007-001284	R-CHIP
R11021	2007-001284	R-CHIP
R11000	2007-007100	R-CHIP
R5032	2007-007142	R-CHIP
R9015,R9016	2007-007193	R-CHIP
R6001,R6031,R6078	2007-007310	R-CHIP
R5030,R5031	2007-007314	R-CHIP
R10006,R4000,R4001	2007-007741	R-CHIP
R4005,R5101,R8032	2007-007741	R-CHIP
R8033,R8039,R9006	2007-007741	R-CHIP
R9020	2007-007741	R-CHIP
R5105	2007-007798	R-CHIP
R6043	2007-007942	R-CHIP
R6045	2007-007946	R-CHIP
R3000	2007-008043	R-CHIP
R10009,R12004	2007-008052	R-CHIP
R12002,R8042	2007-008211	R-CHIP
R9010	2007-008294	R-CHIP
R10003	2007-008296	R-CHIP
R8041	2007-008403	R-CHIP
R11002	2007-008419	R-CHIP
R10002,R8036	2007-008486	R-CHIP
R8010,R8034,R8035	2007-008531	R-CHIP
R9011	2007-008531	R-CHIP
R11015,R11017,R11020	2007-008774	R-CHIP
R11022,R5102,R5103	2007-008774	R-CHIP
R4025	2007-008785	R-CHIP
R8038	2007-008809	R-CHIP
R5100	2007-009111	R-CHIP
R10005,R11014,R4015	2007-009157	R-CHIP
R4016,R5033,R6062	2007-009157	R-CHIP
R6063,R8015,R8016	2007-009157	R-CHIP
R8017,R8029,R8030	2007-009157	R-CHIP
R9014,R9017	2007-009157	R-CHIP
R5003,R7063	2007-009182	R-CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

R9003,R9004,R9005	2007-009201	R-CHIP
R9025	2007-009201	R-CHIP
R10018,R10019,R4002	2007-009212	R-CHIP
R4003,R4004,R4006	2007-009212	R-CHIP
R4007,R4026,R6023	2007-009212	R-CHIP
R6024,R6060,R6061	2007-009212	R-CHIP
R8040,R9007,R9019	2007-009212	R-CHIP
R8023,R8024	2007-009233	R-CHIP
R12005,R4024	2007-009314	R-CHIP
R11001,R12000,R5029	2007-009408	R-CHIP
R6027,R6028,R9012	2007-009408	R-CHIP
R5013,R5014	2007-009805	R-CHIP
R10007,R11010,R11011	2007-009866	R-CHIP
R11012,R11013,R8001	2007-009866	R-CHIP
R8031	2007-009866	R-CHIP
R10014,R10015,R6036	2007-009879	R-CHIP
R6037	2007-009879	R-CHIP
R11004,R11005	2007-009924	R-CHIP
R9009	2007-009969	R-CHIP
R8009,R8012,R8013	2007-010202	R-CHIP
R8025,R8026	2007-010685	R-CHIP
R6000	2007-011043	R-CHIP
R6051,R6052,R6054	2007-011262	R-CHIP
R6055,R6058,R6064	2007-011262	R-CHIP
R6065,R6066,R6067	2007-011262	R-CHIP
R6068,R6070,R6071	2007-011262	R-CHIP
R6073,R6074,R9026	2007-011262	R-CHIP
R5010,R5011	2007-011378	R-CHIP
R9024	2007-011532	R-CHIP
R10004,R12001,R12003	2007-011542	R-CHIP
R6038,R6039,R6040	2007-011546	R-CHIP
R6041,R6079,R6080	2007-011546	R-CHIP
R6081,R6082	2007-011546	R-CHIP
R3002,R3003,R3005	2007-011548	R-CHIP
R3006,R6044	2007-011548	R-CHIP
R5006,R5007,R5008	2007-011591	R-CHIP
R5009,R6002,R6003	2007-011591	R-CHIP
R6006,R6007,R6008	2007-011591	R-CHIP
R6009,R6012,R6013	2007-011591	R-CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

R6014,R6015,R6021	2007-011591	R-CHIP
R6022,R6025,R6026	2007-011591	R-CHIP
R6029,R6030,R6032	2007-011591	R-CHIP
R6033,R6034,R6035	2007-011591	R-CHIP
R6085,R6086,R8019	2007-011591	R-CHIP
R8020	2007-011591	R-CHIP
R6010,R6011,R6019	2007-011594	R-CHIP
R6020,R6091,R6092	2007-011594	R-CHIP
R6042	2007-011599	R-CHIP
R4012	2007-011648	R-CHIP
R8018	2007-012197	R-CHIP
R12010	2007-012202	R-CHIP
C8188,C8189	2203-000138	C-CERAMIC, CHIP
C5072,C5079	2203-000233	C-CERAMIC, CHIP
C5077	2203-000330	C-CERAMIC, CHIP
C5103,C8185	2203-000438	C-CERAMIC, CHIP
C8150	2203-000489	C-CERAMIC, CHIP
C8127,C8128	2203-000679	C-CERAMIC, CHIP
C8180,C8186	2203-000725	C-CERAMIC, CHIP
C11008,C8190,C8191	2203-000812	C-CERAMIC, CHIP
C8124	2203-001033	C-CERAMIC, CHIP
C11009	2203-002285	C-CERAMIC, CHIP
C5076	2203-005057	C-CERAMIC, CHIP
C10092,C10094,C10095	2203-005682	C-CERAMIC, CHIP
C14431,C2038	2203-005682	C-CERAMIC, CHIP
C1071	2203-005717	C-CERAMIC, CHIP
C9035,C9037,C9041	2203-005726	C-CERAMIC, CHIP
C9077	2203-005726	C-CERAMIC, CHIP
L2025	2203-005729	C-CERAMIC, CHIP
C2030,C2047,C9055	2203-005731	C-CERAMIC, CHIP
C9061,L2022	2203-005731	C-CERAMIC, CHIP
C9048,C9059,C9060	2203-005732	C-CERAMIC, CHIP
C9064,C9066,C9078	2203-005732	C-CERAMIC, CHIP
C10024	2203-005734	C-CERAMIC, CHIP
C1004,C10054,C10055	2203-005736	C-CERAMIC, CHIP
C10064,C10065,C10066	2203-005736	C-CERAMIC, CHIP
C10069,C1007,C10070	2203-005736	C-CERAMIC, CHIP
C10093,C1015,C1017	2203-005736	C-CERAMIC, CHIP
C1021,C1022,C1023	2203-005736	C-CERAMIC, CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

C1024,C1027,C1032	2203-005736	C-CERAMIC, CHIP
C1033,C1036,C1037	2203-005736	C-CERAMIC, CHIP
C1038,C1041,C1044	2203-005736	C-CERAMIC, CHIP
C1045,C1046,C1047	2203-005736	C-CERAMIC, CHIP
C1050,C1054,C1061	2203-005736	C-CERAMIC, CHIP
C1069,C1080,C1082	2203-005736	C-CERAMIC, CHIP
C1085,C11012,C1109	2203-005736	C-CERAMIC, CHIP
C1114,C1115,C1118	2203-005736	C-CERAMIC, CHIP
C1122,C1123,C14432	2203-005736	C-CERAMIC, CHIP
C2013,C2014,C2015	2203-005736	C-CERAMIC, CHIP
C2017,C2020,C2025	2203-005736	C-CERAMIC, CHIP
C2027,C2028,C2029	2203-005736	C-CERAMIC, CHIP
C2036,C2045,C2064	2203-005736	C-CERAMIC, CHIP
C2065,C3027,C3029	2203-005736	C-CERAMIC, CHIP
C4015,C5114,C5119	2203-005736	C-CERAMIC, CHIP
C5200,C5204,C5205	2203-005736	C-CERAMIC, CHIP
C8117,L1005,L1014	2203-005736	C-CERAMIC, CHIP
L1025,L1039,L1041	2203-005736	C-CERAMIC, CHIP
L1049,L1051,L1056	2203-005736	C-CERAMIC, CHIP
L1063,L1100,L2028	2203-005736	C-CERAMIC, CHIP
L2043,L5037	2203-005736	C-CERAMIC, CHIP
C1020,C1031,C1084	2203-005777	C-CERAMIC, CHIP
C2006	2203-005777	C-CERAMIC, CHIP
C10053,C10062,C10086	2203-005779	C-CERAMIC, CHIP
C1019,C1030,C1055	2203-005789	C-CERAMIC, CHIP
C1072,C1086,C1087	2203-005789	C-CERAMIC, CHIP
C1088,C2009,L5065	2203-005789	C-CERAMIC, CHIP
L2008	2203-005792	C-CERAMIC, CHIP
C5067	2203-005806	C-CERAMIC, CHIP
C1094,C9047	2203-006121	C-CERAMIC, CHIP
C2039,L1004	2203-006187	C-CERAMIC, CHIP
L2005	2203-006305	C-CERAMIC, CHIP
C2033,L2037	2203-006318	C-CERAMIC, CHIP
C2091,C3021,C3024	2203-006400	C-CERAMIC, CHIP
C3025,C4181	2203-006400	C-CERAMIC, CHIP
C1006,C2021	2203-006410	C-CERAMIC, CHIP
C1029,C1048,L1030	2203-006556	C-CERAMIC, CHIP
C2035	2203-006665	C-CERAMIC, CHIP
C4424,C6006	2203-006668	C-CERAMIC, CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

C1095	2203-006712	C-CERAMIC, CHIP
C1090,C1091,C1093	2203-006839	C-CERAMIC, CHIP
C1097,C1098,C1100	2203-006839	C-CERAMIC, CHIP
C5057,C8114,C8123	2203-006839	C-CERAMIC, CHIP
C8131,C8137	2203-006839	C-CERAMIC, CHIP
C11001,C11003,C11004	2203-006844	C-CERAMIC, CHIP
C11006,C3026	2203-006844	C-CERAMIC, CHIP
C3012,C3014,U4003	2203-006979	C-CERAMIC, CHIP
C2024	2203-007194	C-CERAMIC, CHIP
C4004,C7012	2203-007210	C-CERAMIC, CHIP
C1096	2203-007271	C-CERAMIC, CHIP
C4000,C4035,C5061	2203-007317	C-CERAMIC, CHIP
C5062,C7055,C7065	2203-007317	C-CERAMIC, CHIP
C7104,C7108,C7121	2203-007317	C-CERAMIC, CHIP
C9033,C9036,C9038	2203-007317	C-CERAMIC, CHIP
C9039,C9040,C9072	2203-007317	C-CERAMIC, CHIP
C9074,C9076	2203-007317	C-CERAMIC, CHIP
C10040,C9006,C9007	2203-007391	C-CERAMIC, CHIP
C9030	2203-007391	C-CERAMIC, CHIP
C1081,C1099	2203-007392	C-CERAMIC, CHIP
C10014,C10017,C10039	2203-007393	C-CERAMIC, CHIP
C10063,C1092,C12008	2203-007393	C-CERAMIC, CHIP
C12009,C5055,C5098	2203-007393	C-CERAMIC, CHIP
C5099,C5201,C8019	2203-007393	C-CERAMIC, CHIP
C8063,C8070,C8091	2203-007393	C-CERAMIC, CHIP
C8135,C8140,C8177	2203-007393	C-CERAMIC, CHIP
C9065,C9068	2203-007393	C-CERAMIC, CHIP
L1028	2203-007403	C-CERAMIC, CHIP
C8115	2203-007425	C-CERAMIC, CHIP
C9070	2203-007456	C-CERAMIC, CHIP
C9067	2203-007486	C-CERAMIC, CHIP
C5074,C8149,C8151	2203-007544	C-CERAMIC, CHIP
C8152,C8154,C8157	2203-007544	C-CERAMIC, CHIP
C8159,C8171	2203-007544	C-CERAMIC, CHIP
C10025,C10073,C10090	2203-007621	C-CERAMIC, CHIP
C11013,C2001,C2023	2203-007621	C-CERAMIC, CHIP
C2037,C3002,C3010	2203-007621	C-CERAMIC, CHIP
C3015,C3020,C3023	2203-007621	C-CERAMIC, CHIP
C4005,C4039,C4041	2203-007621	C-CERAMIC, CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

C5021,C5053,C5056	2203-007621	C-CERAMIC, CHIP
C5059,C5060,C5073	2203-007621	C-CERAMIC, CHIP
C5100,C5101,C6000	2203-007621	C-CERAMIC, CHIP
C6001,C8007,C8017	2203-007621	C-CERAMIC, CHIP
C8043,C8044,C8136	2203-007621	C-CERAMIC, CHIP
C8163,C9018,C9057	2203-007621	C-CERAMIC, CHIP
C9058	2203-007621	C-CERAMIC, CHIP
C5037	2203-007781	C-CERAMIC, CHIP
C10005,C10012,C10013	2203-007796	C-CERAMIC, CHIP
C1018,C1042,C11011	2203-007796	C-CERAMIC, CHIP
C12013,C12020,C12021	2203-007796	C-CERAMIC, CHIP
C12039,C3005,C3008	2203-007796	C-CERAMIC, CHIP
C3009,C3011,C3013	2203-007796	C-CERAMIC, CHIP
C3016,C3017,C3028	2203-007796	C-CERAMIC, CHIP
C3030,C4001,C5000	2203-007796	C-CERAMIC, CHIP
C5001,C5002,C5003	2203-007796	C-CERAMIC, CHIP
C5004,C5040,C5041	2203-007796	C-CERAMIC, CHIP
C5054,C5063,C5068	2203-007796	C-CERAMIC, CHIP
C5069,C5094,C7000	2203-007796	C-CERAMIC, CHIP
C7001,C7010,C7011	2203-007796	C-CERAMIC, CHIP
C7014,C7015,C7024	2203-007796	C-CERAMIC, CHIP
C7027,C7028,C7030	2203-007796	C-CERAMIC, CHIP
C7031,C7032,C7034	2203-007796	C-CERAMIC, CHIP
C7035,C7036,C7045	2203-007796	C-CERAMIC, CHIP
C7047,C7050,C7052	2203-007796	C-CERAMIC, CHIP
C7053,C7056,C7057	2203-007796	C-CERAMIC, CHIP
C7058,C7059,C7060	2203-007796	C-CERAMIC, CHIP
C7061,C7062,C7064	2203-007796	C-CERAMIC, CHIP
C7066,C7067,C7068	2203-007796	C-CERAMIC, CHIP
C7069,C7070,C7071	2203-007796	C-CERAMIC, CHIP
C7072,C7073,C7074	2203-007796	C-CERAMIC, CHIP
C7075,C7076,C7077	2203-007796	C-CERAMIC, CHIP
C7078,C7079,C7080	2203-007796	C-CERAMIC, CHIP
C7081,C7084,C7086	2203-007796	C-CERAMIC, CHIP
C7088,C7089,C7090	2203-007796	C-CERAMIC, CHIP
C7092,C7093,C7095	2203-007796	C-CERAMIC, CHIP
C7096,C7097,C7106	2203-007796	C-CERAMIC, CHIP
C7111,C7112,C7113	2203-007796	C-CERAMIC, CHIP
C7115,C7116,C7117	2203-007796	C-CERAMIC, CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

C7119,C8059,C8060	2203-007796	C-CERAMIC, CHIP
C8065,C8066,C8068	2203-007796	C-CERAMIC, CHIP
C8072,C8073,C8077	2203-007796	C-CERAMIC, CHIP
C8092,C8112,C8139	2203-007796	C-CERAMIC, CHIP
C8141,C8143,C8153	2203-007796	C-CERAMIC, CHIP
C8169,C8170,C8183	2203-007796	C-CERAMIC, CHIP
C9008,C9012,C9021	2203-007796	C-CERAMIC, CHIP
C9023,C9024,C9026	2203-007796	C-CERAMIC, CHIP
C9032,C9056,C9073	2203-007796	C-CERAMIC, CHIP
C8187	2203-007809	C-CERAMIC, CHIP
C8104	2203-008095	C-CERAMIC, CHIP
C8005,C8018,C8161	2203-008097	C-CERAMIC, CHIP
C9001,C9004,C9009	2203-008097	C-CERAMIC, CHIP
C9013,C9029,C9031	2203-008097	C-CERAMIC, CHIP
C8146,C8148,C8155	2203-008158	C-CERAMIC, CHIP
C8156	2203-008158	C-CERAMIC, CHIP
C8025	2203-008177	C-CERAMIC, CHIP
C10004,C10021,C10022	2203-008242	C-CERAMIC, CHIP
C10028,C10029,C10030	2203-008242	C-CERAMIC, CHIP
C10031,C10078,C10087	2203-008242	C-CERAMIC, CHIP
C10097,C12019,C12023	2203-008242	C-CERAMIC, CHIP
C12027,C4006,C5009	2203-008242	C-CERAMIC, CHIP
C5010,C5012,C7087	2203-008242	C-CERAMIC, CHIP
C7105,C8010,C8011	2203-008242	C-CERAMIC, CHIP
C8028,C8029,C8030	2203-008242	C-CERAMIC, CHIP
C8031,C8055,C8056	2203-008242	C-CERAMIC, CHIP
C8057,C8061,C8062	2203-008242	C-CERAMIC, CHIP
C8064,C8071,C8074	2203-008242	C-CERAMIC, CHIP
C8090,C8162,C9014	2203-008242	C-CERAMIC, CHIP
C8103	2203-008243	C-CERAMIC, CHIP
C1064	2203-008394	C-CERAMIC, CHIP
C1051,C4036	2203-008400	C-CERAMIC, CHIP
C1028,C4017,C4019	2203-008466	C-CERAMIC, CHIP
C4020,C4021,C5011	2203-008466	C-CERAMIC, CHIP
C5036,C5206,C5207	2203-008466	C-CERAMIC, CHIP
C9016,C9050,L2018	2203-008466	C-CERAMIC, CHIP
C1016,C5096,C5097	2203-008529	C-CERAMIC, CHIP
C1078,C2000,C2063	2203-008563	C-CERAMIC, CHIP
C4013,C4014,C4016	2203-008563	C-CERAMIC, CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

C4018,C5038,C5071	2203-008563	C-CERAMIC, CHIP
C5080,C6003,C6004	2203-008563	C-CERAMIC, CHIP
C8132,C8133,C8158	2203-008563	C-CERAMIC, CHIP
C8118,C8144,C8145	2203-008572	C-CERAMIC, CHIP
C8160,C8178	2203-008572	C-CERAMIC, CHIP
C6002	2203-008653	C-CERAMIC, CHIP
C4010,C5039,C5095	2203-008689	C-CERAMIC, CHIP
C5203	2203-008689	C-CERAMIC, CHIP
C10006,C10007,C10008	2203-008844	C-CERAMIC, CHIP
C10023	2203-008844	C-CERAMIC, CHIP
C1110,C1111,C12010	2203-008860	C-CERAMIC, CHIP
C12028,C12038,C12041	2203-008860	C-CERAMIC, CHIP
C12045,C3001,C8134	2203-008860	C-CERAMIC, CHIP
C8176,C8179	2203-008860	C-CERAMIC, CHIP
C10003,C10018,C10019	2203-008876	C-CERAMIC, CHIP
C10020,C10034,C10036	2203-008876	C-CERAMIC, CHIP
C10037,C10038,C10041	2203-008876	C-CERAMIC, CHIP
C10056,C10071,C10079	2203-008876	C-CERAMIC, CHIP
C10083,C10091,C10098	2203-008876	C-CERAMIC, CHIP
C10103,C1079,C12017	2203-008876	C-CERAMIC, CHIP
C12022,C12026,C12029	2203-008876	C-CERAMIC, CHIP
C12046,C4011,C8004	2203-008876	C-CERAMIC, CHIP
C8006,C8008,C8009	2203-008876	C-CERAMIC, CHIP
C8012,C8013,C8014	2203-008876	C-CERAMIC, CHIP
C8016,C8020,C8021	2203-008876	C-CERAMIC, CHIP
C8032,C8037,C8038	2203-008876	C-CERAMIC, CHIP
C8041,C8042,C8045	2203-008876	C-CERAMIC, CHIP
C8047,C8050,C8052	2203-008876	C-CERAMIC, CHIP
C8053,C8067,C8089	2203-008876	C-CERAMIC, CHIP
C8100,C8113,C8164	2203-008876	C-CERAMIC, CHIP
C9027,C9044,C9045	2203-008876	C-CERAMIC, CHIP
C11000,C11002,C11005	2203-008886	C-CERAMIC, CHIP
C11007	2203-008886	C-CERAMIC, CHIP
C7002,C7003,C7005	2203-009064	C-CERAMIC, CHIP
C7007,C7008,C7018	2203-009064	C-CERAMIC, CHIP
C7019,C7020,C7022	2203-009064	C-CERAMIC, CHIP
C7051,C7114	2203-009064	C-CERAMIC, CHIP
C5075,C5078	2203-009167	C-CERAMIC, CHIP
C8106,C9071	2203-009444	C-CERAMIC, CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

C12014,C12015,C7048	2203-009537	C-CERAMIC, CHIP
C12043	2203-009551	C-CERAMIC, CHIP
C12001,C12002,C12003	2203-009618	C-CERAMIC, CHIP
C12004,C12005	2203-009618	C-CERAMIC, CHIP
C10010,C10011,C10016	2203-009733	C-CERAMIC, CHIP
C10042,C10061,C10100	2203-009733	C-CERAMIC, CHIP
C1101,C1116,C12006	2203-009733	C-CERAMIC, CHIP
C4002,C4012,C5058	2203-009733	C-CERAMIC, CHIP
C8022,C8069,C8088	2203-009733	C-CERAMIC, CHIP
C9011,C9043	2203-009733	C-CERAMIC, CHIP
C7098,C7102	2203-009735	C-CERAMIC, CHIP
C10026,C10046,C10047	2203-009736	C-CERAMIC, CHIP
C10051,C10052,C10057	2203-009736	C-CERAMIC, CHIP
C10058,C10059,C10060	2203-009736	C-CERAMIC, CHIP
C10067,C10068,C10072	2203-009736	C-CERAMIC, CHIP
C10074,C10075,C10076	2203-009736	C-CERAMIC, CHIP
C10077,C10080,C10096	2203-009736	C-CERAMIC, CHIP
C10101,C10102,C3019	2203-009736	C-CERAMIC, CHIP
C3022,C9019	2203-009736	C-CERAMIC, CHIP
C8119	2203-009812	C-CERAMIC, CHIP
C8105	2203-009848	C-CERAMIC, CHIP
C12007,C5065,C5066	2203-009858	C-CERAMIC, CHIP
C5070,C8000,C8001	2203-009858	C-CERAMIC, CHIP
C8002,C8003,C8125	2203-009858	C-CERAMIC, CHIP
C8126,C8129,C8138	2203-009858	C-CERAMIC, CHIP
C10001,C10009,C12000	2203-009859	C-CERAMIC, CHIP
C12011,C12012	2203-009859	C-CERAMIC, CHIP
C9000,C9002,C9003	2203-009969	C-CERAMIC, CHIP
C9042	2203-009969	C-CERAMIC, CHIP
C10027,C10043,C10044	2203-009987	C-CERAMIC, CHIP
C10045,C4008,C4009	2203-009987	C-CERAMIC, CHIP
C8085,C8086,C8087	2203-009987	C-CERAMIC, CHIP
C8040,C8081,C8082	2203-010085	C-CERAMIC, CHIP
C8083,C8084,C8172	2203-010085	C-CERAMIC, CHIP
C10002,C10099,C8051	2203-010127	C-CERAMIC, CHIP
TA8006,TA8007	2409-001387	TANTAL
TA8000,TA8001,TA8002	2409-001400	TANTAL
TA8003,TA8004,TA8005	2409-001400	TANTAL
L1017,L2017,L2035	2703-002907	INDUCTOR

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

L2049	2703-002907	INDUCTOR
C1113,C2005,L1001	2703-002958	INDUCTOR
L1006,L1021,L1022	2703-002958	INDUCTOR
L1050,L2002,L2019	2703-002958	INDUCTOR
L10006,L10007,L10013	2703-002959	INDUCTOR
L1011	2703-002961	INDUCTOR
C2012	2703-002999	INDUCTOR
C1062,C2008,C5112	2703-004012	INDUCTOR
L2032,L5054,L5078	2703-004012	INDUCTOR
C1039,C1067,C1068	2703-004013	INDUCTOR
C2044,L1053,L2026	2703-004013	INDUCTOR
L2029	2703-004013	INDUCTOR
L5053,L5067	2703-004014	INDUCTOR
C1014,L1013	2703-004018	INDUCTOR
L1029,L1058,L1061	2703-004033	INDUCTOR
L2023	2703-004033	INDUCTOR
C1005,C1065,C1119	2703-004034	INDUCTOR
C2022,C5111,L2012	2703-004034	INDUCTOR
L2047,L4009,L5074	2703-004034	INDUCTOR
L1032	2703-004035	INDUCTOR
L2020,L5025	2703-004036	INDUCTOR
C1034,C1049,C1053	2703-004038	INDUCTOR
C2043,L1008,L1024	2703-004038	INDUCTOR
L1026,L1031,L1055	2703-004038	INDUCTOR
L1082,L2006	2703-004038	INDUCTOR
L1062,L2038	2703-004287	INDUCTOR
L5048,L5055	2703-004366	INDUCTOR
L1015	2703-004369	INDUCTOR
L8028,L8029	2703-004841	INDUCTOR
L1003,L1070,L11008	2703-004853	INDUCTOR
C1060,L1083,L4001	2703-005058	INDUCTOR
L10001,L10002,L10003	2703-005067	INDUCTOR
L12002,L5035	2703-005067	INDUCTOR
C1026,C5116,L1037	2703-005085	INDUCTOR
L1046,L1054,L1059	2703-005085	INDUCTOR
L1060,L12012,L2024	2703-005085	INDUCTOR
L2066	2703-005085	INDUCTOR
L1033,L1042,L5080	2703-005086	INDUCTOR
L5036	2703-005087	INDUCTOR

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

L1010,L1019,L1064	2703-005088	INDUCTOR
L2009	2703-005088	INDUCTOR
L2027	2703-005089	INDUCTOR
L5046,L5047	2703-005200	INDUCTOR
L8001,L8003,L8004	2703-005201	INDUCTOR
L8005,L8008,L8009	2703-005201	INDUCTOR
L8010,L8011,L8017	2703-005201	INDUCTOR
L8023,L8026	2703-005201	INDUCTOR
L12000	2703-005224	INDUCTOR
L10000,L4000,L8027	2703-005225	INDUCTOR
L8024,L8025,L9000	2703-005233	INDUCTOR
L9001,L9005,L9011	2703-005233	INDUCTOR
L2046	2703-005296	INDUCTOR
L12001	2703-005418	INDUCTOR
L1066	2703-005430	INDUCTOR
L1069,L9002,L9003	2703-005505	INDUCTOR
L8000,L8006,L8007	2703-005509	INDUCTOR
L8012,L8013,L8014	2703-005509	INDUCTOR
L8015,L8016,L8018	2703-005509	INDUCTOR
L5043,L5044	2703-005555	INDUCTOR
L1007,L1027,L2033	2703-005614	INDUCTOR
L12004,L12005	2703-005663	INDUCTOR
OSC8000	2801-005393	CRYSTAL OSCILLATOR
OSC5000	2805-001118	CRYSTAL OSCILLATOR
TCX3000	2805-001128	CRYSTAL OSCILLATOR
C7004,C7006,C7017	2901-001690	FILTER
C7021,C7037,C7038	2901-001690	FILTER
C7039,C7040,C7049	2901-001690	FILTER
C7054,C7063,C7094	2901-001690	FILTER
C7099,C7100,C7101	2901-001690	FILTER
C7103,C7107	2901-001690	FILTER
F2002	2904-002270	FILTER
F1002	2904-002296	FILTER
U5014	2904-002356	FILTER
U1007,U2001	2904-002362	FILTER
F2000	2904-002378	FILTER
F2001	2904-002382	FILTER
F5001,F5003	2904-002401	FILTER
F1001	2904-002403	FILTER

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

FEM2000	2911-000453	IC
FEM2001,FEM2002	2911-000455	IC
MIC9000,MIC9001	3003-001243	MIC
L9006	3301-001885	BEAD
L12010	3301-001989	BEAD
L10004,L10005,L10011	3301-002223	BEAD
L10012,L10016	3301-002223	BEAD
L9004	3301-002228	BEAD
L11009,L11010,L5041	3301-002235	BEAD
L5042	3301-002235	BEAD
L1009,L1016,L1018	3301-002237	BEAD
L1034,L2000,L2001	3301-002237	BEAD
L2004,L2007,L2011	3301-002237	BEAD
L2014,L5032,L5033	3301-002237	BEAD
L9010	3301-002237	BEAD
L1071,L12009,L5102	3301-002238	BEAD
L12003,L5153	3301-002239	BEAD
L1012	3301-002243	BEAD
L1067	3301-002244	BEAD
L10008,L10009,L10017	3301-002279	BEAD
L1065,L12006,L12007	3301-002312	BEAD
L12008,L4006,L5045	3301-002312	BEAD
L5100,L5101	3301-002312	BEAD
L8020,L8021,L9009	3301-002331	BEAD
L9007,L9008	3301-002375	BEAD
RFS1000,RFS1001	3705-001708	CONNECTOR
CN4000	3709-001892	CONNECTOR
HDC8000	3711-008847	CONNECTOR
HEA8001	3711-008997	CONNECTOR
HEA10001,HEA12000	3711-009359	CONNECTOR
HEA10000,HEA10002	3711-009407	CONNECTOR
ANT1005,ANT1006	3712-001604	C_CLIP
ANT1010,ANT1014	3712-001604	C_CLIP
ANT11000,ANT11002	3712-001604	C_CLIP
ANT11003,ANT11006	3712-001604	C_CLIP
ANT11007,ANT11008	3712-001604	C_CLIP
ANT2010	3712-001604	C_CLIP
ANT11004,ANT11009	3712-001633	C_CLIP
ANT8007,ANT8008	3712-001633	C_CLIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

ANT4000,ANT4001	3712-001634	C_CLIP
ANT4002,ANT4003	3712-001634	C_CLIP
ANT4004,ANT4005	3712-001634	C_CLIP
ANT1001,ANT1002	3712-001666	C_CLIP
ANT1004,ANT2000	3712-001666	C_CLIP
ANT2001,ANT2002	3712-001666	C_CLIP
ANT2006,ANT2008	3712-001666	C_CLIP
ANT5000,ANT5003	3712-001666	C_CLIP
ANT5005,ANT9002	3712-001666	C_CLIP
ANT9003,U5027,U5028	3712-001666	C_CLIP
ANT8000,ANT8001	3712-001714	C_CLIP
ANT8002,ANT8003	3712-001714	C_CLIP
ANT8004,ANT8005	3712-001714	C_CLIP
ANT8006,ANT9000	3712-001714	C_CLIP
ANT9001	3712-001714	C_CLIP
ANT1003,ANT5001	3712-001731	C_CLIP
ANT5007	3712-001731	C_CLIP
IFC11000	3722-004150	CONNECTOR
F1000,F2005	4709-002196	RF MODULE
F5002,F5004	4709-002285	RF MODULE
U5007	4709-002708	RF MODULE
SUS3002,SUS3003	GH61-13928A	SUS
SUS3001	GH61-13929A	SUS
SUS3005	GH61-13930A	SUS
GA11000,GA11001	GH62-00042A	-
GA11002	GH62-00042A	-
SC3011	GH63-16566A	Shield Can
SC3002	GH63-16568A	Shield Can
SC3001	GH63-16569A	Shield Can
SC3008	GH63-16570A	Shield Can
SC3003	GH63-16571A	Shield Can
SC3006	GH63-16588A	Shield Can
SC3004	GH63-16624A	Shield Can
SC3007	GH63-16642A	Shield Can
SC3005	GH98-43745A	Shield Can
SC3006SP	GH02-17467A	TAPE
U5101SP	GH02-18195A	TAPE

Please consult the GSPN website (Samsung Portal) for the most recent version of the product's part list.

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.