

## Section 13      OTHER FUNCTIONS

---

Adjusting the main dial friction.....	13-2
Using the SPEECH function .....	13-2
Measuring SWR .....	13-2
◇ Spot measurement .....	13-2
◇ Plot measurement.....	13-3
Selecting the display type and font.....	13-3
◇ Selecting the display background .....	13-3
◇ Selecting the display font.....	13-3
Protection function.....	13-4
REF adjustment.....	13-4
Displaying my call sign .....	13-5
Screen Capture function.....	13-5
◇ Capturing a screen .....	13-5
◇ Viewing the captured screen.....	13-5