

Section 11

ANTENNA TUNER OPERATION

About the internal antenna tuner11-2

Internal antenna tuner operation11-2

◇ Manual tuning11-2

◇ PTT Tuner start.....11-2

About the external antenna tuner11-3

◇ Using the AH-4 or AH-74011-3

◇ Using a user supplied antenna tuner11-3

Emergency mode (Tuner).....11-4