

## 13 OTHER FUNCTIONS

### Measuring SWR (Continue)

#### ◇ Plot measurement

You can measure the SWR over the entire set frequency range.


1. Set the desired frequency band.
2. Select the RTTY or RTTY-R mode.
3. If necessary, adjust the RF power to approximately 30 W in the Multi-function menu.
  - 70 MHz: 20 W  
(70 MHz band transmission may be possible, depending on the transceiver version.)

**NOTE:** Before transmitting, monitor the operating frequency to make sure you will not cause interference to other stations on the same frequency.

4. Open the SWR GRAPH screen.

**MENU** » **SWR**

5. Set the center frequency for the SWR to be measured. (Example: 14.080.00)
6. If necessary, touch [STEP] several times until the measuring step is selected, or touch [BAR] several times until the number of graph bars is selected.




① You can select between 10, 50, 100, and 500 kHz measuring steps.


① You can select between 3, 5, 7, 9, 11 and 13 graph bars.

7. Touch **▶** to start measuring.

• The frequency marker “▲” and the measurement frequency are displayed.



8. Push **TRANSMIT** or hold down [PTT] on the microphone to transmit.
  - The bar graph displays the SWR.



The best match is within this range.  
(1.5 or less)

9. Push **TRANSMIT** or release [PTT] to stop transmitting.
10. Repeat steps 8 and 9 to measure the SWR over the entire frequency range.

### Selecting the display type and font

You can select between 2 display backgrounds and 2 frequency readout fonts.

#### ◇ Selecting the display background

1. Select the “Display Type” screen.
 

**MENU** » **SET > Display > Display Type**
2. Select the desired background between A and B by rotating and then pushing **MULTI**.
  - A: Black background (default)
  - B: Blue background
3. To close the DISPLAY screen, push **EXIT** several times.

#### ◇ Selecting the display font

1. Select the “Display Font” screen.
 

**MENU** » **SET > Display > Display Font**
2. Set the desired display font to “Basic” or “Round” by rotating, and then pushing **MULTI**.
  - Basic (Default):

**14.100.00** VFO A 1

• Round:

**14.100.00** VFO A 1

3. To close the DISPLAY screen, push **EXIT** several times.