

When first applying power .....	3-2
Turning power ON or OFF .....	3-2
Adjusting the volume level.....	3-2
About the VFO and Memory modes .....	3-2
Using the VFO mode .....	3-2
◇ Selecting VFO A or VFO B.....	3-2
◇ Equalizing VFO A and VFO B .....	3-2
Selecting the operating band.....	3-3
◇ Using the band stacking registers.....	3-3
Selecting the operating mode.....	3-3
Setting the frequency.....	3-4
◇ Using the Main Dial.....	3-4
◇ About the Tuning Step function.....	3-4
◇ Changing the Tuning Step .....	3-4
◇ About the 1 Hz step Fine Tuning function .....	3-4
◇ About the 1/4 Tuning function .....	3-5
◇ About the Auto Tuning Step function .....	3-5
◇ Directly entering a frequency .....	3-5
◇ Band Edge Beep.....	3-6
◇ Entering a Band Edge.....	3-7
RF gain and SQL level .....	3-10
Dial Lock function .....	3-10
Basic transmission.....	3-10
Adjusting the transmit output power .....	3-10
◇ Adjusting the transmit output power .....	3-10
Meter display .....	3-11
◇ Meter display selection .....	3-11
◇ Multi-function meter .....	3-11
Adjusting the microphone gain .....	3-11
About the 5 MHz frequency band operation (USA version only).....	3-12