

Remote control (CI-V) information


◆ CI-V connection

The transceiver's operating frequency, mode, VFO and memory selection, can be remotely controlled using a PC.

Choose your connection method from the following:

- A USB cable (A-B type, user supplied)
The required USB driver and driver installation guide can be downloaded from the Icom web site.
Go to "<http://www.icom.co.jp/world>," and then click "Support," "Firmware Updates / Software downloads" in sequence.
①The download procedure on the web page may be changed without notice.
- The optional CT-17 CI-V LEVEL CONVERTER.
Connects to a PC with an RS-232C port.

• Connection example (using CT-17)




◆ Preparing

The Icom Communications Interface V (CI-V) is used for remote control.
To control the transceiver, first set its address, data communication speed, and transceive function. These settings are set in Set mode.

◆ Data format


The CI-V system can be written using the following data formats. Data formats differ according to command numbers. A data area or sub command is added for some commands.

Controller to IC-7300



IC-7300 to controller

OK message to controller



NG message to controller