

## Section 4      RECEIVING AND TRANSMITTING

---

Convenient for receiving.....	4-2	Operating RTTY (FSK).....	4-22
◇ All operating modes .....	4-2	◇ About the RTTY reverse mode .....	4-22
◇ SSB, CW, RTTY, and AM modes .....	4-2	◇ Twin Peak Filter .....	4-22
◇ SSB, AM and FM modes .....	4-2	◇ Functions on the RTTY DECODE screen.....	4-23
◇ SSB-D, CW and RTTY modes.....	4-2	◇ Setting the decoder threshold level .....	4-23
◇ CW mode.....	4-2	◇ Transmitting an RTTY memory content .....	4-24
Convenient for transmitting.....	4-2	◇ Editing an RTTY memory.....	4-25
◇ SSB, AM and FM modes .....	4-2	◇ Turning ON the RTTY log .....	4-26
◇ SSB mode.....	4-2	◇ Viewing the RTTY log contents.....	4-26
◇ CW mode.....	4-2	◇ About the RTTY decode log set mode .....	4-27
Preamplifiers.....	4-3	◇ About the RTTY decode set mode.....	4-28
Attenuator .....	4-3	FM repeater operation .....	4-29
RIT function .....	4-3	◇ Setting the repeater tone frequency .....	4-29
◇ RIT monitor function.....	4-3	◇ Checking the repeater input signal .....	4-30
AGC function control .....	4-4	Tone squelch operation .....	4-30
◇ Selecting the AGC time constant		Data mode (AFSK) operation .....	4-31
preset value .....	4-4		
◇ Setting the AGC time constant.....	4-4		
Using the Twin PBT .....	4-5		
Selecting the IF filter.....	4-6		
Selecting the IF filter shape.....	4-6		
IP Plus function.....	4-7		
Noise Blanker .....	4-8		
◇ Adjusting the NB level and time .....	4-8		
Noise Reduction .....	4-9		
◇ Adjusting the Noise Reduction level .....	4-9		
Notch Filter .....	4-9		
◇ Auto Notch function .....	4-9		
◇ Manual Notch function .....	4-9		
VOX function .....	4-10		
◇ Adjusting the VOX function .....	4-10		
◇ Turning ON the VOX function .....	4-10		
ΔTX function.....	4-11		
◇ ΔTX monitor function .....	4-11		
Monitor function .....	4-11		
Setting the Speech Compressor.....	4-12		
Split frequency operation.....	4-13		
◇ Using the Quick Split function.....	4-13		
◇ Using the receive and transmit frequencies			
set to VFO A and VFO B.....	4-13		
Split Lock function .....	4-14		
Setting the transmit filter width .....	4-14		
Operating CW.....	4-14		
◇ Setting the CW pitch control .....	4-14		
◇ Setting the key speed .....	4-15		
◇ About the Break-in function .....	4-15		
◇ CW Auto Tuning function .....	4-16		
◇ About the CW Reverse mode .....	4-16		
◇ Electronic Keyer function .....	4-17		
◇ Monitoring the CW side tone .....	4-17		
◇ Sending from the Memory keyer (KEYER) ...	4-18		
◇ Keyer memory edit menu (EDIT) .....	4-19		
◇ Contest number menu (001 SET).....	4-20		
◇ Keyer set menu (CW-KEY SET).....	4-21		