



JP1 – Flash ROM A18 Select  
Open: A18=0 (default);  
Closed: A18=1

JP5, JP6: 1-2: NTSC; 2-3: PAL  
(Use wire links instead of jumpers)

[Chip Select]

[Slot Direction]