

Brief Introduction to the music files

1. "0001_start.mp3" is the starting music;
2. "0002_dance1.mp3" is the music of the first dance of Penguin Bot;
3. "0003_dance2.mp3" is the music of the second dance of Penguin Bot;
4. "0004_dance3.mp3" is the music of the third dance of Penguin Bot;
5. "0005_g.mp3" is the notification music when switch Penguin Bot into Volume Control Mode;
6. "0006_f.mp3" is the music when you switch Penguin Bot into Auto Follow Mode;
7. "0007_o.mp3" is the music when you switch Penguin Bot into Obstacle Avoidance Mode.

You can also change above music as you like, for example the starting music. Simply rename your music as "0001_start.mp3" and then copy it into the TF card.

One thing you need to pay attention to is that Penguin Bot has a *default duration time* for the starting movement and the 3 dancing moves, so it would work out better if the new music you choose has the same time duration.