

addFC – additional tools for FreeCAD

Golodnikov Sergey

27.12.2024

1 Goals and objectives

- Generate a BOM based on the model.
- Batch processing of sheet metal parts.
- Assistance in creating design documentation.
- Library of elements and nodes.
- Process automation.

The main purpose of the workbench is to simplify the work with large and «complex» assemblies, especially with assemblies containing sheet metal parts. «Complex» I mean parametric models (assemblies) with a large number of objects and nodes in the form of links (App::Link). The main point is to reuse components.




Figure 1: Example of a «complex» assembly

The logic of work is based on adding custom properties to objects, giving them certain semantic meanings.

2 Toolbar

When you select the **addFC workbench**, its toolbar will become available, it looks like this:



Figure 2: Toolbar

Tools in order:

1. Open last working file – **Recent File** (Alt+Shift+R).
2. Isometry and fit all – **Display** (Alt+Shift+D).
3. Managing a parametric model – **Model Control** (Alt+Shift+C).
4. Bill of Materials (BOM) – **Specification** (Alt+Shift+S).
5. Filling an object with properties – **Add Properties** (Alt+Shift+A).
6. Create a drawing based on a template – **Creating a Drawing** (Alt+Shift+I).
7. Library of elements and nodes – **Library** (Alt+Shift+L).
8. Exploded view – **Explode** (Alt+Shift+E).
9. Creating a pipeline using coordinates – **Pipe** (Alt+Shift+P).
10. Help – **Help and Examples**.

Note: FreeCAD allows you to create additional toolbars, I recommend taking advantage of this and creating your own toolbar from the most popular functions to display it on your main workbench, for example in PartDesign.

3 Help and examples

The workbench includes samples that you can study to better understand the principles of its operation, to open one of them, use the [Help and Examples](#) command on the toolbar. The most suitable example is **Assembly**, which will be discussed in this guide.




Figure 3: Help and examples

- **Additional files** – supporting files such as templates, fonts.
- **Documentation** – documentation for using the workbench (this file).
- **Assembly** и **Belt Roller Support** – examples of assemblies and working with user properties.
Assembly – parametric assembly.
- **Pipe** – example of using the tool [Pipe](#).
- **RU std: ЕСКД** – example of design according to USDD standards.
Unified System for Design Documentation – Russia.

4 Preferences

PropertiesMaterialsSheet metalOther

Name of the property group: «Add» 1RemoveAdd

	Title	Type	Addition	Alias
1	Name	String	False	
2	Code	String	False	
3	Index	String	False	
4	Material	Enumeration	False	
5	MetalThickness	Float	False	
6	Node	String	False	
7	Price	Float	True	
8	Quantity	Float	True	
9	Unfold	Bool	False	
10	Unit	Enumeration	False	
11	Weight	Float	True	
12	Format	Enumeration	False	
13	Id	String	False	
14	Note	String	False	
15	Type	Enumeration	False	
16	Section	Enumeration	False	

2

Available types: Bool, Enumeration, Float, Integer, String

Values of enumerated properties

Property	Values
1 Material	... use the materials tab
2 Unit	-, m, kg, m^2, m^3
3 Format	-, A0, A1, A2, A3, A4
4 Type	-, Part, Sheet metal part, Fastener, Material
5 Section	-, Документация, Комплексы, Сборочные единицы, Детали, Стандартные изделия, Прочие изделия, ...

3

Figure 4: Specification (BOM) preferences

4.1 Area 1 – Name for grouping properties

The properties that we add to objects will be combined into a special group called «Add». This will facilitate visual perception and will not allow our properties to be mixed with standard ones.

4.2 Area 2 – User properties

This table contains all the properties available for use.

- **Title** – property name (important: Latin characters only).
- **Type** – property value type available for use:
 - **Bool** – boolean data type (true или false).
 - **Enumeration** – a list of predefined values.
 - **Float**.
 - **Integer**.
 - **String**.
- **Addition** – indicates the need to sum all property values (example: total assembly mass).
- **Alias** – a property alias, a value that will replace **Title** when displaying or exporting a specification (allows you to eliminate the restriction on Latin characters).

The **Remove** and **Add** buttons, respectively, allow you to delete a property selected in the table or add a row to create a new one.

4.3 Area 3 – Lists of predefined values

All properties with the **Enumeration** data type appear in this area.

In the **Values** column – comma-separated values to form a list.

4.4 Object properties

Inactive properties and values in the table are basic and required for the workbench to work correctly.

Properties should give meaning to FreeCAD objects.

- **Name** – the name of the object is the most important property, the program works with elements only if they have a name. The name should reflect the essence of the object.
- **Code** – element designation.
- **Index** – an identifier for determining the position of an object in an assembly.
- **Material** – the material of the object (enumeration). This is an important property for sheet metal, when creating a flat part view (unfold) for galvanized and stainless steel, different coefficients are used, and this property is also taken into account when saving the scan to an external file. Additionally, you can link density and cost to this property to automatically calculate the mass and cost of the object.
- **MetalThickness** – short designation: **MT**.
- **Node** – The name of the node to which the object belongs is useful for dividing the final specification into groups. Note: If missing, the document name is used.
- **Price** – cost price of an object (can be specified by an equation linked to the material).


- **Unfold** – determines the need to create a flat view (unfold) for a specific object (relevant only for sheet metal parts).
- **Weight** – object mass.
- **Quantity** and **Unit** of measurement (-, m, kg, m², m³). For piece items, the default value in most cases is one, «pcs» (-). Any combination is available for different materials: for example, a seal length of **1.2 m** or a quantity of insulation of **4.2 m²**. Important: values are summed for objects of the same name.

4.5 Additional properties

These properties are not essential (*they can be removed*), but nevertheless they are useful in work:

- **Format** – paper format of documentation for a specific object (enumeration).
- **Id** – some object identifier for communication with another program.
- **Note** – any note, reminder or clarification.
- **Type** – object type (enumeration). Useful property for grouping elements when displaying or exporting a BOM.
- **Section** – specification sections, USDD standard requirement.
Unified System for Design Documentation – Russia.

*To account for an object by the program, only the **Name** property is required, all others are used as needed.*



The screenshot shows a software interface with a tree view on the left and a table on the right. The tree view has a root node 'Link - Node' which contains several sub-nodes: 'Origin', 'Spreadsheet', 'E2 - Stand' (highlighted in blue), 'Amplifier 1', 'Amplifier 2', 'Link - Electromotor', and 'Explosion'. The table on the right lists the properties of the selected 'E2 - Stand' object.

Property	Value
Code	E2
Index	05
Material	Galvanized
Metal Thickness	2,00 (BaseBend.thickness)
Name	Stand
Type	Sheet metal part
Unfold	true
Weight	1,67 (.Tip.Shape.Volume * 7870 / 10 ^ 9)

Figure 5: Example of an object with filled in properties

Properties
Materials
Sheet metal
Other

Color of sheet metal parts
#b4c0c8
4
Calculate K-Factor

Galvanized / Steel

	Thickness	Radius	K-Factor
1	0.35	1.0	0.475
2	0.4	1.0	0.472
3	0.45	1.0	0.469
4	0.5	1.0	0.466
5	0.55	1.0	0.464
6	0.6	1.0	0.461
7	0.65	1.0	0.458
8	0.7	1.3	0.464
9	0.75	1.3	0.462
10	0.8	1.3	0.46
11	0.9	1.3	0.456
12	1.0	1.3	0.453
13	1.2	1.7	0.456
14	1.4	1.7	0.45
15	1.5	1.7	0.448
16	1.8	1.7	0.44
17	2.0	2.7	0.454
18	2.5	2.7	0.446
19	3.0	3.3	0.446
20	3.5	3.3	0.44

Default
Remove
Add

Stainless / AISI

	Thickness	Radius	K-Factor
1	0.4	1.0	0.472
2	0.5	1.0	0.466
3	0.6	1.0	0.461
4	0.7	1.3	0.464
5	0.8	1.3	0.46
6	0.9	1.3	0.456
7	1.0	1.3	0.453
8	1.2	1.7	0.456
9	1.5	1.7	0.448
10	2.0	2.7	0.454
11	2.5	2.7	0.446
12	3.0	3.3	0.446
13	4.0	5.3	0.453
14	5.0	6.7	0.454
15	6.0	8.3	0.455
16	8.0	10.5	0.453
17	10.0	13.3	0.454
18	12.0	16.7	0.455

Default
Remove
Add

Figure 6: Sheet metal preferences

4.6 Area 4 – Color for sheet metal part

Color display for the object in HEX format, default value: #b4c0c8.

4.7 Area 5 – Sheet steel parameters

This table indicates the acceptable sheet metal **Thickness** for use and their parameters, such as the internal bending **Radius**, the **K-Factor** used when calculating the flat view (unfold).

The **Calculate K-Factor** button automatically calculates the **k-factor** for each thickness using formulas from the strength of materials:




Figure 7: Formulas for calculating sheet metal parameters




Figure 8: Additional preferences

4.8 Area 6 – FreeCAD interface font options, additions

In the **Font** area, you can specify the need to replace the standard program font and its parameters. The **Additions** area displays the presence of modules in the system that are necessary for the full operation of this workbench.

4.9 Area 7 – Parameters for Russian standard templates

In this area you can specify values for automatic filling of stamps when [creating drawings](#) based on a template and automatic generation of a specification based on a model. The template specified in the corresponding field (шаблон текстового документа) will be selected as the first sheet of the specification.

Properties Materials Sheet metal Other					
Default material		Galvanized		Default Remove Add	
	Title	Category	Density	Unit	Price per unit
1	Galvanized	Sheet metal	7870	m^2	0
2	Stainless	Sheet metal	7900	m^2	0
3	Aluminum	General	2700	kg	0
4	Brass	General	8600	kg	0
5	Cast iron	General	7300	kg	0
6	Ceramic	General	2300	kg	0
7	Concrete	General	2410	m^3	0
8	Copper	General	8900	kg	0
9	Glass	General	2530	kg	0
10	Mineral wool	General	100	m^2	0
11	Rubber	General	1000	kg	0
12	Steel	General	7800	kg	0
13	AISI 201	Sheet metal	7860	m^2	0
14	AISI 304	Sheet metal	7950	m^2	0
15	AISI 316	Sheet metal	7970	m^2	0
16	AISI 321	Sheet metal	8020	m^2	0
17	AISI 430	Sheet metal	7720	m^2	0
18	ABS	Plastic	1040	kg	0
19	PET/G	Plastic	1340	kg	0
20	PLA	Plastic	1240	kg	0
21	PP	Plastic	900	kg	0
22	PVC	Plastic	1330	kg	0
23	EPDM	Rubber	155	kg	0
24	Natural rubber	Rubber	920	kg	0
25	Neoprene	Rubber	1230	kg	0
26	Wood, low density	Wood	500	m^3	0
27	Wood, medium density	Wood	700	m^3	0
28	Wood, high density	Wood	900	m^3	0

Figure 9: Materials and their parameters

4.10 Materials

This tab contains a list of materials available for use. Parameters:

- **Title** and **Category** – name of the material and its category. For work with sheet metal parts, the choice of material is limited to the corresponding category.
- **Density** – material density, can be used to automatically calculate the mass of an object, the «Weight» property.
- **Unit** and **Price per unit** – price per unit of material, if necessary, can be used to calculate the cost of the element, the «Price» property.

5 Filling an object with properties

To add properties, you need to select one or more objects and use the [Add Properties](#) command on the toolbar.




Figure 10: Interface **Add Properties**

The entire list of available custom properties is visible in the command interface. You need to mark the ones you need and click **Add**.

Buttons **All**, **Core**, **None** – select all properties, only the main ones and clear the selection. The **Prev.** button will highlight the properties added the last time the command was used.

Checkbox **Set weight and price as an equation** – if enabled, the added properties «Weight» and «Price» will contain equations for automatic calculation of the corresponding parameters.

The **Sheet metal part** checkbox will check all the necessary properties for a sheet metal part, allow you to select the type of material and, if desired, associate the «MetalThickness» property with the thickness parameters of the object. Additionally, the element will be assigned a weight and color based on the parameters specified in the settings.

Note: During the process of assigning a **Name** and **Index**, the program tries to guess the property values based on the **Label** of the object.

To automatically fill these properties, the name template must match: «**Index. Name - Copy**» or «**Index - Name - Copy**». If the template matches, the values will be filled in correctly – [example](#).

6 Bill of materials – BOM

To generate and work with BOM, you must use the **Specification** command on the toolbar. Based on user properties, the program will generate a specification for any model (assembly), consider an example from the workbench:




Figure 11: Bill of materials




Figure 12: Bill of materials, sheet metal parts

The specification interface contains two tabs:

- **All** – all objects.
- **Sheet metal** – sheet metal objects.

The **Strict mode** option – if the checkbox is unchecked, the program will process all user properties in your group – [figure 4: area 1](#), not only those specified in the table (area 2).

There are two buttons on the [all](#) specification tab:

- **Indexing elements** – Automatic indexing of positions for all elements included in the specification.
- **Update enumerations** – update in model objects properties containing lists of predefined values. Useful after adding new values to preferences.
- **Update equations** – updating in model objects properties containing material-related equations, properties «Weight» and «Price».

Next we will look at **Sheet metal** objects – this tab contains functions for their batch processing. The manufacturing process for such parts will in most cases require two elements:

- **Blank (unfold)** – a flat view of an object for nesting and processing on machines.
- **Part in 3D format (step)** – for bending sheet metal.

All parts from the list generated based on the model (assembly), depending on the value of the **Unfold** property, can be processed and exported to external files, such as dxf, svg (unfolding) and step (3D).

Select a directory – to save work results (the default value is the user's desktop).

Unfold prefix – the name of the directory in which the files will be saved, as well as an option for signing the part.

File signature – list of options for part signature. The signature is text in the file, inside the outline of the part, which can be useful when nesting. At the moment the function is only available for dxf format. When set to **None**, the signature is disabled. Important: This function requires the Python module: [ezdxf](#).

File Name – the template by which the files will be named, for example, for the part «**E2 - Stand**» ([figure 5](#)) the names will be as follows:

- **Name** = Stand (1).dxf
- **Code** = E2 (1).dxf
- **Index** = 05 (1).dxf
- **Code + Name** = (E2) Stand (1).dxf
- **Index + Name** = (05) Stand (1).dxf

The number in brackets at the end of the name is the copy number, if there are two or more identical parts in the assembly, they will be saved in separate files.

After selecting the desired options and parameters, you can click the **Unfold** button and the program will save all received data in the specified path. The work process can be observed in the progress indicator and in FreeCAD, in the report panel (report view).

Important: The part files will be placed in additional directories, the names of which correspond to the name of the material and the thickness of the steel.

7 Export specification

The program can export a model (assembly) specification for subsequent viewing, editing or other use, available formats:

- **Spreadsheet** – FreeCAD spreadsheet workbench.
- **json** – the most suitable option for subsequent automation.
- **csv** – comma-separated values.
- **RU std** – Unified System for Design Documentation, USDD – Russia.

First, let's look at the export options, button **Export Settings**.




Figure 13: Specification export options

On the left side of the interface you need to select the properties that will be available for export.

In the **Use aliases** area, you need to mark the formats in which aliases will be used, as a replacement for the **Title** property.

In the **Order of elements** area, you need to specify properties for grouping and sorting objects:

- **Merger** – a property by the value of which the elements will be grouped, the most suitable is the object **Type**, for example, display first all fasteners, then materials, then sheet metal parts.
- **Sorting** – a property by the value of which objects will be sorted within a **Merger**, the most logical thing is to sort by **Index** or **Name**.

Select the necessary options, the appropriate format and click the button **Export**.

	A	B	C	D	E	F	G	H
1	Code	Index	MT	Name	Quantity	Type	Unfold	Weight
2		6		Plain washer - M10	4	Fastener		0,01
3		7		Spring lock washer - M10	4	Fastener		0,01
4		8		Hexagon nut - M10	4	Fastener		0,04
5		9		Plain washer, outer diameter - M8	4	Fastener		0,03
6		10		Spring lock washer - M8	8	Fastener		0,01
7		11		Hexagon head cap screw - M8X25	4	Fastener		0,06
8		12		Plain washer - M8	4	Fastener		0,01
9		13		Hexagon nut - M8	4	Fastener		0,02
10		15		Plain washer - M6	24	Fastener		0,02
11		16		Spring lock washer - M6	24	Fastener		0,01
12		17		Hexagon head cap screw - M6X20	12	Fastener		0,08
13		18		Hexagon nut - M6	12	Fastener		0,03
14		2		Electromotor - DIN 80 (2,4,6,8)	1	Material		11,20
15		4		AVM - 50X30	4	Material		0,56
16	E1	1	2	Base	1	Sheet metal part	True	1,43
17	F1	3	3	Guide	2	Sheet metal part	True	4,13
18	E2	5	2	Stand	1	Sheet metal part	True	1,65
19	D1	14	1,50	Amplifier	2	Sheet metal part	True	0,47

Figure 14: BOM export result

8 Managing a parametric model

The [Model Control](#) command is available on the taskbar, the purpose of which is to launch a control program for a **parametric** model.

In my work, I was convinced that not one of the existing (for FreeCAD) assembly systems in combination with tables and equations is capable of providing such capabilities that are available from program code.

I write control files and interfaces for my parametric models, which are convenient to call with one command. To do this, next to the main model (assembly) file there should be two files named similarly to the main one.

In the samples supplied with the workbench, a simple example of a parametric model is available for study – `addFC/repo/example`




Figure 15: Parametric model files

- **.FCStd** – main model file – assembly.
- **.ui** – user interface – Qt.
- **.py** – source code – Python.
- **noAssembly** – directory with additional files.

Having opened the main file, you can call its control program using the [Model Control](#) command:




Figure 16: Parametric model management interface

For convenience, the graphical user interface is built into the FreeCAD sidebar; after setting the necessary parameters and selecting components from the lists, click the **Rebuild** button – the model will be updated.

9 Creating a pipeline using coordinates

The **Pipe** command allows you to create a pipeline using specified coordinates, *the source of coordinates must be points* - either **Point** (Draft) or **Datum Point** (PartDesign). The first option is preferable.

Create and place points in 3D space, for convenience, they can be combined into a group, as shown in the example (figure 17).

Select the group with dots or any other parent element (in the example, pipe and path) in the project tree and click **Pipe** on the toolbar.




Figure 17: Coordinate points and interface **Pipe**

The interface provides:

- **Top drop down list** – these are pipe templates, available options:
 - **OD - Copper pipe** – inch copper pipes, range from 1/4” to 4+1/8”.
 - **DN - Nominal pipe size** – NPS.
 - **DN - ВГП (водогазопроводная)** – GOST 3262-75 (Russia).
- **Pipe** – pipe size option from selected template.
- **Diameter** – diameter, OD – external, DN – nominal bore.
- **Fillet radius** – pipe bending radius.
- **Wall thickness** – pipe wall thickness.
- **Material** – pipe material, color and density values.

If necessary, the values of diameter, bend and wall thickness can be specified manually by changing the values of the corresponding fields.

After selecting the required parameters, click **Create pipe**.




Figure 18: The result of the **Pipe** operation

The program will receive the coordinates of all points (the points themselves will be sorted by **Label**, in ascending order) and will build a pipeline with the previously specified parameters.

The image shows the result of the team's work, on the right is an option with added fittings, command **And fittings**.

10 Exploded view

The **Explode** command is responsible for creating an exploded view – a sketch view of a design (assembly) with its component parts exploded, which allows you to convey information about the product in a simpler and easier to understand form. The tool allows you to create, animate and save views.




Figure 19: **Explode**: exploded view of model




Figure 20: **Explode**: export exploded view to drawing




Figure 21: **Explode** interface

On the left side of the interface there are groups, a group is one or more combined elements. To create a group, you need to select objects in the project tree or 3D view window and click the **Add** button. Created groups can be **Remove** and moved by positions (arrows: up, down).

Double clicking on the group name will make it active, area: **Selected group**.

Elements of the active group can be moved by coordinates (**Position**) and rotated by axes (**Rotation**). All actions are displayed in the 3D view window and are automatically saved.

The **Combine** button returns all elements in the group to their original positions.

The **Explode** button moves the group objects to the location specified by the user.

Список **Selection** - appearance of selected objects:

- **Shape** – fill an object with color (standard selection).
- **BoundingBox** – frame around object.
- **None** – no selection.

The **Trace** tab is responsible for guides - these are visual lines from the original position of the element to its current location specified by the user.

- **Line style, Color** – the style of the guide line and its color.
- **Line width, Point size** – line thickness and size of start and end points.
- **Create, Remove** – create and delete guide lines for a group.

An example of guides can be seen in images [19](#) and [20](#).

The **Animation** tab is responsible for animating the exploded view and exporting the animation to a video file. The general principle of operation is as follows: after moving and/or rotating an object, you can **Add key** frame, the program animates the movement and/or rotation of objects from the initial location to the position specified by the key frame. The number of frames is unlimited. The current number of frames is displayed in the field: **Key frames**. The **Clear** button will delete all created key frames for the group.

Speed – the animation playback speed for the current keyframe..

Split – if checked, the objects in the group will be animated sequentially.

Trace – display guide lines for objects during animation.

Animate button – play animation by keyframes.

Reverse checkbox, if checked – the animation will be played in reverse.

Auto fit – automatic camera positioning to display all elements.

Export – when playing, save the animation to a video file.

Important: for full functionality you need:

- Python **NumPy** module for animation.
- **FFmpeg** library for exporting animation to a video file.




Figure 22: Export settings

Export options are the video file **Resolution**, **Frame rate**, directory for saving the result – the **Select a directory** button, and also some frame-by-frame image settings:

- **Image format** – PNG (higher quality) and JPG (faster).
- **Background and Creation method.**

11 Библиотека элементов и узлов

Coming soon...