



1. Configure Management Switches: NetApp HCI with RHV

NetApp Solutions

Kevin Hoke, Dorian Henderson
February 19, 2021

This PDF was generated from https://docs.netapp.com/us-en/netapp-solutions/infra/rhv-1._configure_management_switches.html on August 03, 2021. Always check docs.netapp.com for the latest.

Table of Contents

1. Configure Management Switches: NetApp HCI with RHV 1

1. Configure Management Switches: NetApp HCI with RHV

Cisco Nexus 3048 switches are used in this deployment procedure to provide 1Gbps connectivity for in and out-of-band management of the compute and storage nodes. These steps begin after the switches have been racked, powered, and put through the initial setup process. To configure the switches to provide management connectivity to the infrastructure, complete the following steps:

Enable Advanced Features for Cisco Nexus

Run the following commands on each Cisco Nexus 3048 switch to configure advanced features:

1. Enter configuration mode.

```
Switch-01# configure terminal
```

2. Enable VLAN functionality.

```
Switch-01(config)# feature interface-vlan
```

3. Enable LACP.

```
Switch-01(config)# feature lacp
```

4. Enable virtual port channels (vPCs).

```
Switch-01(config)# feature vpc
```

5. Set the global port-channel load-balancing configuration.

```
Switch-01(config)# port-channel load-balance src-dst ip-l4port
```

6. Perform global spanning-tree configuration.

```
Switch-01(config)# spanning-tree port type network default  
Switch-01(config)# spanning-tree port type edge bpduguard default
```

Configure Ports on the Switch for In-Band Management

1. Run the following commands to create VLANs for management purposes:

```
Switch-01(config)# vlan 2
Switch-01(config-vlan)# Name Native_VLAN
Switch-01(config-vlan)# vlan 16
Switch-01(config-vlan)# Name OOB_Network
Switch-01(config-vlan)# vlan 1172
Switch-01(config-vlan)# Name MGMT_Network
Switch-01(config-vlan)# exit
```

2. Configure the ports ETH1/29-32 as VLAN trunk ports that connect to management interfaces on each HCI storage node.

```
Switch-01(config)# int eth 1/29
Switch-01(config-if)# description HCI-STG-01 PortA
Switch-01(config-if)# switchport mode trunk
Switch-01(config-if)# switchport trunk native vlan 2
Switch-01(config-if)# switchport trunk allowed vlan 1172
Switch-01(config-if)# spanning tree port type edge trunk
Switch-01(config-if)# int eth 1/30
Switch-01(config-if)# description HCI-STG-02 PortA
Switch-01(config-if)# switchport mode trunk
Switch-01(config-if)# switchport trunk native vlan 2
Switch-01(config-if)# switchport trunk allowed vlan 1172
Switch-01(config-if)# spanning tree port type edge trunk
Switch-01(config-if)# int eth 1/31
Switch-01(config-if)# description HCI-STG-03 PortA
Switch-01(config-if)# switchport mode trunk
Switch-01(config-if)# switchport trunk native vlan 2
Switch-01(config-if)# switchport trunk allowed vlan 1172
Switch-01(config-if)# spanning tree port type edge trunk
Switch-01(config-if)# int eth 1/32
Switch-01(config-if)# description HCI-STG-04 PortA
Switch-01(config-if)# switchport mode trunk
Switch-01(config-if)# switchport trunk native vlan 2
Switch-01(config-if)# switchport trunk allowed vlan 1172
Switch-01(config-if)# spanning tree port type edge trunk
Switch-01(config-if)# exit
```

Configure Ports on the Switch for Out-of-Band Management

Run the following commands to configure the ports for cabling the IPMI interfaces on each HCI node.

```
Switch-01(config)# int eth 1/13
Switch-01(config-if)# description HCI-CMP-01 IPMI
Switch-01(config-if)# switchport mode access
Switch-01(config-if)# switchport access vlan 16
Switch-01(config-if)# spanning-tree port type edge
Switch-01(config-if)# int eth 1/14
Switch-01(config-if)# description HCI-STG-01 IPMI
Switch-01(config-if)# switchport mode access
Switch-01(config-if)# switchport access vlan 16
Switch-01(config-if)# spanning-tree port type edge
Switch-01(config-if)# int eth 1/15
Switch-01(config-if)# description HCI-STG-03 IPMI
Switch-01(config-if)# switchport mode access
Switch-01(config-if)# switchport access vlan 16
Switch-01(config-if)# spanning-tree port type edge
Switch-01(config-if)# exit
```



In the validated configuration, we cabled odd-node IPMI interfaces to Switch-01 and even-node IPMI interfaces to Switch-02.

Create a vPC Domain to Ensure Fault Tolerance

1. Activate the ports used for the vPC peer-link between the two switches.

```
Switch-01(config)# int eth 1/1
Switch-01(config-if)# description vPC peer-link Switch-02 1/1
Switch-01(config-if)# int eth 1/2
Switch-01(config-if)# description vPC peer-link Switch-02 1/2
Switch-01(config-if)# exit
```

2. Perform the vPC global configuration.

```
Switch-01(config)# vpc domain 1
Switch-01(config-vpc-domain)# role priority 10
Switch-01(config-vpc-domain)# peer-keepalive destination <switch-
02_mgmt_address> source <switch-01_mgmt_address> vrf managment
Switch-01(config-vpc-domain)# peer-gateway
Switch-01(config-vpc-domain)# auto recovery
Switch-01(config-vpc-domain)# ip arp synchronize
Switch-01(config-vpc-domain)# int eth 1/1-2
Switch-01(config-vpc-domain)# channel-group 10 mode active
Switch-01(config-vpc-domain)# int Po10
Switch-01(config-if)# description vPC peer-link
Switch-01(config-if)# switchport mode trunk
Switch-01(config-if)# switchport trunk native vlan 2
Switch-01(config-if)# switchport trunk allowed vlan 16, 1172
Switch-01(config-if)# spanning-tree port type network
Switch-01(config-if)# vpc peer-link
Switch-01(config-if)# exit
```

[Next: 2. Configure Data Switches](#)

Copyright Information

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system-without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.