

How to use device to update EMV Configuration

1. You need to move your "emv_profile_tlv.xml" file to this folder. Make sure the xml file name is "emv_profile_tlv".
2. Click the "old_emv_profile_to_bin.exe" to get the two bin files.
3. Move this these two bin files to the assets folder in main.
4. Use the "updateEmvConfig" function to update.

```
public void updateEmvConfig(){
    String emvAppCfg = QPOSUtil.byteArray2Hex(readLine("emv_app.bin"));
    String emvCapkCfg = QPOSUtil.byteArray2Hex(readLine("emv_capk.bin"));
    TRACE.d("emvAppCfg: "+emvAppCfg);
    TRACE.d("emvCapkCfg: "+emvCapkCfg);
    pos.updateEmvConfig(emvAppCfg,emvCapkCfg);
}
```

5. Please make sure you connect the device on charger when you updating.