


## Technical Quick Guides


### Dahua Intercom Password for Door Unlock

For Firmware Ver 4.6 below

Login to the Webpage and select **Local Settings**




At the Local Settings select




Under Access Control, Select **Password Management**,

You can modify the existing password or Add additional password




To Add click the Add button and enter the username that you want and the password, you can enter a 4 digits code or a 6 digits code.





Select the Password and add the code you want to, you can enter 4 digits code or 6 digits code

Figure 8-2 Add the person



**Add** [X]

\* Person ID

\* Room No.

Username

\* Validity Period

\* Lock Permission ☒ Local Lock ☒ External Lock

Multi-Door Unlock ⓘ ☐

**Verification Mode**

> Password	Not Added
> Card	Not Added

OK Cancel

**Note: To unlock the door, you need to press the # + Code + #**