

UEFI & EDK II Training

Platform Configuration Database (PCD)

tianocore.org

LESSON OBJECTIVE

- ★ Define Platform Configuration Database (PCD) and explain the syntax
- ★ Differentiate types of PCDs
- ★ Explain how changing a PCD value affects output
- ★ Evaluate the results of a PCD value modification

PCD OVERVIEW

EDK II PCD's Purpose and Goals

 Documentaton : [MdeModulePkg/Universal/PCD/Dxe/Pcd.inf](https://github.com/tianocore/edk2/blob/master/MdeModulePkg/Universal/PCD/Dxe/Pcd.inf)

Purpose

- Establishes platform common definitions
- Build-time/Run-time aspects
- Binary Editing Capabilities

Goals

- Simplify porting
- Easy to associate with a module or platform

EDK II PCD's Purpose and Goals

 Documentaton : [MdeModulePkg/Universal/PCD/Dxe/Pcd.inf](https://github.com/tianocore/edk2/blob/master/MdeModulePkg/Universal/PCD/Dxe/Pcd.inf)

```
////////////////////////////////////  
//  
//          Introduction of PCD database          //  
//  
////////////////////////////////////
```

1, Introduction

PCD database hold all dynamic type PCD information. The structure of PEI PCD database is generated by build tools according to dynamic PCD usage for specified platform.

2, Dynamic Type PCD

Dynamic type PCD is used for the configuration/setting which value is determined dynamic. In contrast, the value of static type PCD (FeatureFlag, FixedPcd, PatchablePcd) is fixed in final generated FD image in build time.

See Link above to view the entire documentation

FeatureFlag

FixedAtBuild

FeatureFlag

PCD TYPES

FixedAtBuild

PatchableInModule

FeatureFlag

PCD TYPES

FixedAtBuild

Dynamic

PatchableInModule

DyanmicEx

DynamicHii

FeatureFlag

DynamicVpd

PCD TYPES

FixedAtBuild

Dynamic

PatchableInModule

DyanmicEx

DynamicHii

FeatureFlag

DynamicVpd

Syntax Examples

```
[pcdsFeatureFlag.common] [pcdsFixedAtBuild.IA32]
```


PCD TYPES

FixedAtBuild

Dynamic

PatchableInModule

DyanmicEx

DynamicHii

FeatureFlag

DynamicVpd

Syntax Examples

`[pcdsFeatureFlag.common]`

`[pcdsFixedAtBuild.IA32]`

PCD TYPES

FixedAtBuild

Dynamic

PatchableInModule

DyanmicEx

DynamicHii

FeatureFlag

DynamicVpd

Syntax Examples

```
[pcdsFeatureFlag.common] [pcdsFixedAtBuild, IA32]
```


PCD TYPES

FixedAtBuild

Dynamic

PatchableInModule

DyanmicEx

DynamicHii

FeatureFlag

DynamicVpd

Syntax Examples

```
[pcdsFeatureFlag.common] [pcdsFixedAtBuild.IA32]  
[PcdsFixedAtBuild, PcdsPatchableInModule, PcdsDynamic,  
PcdsDynamicEx]
```


UEFI Platform Initialization (PI) 1.x Spec & PCDs


PEI

- PCD PEIM produces PCD database
- Two PCD PPIs: PCD_PPI and EFI_PEI_PCD_PPI

DXE

- DXE Driver Manages PCDs
- Two PCD Protocols: PCD_PROTOCOL and EFI_PCD_PROTOCOL

- Provides interface for PCDs
- PCD PPI - PEI
- PCD Protocol – DXE
- Allows access to data



PCD LIBRARY CALLS: PCD PROTOCOL AND PCD PPI FUNCTIONS

```
PcdGetXX()  
PcdSetXX()  
PcdGetExXX()  
PcdSetExXX()  
PcdToken()  
PCDSetSku()  
PcdGetNextToken()  
PcdGetNextTokenSpace()  
CallbackOnSet()  
CancelCallback()
```

Where “xx” =

```
8  
16  
32  
Size  
Ptr  
Boolean
```


PCDs can be located anywhere within the Workspace even though a different package will use those PCDs for a given project

.DEC

Define PCD

PCDs can be located anywhere within the Workspace even though a different package will use those PCDs for a given project

.DEC

Define PCD

.INF

**Reference
PCD**

PCDs can be located anywhere within the Workspace even though a different package will use those PCDs for a given project

.DEC

Define PCD

.INF

**Reference
PCD**

.DSC

Modify PCD

PCD SYNTAX EXAMPLE



PCD SYNTAX EXAMPLE

DEC

PCD defined in the DEC file from any package

```
[Guids.common]
```

```
PcdTokenSpaceGuidName={ 0xxxxxxxxx, 0xxxxx, 0xxxxx, { 0xxx, . . . }}
```

```
. . .
```

```
[Pcds...]
```

```
PcdTokenSpaceGuidName.PcdTokenName | Value[ | DatumType[ | MaxSize]] | Token
```

INF

DSC

PCD SYNTAX EXAMPLE

DEC

PCD defined in the DEC file from any package

```
[Guids.common]  
PcdTokenSpaceGuidName= { 0xxxxxxxxx, 0xxxxx, 0xxxxx, { 0xxx, . . . } }  
  
. . .  
[Pcds...]  
PcdTokenSpaceGuidName.PcdTokenName | Value[ | DatumType[ | MaxSize]] | Token
```

INF

PCD usage listed in INF file for module

```
[...Pcd...]  
PcdTokenSpaceGuidName.PcdTokenName | [Value]
```

DSC

PCD SYNTAX EXAMPLE

DEC

PCD defined in the DEC file from any package

```
[Guids.common]
PcdTokenSpaceGuidName={ 0xxxxxxxxx, 0xxxxx, 0xxxxx, { 0xxx, . . .}}

. . .
[Pcds...]
PcdTokenSpaceGuidName.PcdTokenName|Value[|DatumType[|MaxSize]]|Token
```

INF

PCD usage listed in INF file for module

```
[...Pcd...]
PcdTokenSpaceGuidName.PcdTokenName|[Value]
```

DSC

Value of PCD set in Platform DSC

```
[Pcds...]
PcdTokenSpaceGuidName.PcdTokenName|Value[|DatumType[|MaximumDatumSize]]
```


PCD VARIABLE EXAMPLE



PCD VARIABLE EXAMPLE

Defined



```
[PcdsFixedAtBuild, PcdsPatchableInModule]  
gEfiMdeModulePkgTokenSpaceGuid.PcdMaxVariableSize | 0x400 | UINT32 | 0x30000003
```


PCD VARIABLE EXAMPLE



Defined

```
[PcdsFixedAtBuild, PcdsPatchableInModule]  
gEfiMdeModulePkgTokenSpaceGuid.PcdMaxVariableSize | 0x400 | UINT32 | 0x30000003
```



Referenced

MdeModulePkg\Universal\Variable\RuntimeDxe\VariableRuntimeDxe.inf

```
[Pcd]  
gEfiMdeModulePkgTokenSpaceGuid.PcdMaxVariableSize ## CONSUMES
```



PCD VARIABLE EXAMPLE



Defined

```
[PcdsFixedAtBuild, PcdsPatchableInModule]  
gEfiMdeModulePkgTokenSpaceGuid.PcdMaxVariableSize | 0x400 | UINT32 | 0x30000003
```



Referenced

MdeModulePkg\Universal\Variable\RuntimeDxe\VariableRuntimeDxe.inf

```
[Pcd]  
gEfiMdeModulePkgTokenSpaceGuid.PcdMaxVariableSize ## CONSUMES
```



Modified

```
[PcdsFixedAtBuild]  
gEfiMdeModulePkgTokenSpaceGuid.PcdMaxVariableSize | 0x008400
```



PCD VARIABLE EXAMPLE



Defined

```
[PcdsFixedAtBuild, PcdsPatchableInModule]  
gEfiMdeModulePkgTokenSpaceGuid.PcdMaxVariableSize | 0x400 | UINT32 | 0x30000003
```



Referenced

MdeModulePkg\Universal\Variable\RuntimeDxe\VariableRuntimeDxe.inf

```
[Pcd]  
gEfiMdeModulePkgTokenSpaceGuid.PcdMaxVariableSize ## CONSUMES
```



Modified

```
[PcdsFixedAtBuild]  
gEfiMdeModulePkgTokenSpaceGuid.PcdMaxVariableSize | 0x008400
```



Used

MdeModulePkg\Universal\Variable\RuntimeDxe\Variable.c // max NV variable size

```
mVariableModuleGlobal->MaxVariableSize = PcdGet32 (PcdMaxVariableSize);
```


PCD VARIABLE EXAMPLE



Defined

```
[PcdsFixedAtBuild, PcdsPatchableInModule]
gEfiMdeModulePkgTokenSpaceGuid.PcdMaxVariableSize | 0x400 | UINT32 | 0x30000003
```



Referenced

MdeModulePkg\Universal\Variable\RuntimeDxe\VariableRuntimeDxe.inf

```
[Pcd]
gEfiMdeModulePkgTokenSpaceGuid.PcdMaxVariableSize ## CONSUMES
```



Modified

```
[PcdsFixedAtBuild]
gEfiMdeModulePkgTokenSpaceGuid.PcdMaxVariableSize | 0x008400
```



Used

MdeModulePkg\Universal\Variable\RuntimeDxe\Variable.c // max NV variable size

```
mVariableModuleGlobal->MaxVariableSize = PcdGet32 (PcdMaxVariableSize);
```



PCD SOFTWARE

DEC
+
INF
+
DSC


PCD SOFTWARE




PCD SOFTWARE



PCD SOFTWARE




PCD SOFTWARE




PCD DRIVER

DEC
+
INF
+
DSC


PCD DRIVER




PCD DRIVER



PCD DRIVER



PCD DRIVER



Fixed PCD AutoGen files

Example :  [MdeModulePkg\Universal\Variable\RuntimeDxe\VariableRuntimeDxe](#)

Autogen.h

```
#define _PCD_TOKEN_PcdMaxVariableSize 250U
#define _PCD_SIZE_PcdMaxVariableSize 4
#define _PCD_GET_MODE_SIZE_PcdMaxVariableSize _PCD_SIZE_PcdMaxVariableSize
#define _PCD_VALUE_PcdMaxVariableSize 0x8400U
extern const UINT32 _gPcd_FixedAtBuild_PcdMaxVariableSize;
#define _PCD_GET_MODE_32_PcdMaxVariableSize _gPcd_FixedAtBuild_PcdMaxVariableSize
```

Autogen.c

```
// Definition of PCDs used in this module
...
GLOBAL_REMOVE_IF_UNREFERENCED const UINT32
_gPcd_FixedAtBuild_PcdMaxVariableSize = _PCD_VALUE_PcdMaxVariableSize;
```


What about a Dynamic PCDs?

- Only can be Set and changed during Boot time.
- PCD can be set with the library Set: LibPcdSet...
- PCD can be retrieved with the library Get: LibPcdGet...

Example: Use the variable **PcdPlatformBootTimeOut** defined for the platform time in seconds before booting, modified for a value of **03** seconds



Defined

[PcdsDynamic]

gEfiIntelFrameworkModulePkgTokenSpaceGuid.**PcdPlatformBootTimeOut** | 0xffff | UINT16 | 0x



Defined

[PcdsDynamic]

gEfiIntelFrameworkModulePkgTokenSpaceGuid.**PcdPlatformBootTimeOut** | 0xffff | UINT16 | 0x



Modified

[PcdsDynamicDefault]

gEfiIntelFrameworkModulePkgTokenSpaceGuid.**PcdPlatformBootTimeOut** | 03



Defined

[PcdsDynamic]

```
gEfiIntelFrameworkModulePkgTokenSpaceGuid.PcdPlatformBootTimeOut | 0xffff | UINT16 | 0x
```



Modified

[PcdsDynamicDefault]

```
gEfiIntelFrameworkModulePkgTokenSpaceGuid.PcdPlatformBootTimeOut | 03
```



Setting

IntelFrameworkModulePkg/Universal/BdsDxe/BootMaint/BootMaint.c

```
PcdSet16 (PcdPlatformBootTimeOut,  
          NewBmmData->BootTimeOut);
```




Defined

[PcdsDynamic]

gEfiIntelFrameworkModulePkgTokenSpaceGuid.**PcdPlatformBootTimeOut** | 0xffff | UINT16 | 0x



Modified

[PcdsDynamicDefault]

gEfiIntelFrameworkModulePkgTokenSpaceGuid.**PcdPlatformBootTimeOut** | 03



Setting

IntelFrameworkModulePkg/Universal/BdsDxe/BootMaint/BootMaint.c

```
PcdSet16 (PcdPlatformBootTimeOut,  
          NewBmmData->BootTimeOut);
```



Used

OvmfPkg/Library/PlatformBootManagerLib/BdsPlatform.c

```
Timeout = PcdGet16 (PcdPlatformBootTimeOut);
```


DEC

Defined

[PcdsDynamic]

`gEfiIntelFrameworkModulePkgTokenSpaceGuid.PcdPlatformBootTimeOut | 0xffff | UINT16 | 0x`

DSC

Modified

[PcdsDynamicDefault]

`gEfiIntelFrameworkModulePkgTokenSpaceGuid.PcdPlatformBootTimeOut | 03`

C

Setting

`IntelFrameworkModulePkg/Universal/BdsDxe/BootMaint/BootMaint.c`

```
PcdSet16 (PcdPlatformBootTimeOut,  
          NewBmmData->BootTimeOut);
```

C

Used

`OvmfPkg/Library/PlatformBootManagerLib/BdsPlatform.c`

```
Timeout = PcdGet16 (PcdPlatformBootTimeOut);
```


DYNAMIC PCD AUTOGEN FILES

Example Module: (OvmfPkg/Library/PlatformBootManagerLib)

DYNAMIC PCD AUTOGEN FILES

Example Module: (OvmfPkg/Library/PlatformBootManagerLib)

Autogen.h

• • •

```
#define _PCD_SET_MODE_16_PcdPlatformBootTimeOut(Value) \  
    LibPcdSet16(_PCD_TOKEN_PcdPlatformBootTimeOut, (Value))  
#define _PCD_SET_MODE_16_S_PcdPlatformBootTimeOut(Value) \  
    LibPcdSet16S(_PCD_TOKEN_PcdPlatformBootTimeOut, (Value))
```


DYNAMIC PCD AUTOGEN FILES

Example Module: (OvmfPkg/Library/PlatformBootManagerLib)

Autogen.h

• • •

```
#define _PCD_SET_MODE_16_PcdPlatformBootTimeOut(Value) \  
    LibPcdSet16(_PCD_TOKEN_PcdPlatformBootTimeOut, (Value))  
#define _PCD_SET_MODE_16_S_PcdPlatformBootTimeOut(Value) \  
    LibPcdSet16S(_PCD_TOKEN_PcdPlatformBootTimeOut, (Value))
```

Example Module: (MdeModulePkg/Universal/PCD/Dxe/Pcd)

DYNAMIC PCD AUTOGEN FILES

Example Module: (OvmfPkg/Library/PlatformBootManagerLib)

Autogen.h

• • •

```
#define _PCD_SET_MODE_16_PcdPlatformBootTimeOut(Value) \  
    LibPcdSet16(_PCD_TOKEN_PcdPlatformBootTimeOut, (Value))  
#define _PCD_SET_MODE_16_S_PcdPlatformBootTimeOut(Value) \  
    LibPcdSet16S(_PCD_TOKEN_PcdPlatformBootTimeOut, (Value))
```

Example Module: (MdeModulePkg/Universal/PCD/Dxe/Pcd)

Autogen.c

```
DXE_PCD_DATABASE_INIT gDXEPcdDbInit = {  
    • • •  
    /* LocalTokenNumberTable */  
    • • •  
    offsetof(DXE_PCD_DATABASE, Init.PcdPlatformBootTimeOut_*1) | PCD_TYPE_DATA |  
    PCD_DATUM_TYPE_UINT16,  
    • • •  
    /* PcdPlatformBootTimeOut_*1 [1] */,
```

*1 GUID of PCD Variable PcdPlatformBootTimeOut

DYNAMIC PCD AUTOGEN FILES

Example Module: (OvmfPkg/Library/PlatformBootManagerLib)

Autogen.h

• • •

```
#define _PCD_SET_MODE_16_PcdPlatformBootTimeOut(Value) \
    LibPcdSet16(_PCD_TOKEN_PcdPlatformBootTimeOut, (Value))
#define _PCD_SET_MODE_16_S_PcdPlatformBootTimeOut(Value) \
    LibPcdSet16S(_PCD_TOKEN_PcdPlatformBootTimeOut, (Value))
```

Example Module: (MdeModulePkg/Universal/PCD/Dxe/Pcd)

Autogen.c

```
DXE_PCD_DATABASE_INIT gDXEPcdDbInit = {
    • • •
    /* LocalTokenNumberTable */
    • • •
    offsetof(DXE_PCD_DATABASE, Init.PcdPlatformBootTimeOut_*1) | PCD_TYPE_DATA |
    PCD_DATUM_TYPE_UINT16,
    • • •
    { 0x3U } /* PcdPlatformBootTimeOut_*1 [1] */,
```

*1 GUID of PCD Variable PcdPlatformBootTimeOut

SUMMARY

- ★ Define Platform Configuration Database (PCD) and explain the syntax
- ★ Differentiate types of PCDs
- ★ Explain how changing a PCD value affects output
- ★ Evaluate the results of a PCD value modification

Questions?



