

Prototype Pacemaker Manual

Artefact Setup

1. Clone Repository to Device
2. locate /main/ppmServer.py
 - 2a. If using two devices change Address to host device.
 - 2b. if using Local run ppmServer.py using python 3.7
3. locate /main/ppmClient.py
 - 3a. If using two devices change Address to host device.
 - 3b. if using local run ppmClient.py using python 3.7
4. Login to system using default User (Admin:pacewall)

COMMANDS

set minhr X – Used to set the minimum heart rate of the system

set maxhr X - Used to set the maximum heart rate of the system

set avghr X – Used to set the average heart rate of the system.

chkinfo – Used to check the current pacemaker settings

chkusr – Used to check the current users setup on the system.

addusr – Used to add a user to the system.

delusr – Used to delete a user from the system.

Chkuptime – Used to check the current system uptime

hh – Used to change the heart health (prototype Command)