

ASR6501 Demo Board Driver Manual

There are two micro USB interfaces for baseboard to connecting PC and each used for UART serial port interaction the other is for download/debug.

1. UART Serial Port:

The chip of serial port that transfer to USB is Cp2104. The upload attachment is "Windows XP/Server 2003/Vista/7/8/8.1 (v6.7) Version Driver".

If the testing environment does not match, please download it from the following website according to the version of Windows

<https://www.silabs.com/products/development-tools/software/usb-to-uart-bridge-vcp-drivers>

2. USB Download:

Using kitprog2 Driver, check as attachment.

After the installation of the two drivers, please check the Device Manager and display it as follows:

