

## The first use of JDY-10M must read it

1: The first use must set the ID: AT+NETID123456789ABC

The above is an example. It is generally suggested that users have to set the ID. As the last byte of the factory MAC address may be the same, it is generally suggested that users have to set it for the first time of use. You must set the AT+NETID, which is only for the mesh networks, the ordinary APP transparent transmission does not have to set it.

2: The first use must set the broadcast name. It is suggested not to use the name of JDY-10M-1.2. Users must change the broadcast names to their own, such as AT+NAME123, which is only for the mesh networks, the ordinary APP transparent transmission does not have to set it.

3: The first use must set the short address. It is suggested not to use the default short address. As the default short address is the last byte of the factory MAC address, which may be the same. It is suggested that users to change it during use. Special note: Each mesh network short address of JDY-10M must be unique within the mesh networks. For example, AT+MADDR11, which is only for the mesh networks, the ordinary APP transparent transmission does not have to set it.

Special declaration: Rookies please try to figure it out by yourselves. The JDY-10M user manual has been clearly described. The technical support are development engineers who do not have much time to answer such simple questions.