

The Primary and Secondary Client Interfaces (10Hz)

The information on this page applies to:

[3.4: Primary and Secondary Client Interface](#)

[3.3: Primary and Secondary Client Interface](#)

[3.2: Primary and Secondary Client Interface](#)

[3.1: Primary and Secondary Client Interface](#)

[3.0: Primary and Secondary Client Interface](#)

[1.8: Primary and Secondary Client Interface](#)

[1.7: Primary and Secondary Client Interface](#)

[1.6: Primary and Secondary Client Interface](#)

Primary client=port 30001(Robot state and messages)

Secondary client=port 30002(Only robot state and the Version messages)

Example of data recieved:

[Example](#)

The realtime communications interface (125 Hz)

The information on this page applies to UR software version

[3.2 -> 3.4 Realtime interface](#)

[3.0 and 3.1 Realtime interface](#)

[pre-3.0 Realtime interface](#)

RealTime client=port 30003(Only robot state and the Version messages)

The realtime communications interface is also known as the Matlab interface

	Updated	3/9/2017	By:	PLN			

Change log				
				Retur til index
Date	Revision	Initials	Action	Change
March 2017	3.4	RWI	Added	SW 3.3 worksheet: VersionMessage differs from SW3.2
		RWI	Added	SW 3.4 worksheet: RuntimeExceptionMessage has been changed to include the line & column number
		RWI	Added	DataStreamFromURController worksheet: Added Package-Type "Safety Data", since it was missing. Not
		PLN	Added	Change log sheet
	3.2	PLN	Corrected	ROBOT_MODE_DATA - added 8 bytes correspond to "targetSpeedFractionLimit"
	3.2	PLN	Corrected	MASTERBOARD_DATA - added 2 bytes correspond to "operationalModeSelectorInput" and "threePositi
	3.3	PLN	Corrected	In Additional Info

Retur til index

of the problem for the better debugging feature
e, the package contents are not described on purpose.

```
onEnablingDeviceInput"
```

1.6

[Retur til index](#)

Primary and secondary client

The robot state message contain several packages as seen below.

NOTE:

- Not every robot state message may necessarily contain all of the packages described.
- Therefore, it is a good idea to test the package type chars, to see what packages are included in the message.
- Not all package types are documented here.
- Only the message type "ROBOT_STATE" is documented here (messageType value is 16)

int messageSize (total size including robot mode data, joint data, cartesian info, kinematics info, masterboard data, tool data, configuration data)

unsigned char messageType = ROBOT_STATE = 16

This page describes the data sent from the robot controller:

[DataStreamFromURController](#)

Robot mode data

int packageSize

unsigned char packageType = ROBOT_MODE_DATA = 0

uint64_t timestamp

bool isRobotConnected

bool isRealRobotEnabled

bool isPowerOnRobot

bool isEmergencyStopped

bool isSecurityStopped

bool isProgramRunning

bool isProgramPaused

unsigned char robotMode

double speedFraction

Joint data

int packageSize

unsigned char packageType = JOINT_DATA = 1

for each joint:

double q_actual

double q_target

double qd_actual

float I_actual

float V_actual

float T_motor

float T_micro

unsigned char jointMode

end

The "jointMode" field is a code for the joint status (shown on the initialisation screen):

[JointModes](#)

Cartesian info

int packageSize

unsigned char = CARTESIAN_INFO = 4

double X

double Y

double Z

double Rx

double Ry

double Rz

Masterboard data

int packageSize

unsigned char packageType = MASTERBOARD_DATA = 3

short digitalInputBits

short digitalOutputBits

char analogInputRange0

char analogInputRange1

The "source" field is a code for the sender of the message:

[MessageSources](#)

VersionMessage - first package only

int messageSize

unsigned char messageType = ROBOT_MESSAGE = 20

uint64_t timestamp

char source

char robotMessageType = ROBOT_MESSAGE_VERSION = 3

char projectNameSize

char array projectName

unsigned char majorVersion

unsigned char minorVersion

int svnRevision

char array buildDate

Zero or more of the following messages:

SecurityMessage

int messageSize

unsigned char messageType = ROBOT_MESSAGE = 20

uint64_t timestamp

char source

char robotMessageType = ROBOT_MESSAGE_SECURITY = 5

int robotMessageCode

int robotMessageArgument

char array textMessage

RobotcommMessage

int messageSize

unsigned char messageType = ROBOT_MESSAGE = 20

uint64_t timestamp

char source

char robotMessageType = ROBOT_MESSAGE_ERROR_CODE = 6


```
int robotMessageCode
int robotMessageArgument
char array textMessage
```

KeyMessage

```
int messageSize
unsigned char messageType = ROBOT_MESSAGE = 20
uint64_t timestamp
char source
char robotMessageType = ROBOT_MESSAGE_KEY = 7
int robotMessageCode
int robotMessageArgument
unsigned char titleSize
char array messageTitle
char array textMessage
```

LabelMessage

```
int messageSize
unsigned char messageType = ROBOT_MESSAGE = 20
uint64_t timestamp
char source
char robotMessageType = ROBOT_MESSAGE_PROGRAM_LABEL = 1
int id
char array textMessage
```

PopupMessage

```
int messageSize
unsigned char messageType = ROBOT_MESSAGE = 20
uint64_t timestamp
char source
char robotMessageType = ROBOT_MESSAGE_POPUP = 2
bool warning
bool error
```

unsigned char titleSize
char array messageTitle
char array textMessage

RequestValueMessage

int messageSize
unsigned char messageType = ROBOT_MESSAGE = 20
uint64_t timestamp
char source
char robotMessageType = ROBOT_MESSAGE_REQUEST_* = 0-8
unsigned int requestId
char array textMessage

TextMessage

int messageSize
unsigned char messageType = ROBOT_MESSAGE = 20
uint64_t timestamp
char source
char robotMessageType = ROBOT_MESSAGE_TEXT = 0
char array textMessage

VarMessage

int messageSize
unsigned char messageType = ROBOT_MESSAGE = 20
uint64_t timestamp
char source
char robotMessageType = ROBOT_MESSAGE_VARIABLE = 8
int code
int argument
unsigned char titleSize
char array messageTitle
char array messageText

Example of data recieved:	Example				
---------------------------	-------------------------	--	--	--	--

1.7

[Retur til index](#)

Primary and secondary client

The robot state message contain several packages as seen below.

NOTE:

- Not every robot state message may necessarily contain all of the packages described.
- Therefore, it is a good idea to test the package type chars, to see what packages are included in the message.
- Not all package types are documented here.
- Only the message type "ROBOT_STATE" is documented here (messageType value is 16)

int messageSize (total size including robot mode data, joint data, cartesian info, kinematics info, masterboard data, tool data, configuration data)

unsigned char messageType = ROBOT_STATE = 16

This page describes the data sent from the robot controller:

[DataStreamFromURController](#)

Robot mode data

int packageSize

unsigned char packageType = ROBOT_MODE_DATA = 0

uint64_t timestamp

bool isRobotConnected

bool isRealRobotEnabled

bool isPowerOnRobot

bool isEmergencyStopped

bool isSecurityStopped

bool isProgramRunning

bool isProgramPaused

unsigned char robotMode

double speedFraction

Joint data

int packageSize

unsigned char packageType = JOINT_DATA = 1

for each joint:

double q_actual

double q_target

double qd_actual

float I_actual

float V_actual

float T_motor

float T_micro

unsigned char jointMode

end

The "jointMode" field is a code for the joint status (shown on the initialisation screen):

[JointModes](#)

Cartesian info

int packageSize

unsigned char = CARTESIAN_INFO = 4

double X

double Y

double Z

double Rx

double Ry

double Rz

Masterboard data

int packageSize

unsigned char packageType = MASTERBOARD_DATA = 3

short digitalInputBits

short digitalOutputBits

char analogInputRange0

char analogInputRange1

The "source" field is a code for the sender of the message:

[MessageSources](#)

VesionMessage - first package only

int messageSize

unsigned char messageType = ROBOT_MESSAGE = 20

uint64_t timestamp

char source

char robotMessageType = ROBOT_MESSAGE_VERSION = 3

char projectNameSize

char array projectName

unsigned char majorVersion

unsigned char minorVersion

int svnRevision

char array buildDate

Zero or more of the following messages:

SecurityMessage

int messageSize

unsigned char messageType = ROBOT_MESSAGE = 20

uint64_t timestamp

char source

char robotMessageType = ROBOT_MESSAGE_SECURITY = 5

int robotMessageCode

int robotMessageArgument

char array textMessage

RobotcommMessage

int messageSize

unsigned char messageType = ROBOT_MESSAGE = 20

uint64_t timestamp

char source

char robotMessageType = ROBOT_MESSAGE_ERROR_CODE = 6

```
int robotMessageCode
int robotMessageArgument
char array textMessage
```

KeyMessage

```
int messageSize
unsigned char messageType = ROBOT_MESSAGE = 20
uint64_t timestamp
char source
char robotMessageType = ROBOT_MESSAGE_KEY = 7
int robotMessageCode
int robotMessageArgument
unsigned char titleSize
char array messageTitle
char array textMessage
```

LabelMessage

```
int messageSize
unsigned char messageType = ROBOT_MESSAGE = 20
uint64_t timestamp
char source
char robotMessageType = ROBOT_MESSAGE_PROGRAM_LABEL = 1
int id
char array textMessage
```

PopupMessage

```
int messageSize
unsigned char messageType = ROBOT_MESSAGE = 20
uint64_t timestamp
char source
char robotMessageType = ROBOT_MESSAGE_POPUP = 2
bool warning
bool error
```



```
unsigned char titleSize  
char array messageTitle  
char array textMessage
```

RequestValueMessage

```
int messageSize  
unsigned char messageType = ROBOT_MESSAGE = 20  
uint64_t timestamp  
char source  
char robotMessageType = ROBOT_MESSAGE_REQUEST_* = 0-8  
unsigned int requestId  
char array textMessage
```

TextMessage

```
int messageSize  
unsigned char messageType = ROBOT_MESSAGE = 20  
uint64_t timestamp  
char source  
char robotMessageType = ROBOT_MESSAGE_TEXT = 0  
char array textMessage
```

VarMessage

```
int messageSize  
unsigned char messageType = ROBOT_MESSAGE = 20  
uint64_t timestamp  
char source  
char robotMessageType = ROBOT_MESSAGE_VARIABLE = 8  
int code  
int argument  
unsigned char titleSize  
char array messageTitle  
char array messageText
```

Example of data recieved:	Example					
---------------------------	-------------------------	--	--	--	--	--

1.8

[Retur til index](#)

Primary and secondary client

The robot state message contain several packages as seen below.

NOTE:

- Not every robot state message may necessarily contain all of the packages described.
- Therefore, it is a good idea to test the package type chars, to see what packages are included in the message.
- Not all package types are documented here.
- Only the message type "ROBOT_STATE" is documented here (messageType value is 16)

int messageSize (total size including robot mode data, joint data, cartesian info, kinematics info, masterboard data, tool data, configuration data)

unsigned char messageType = ROBOT_STATE = 16

This page describes the data sent from the robot controller:

[DataStreamFromURController](#)

Robot mode data

int packageSize

unsigned char packageType = ROBOT_MODE_DATA = 0

uint64_t timestamp

bool isRobotConnected

bool isRealRobotEnabled

bool isPowerOnRobot

bool isEmergencyStopped

bool isSecurityStopped

bool isProgramRunning

bool isProgramPaused

unsigned char robotMode

double speedFraction

Joint data

int packageSize

unsigned char packageType = JOINT_DATA = 1

for each joint:

double q_actual

double q_target

double qd_actual

float I_actual

float V_actual

float T_motor

float T_micro

unsigned char jointMode

end

The "jointMode" field is a code for the joint status (shown on the initialisation screen):

[JointModes](#)

Cartesian info

int packageSize

unsigned char = CARTESIAN_INFO = 4

double X

double Y

double Z

double Rx

double Ry

double Rz

Masterboard data

int packageSize

unsigned char packageType = MASTERBOARD_DATA = 3

short digitalInputBits

short digitalOutputBits

char analogInputRange0

char analogInputRange1

int packageSize

unsigned char packageType = KINEMATICS_INFO = 5

This package contains a checksum for the specific robot. It might be subject of change in the near future

Configuration data

int packageSize

unsigned char packageType = CONFIGURATION_DATA = 6

for each joint:

double jointMinLimit

double jointMaxLimit

for each joint:

double jointMaxSpeed

double jointMaxAcceleration

double vJointDefault

double aJointDefault

double vToolDefault

double aToolDefault

double eqRadius

for each joint:

double DHa

for each joint:

double DHd

for each joint:

double DHalpha

for each joint:

double DHtheta

int masterboardVersion

int controllerBoxType

int robotType

int robotSubType

for each joint:

int motorType

Force mode data

int packageSize

unsigned char = FORCE_MODE_DATA = 7

double X

double Y

double Z

double Rx

double Ry

double Rz

double robotDexterity

Additional info

int packageSize

unsigned char = ADDITIONAL_INFO = 8

bool teachButtonPressed

bool teachButtonEnabled

Calibration data

int packageSize

unsigned char packageType = CALIBRATION_DATA = 9

Below is only for primary client

The "source" field is a code for the sender of the message:

[MessageSources](#)

VesionMessage - first package only

int messageSize

unsigned char messageType = ROBOT_MESSAGE = 20

uint64_t timestamp

char source

char robotMessageType = ROBOT_MESSAGE_VERSION = 3

char projectNameSize
char array projectName
unsigned char majorVersion
unsigned char minorVersion
int svnRevision
char array buildDate

Zero or more of the following messages:

SecurityMessage

int messageSize
unsigned char messageType = ROBOT_MESSAGE = 20
uint64_t timestamp
char source
char robotMessageType = ROBOT_MESSAGE_SECURITY = 5
int robotMessageCode
int robotMessageArgument
char array textMessage

RobotcommMessage

int messageSize
unsigned char messageType = ROBOT_MESSAGE = 20
uint64_t timestamp
char source
char robotMessageType = ROBOT_MESSAGE_ERROR_CODE = 6
int robotMessageCode
int robotMessageArgument
char array textMessage

KeyMessage

int messageSize
unsigned char messageType = ROBOT_MESSAGE = 20
uint64_t timestamp

char source

char robotMessageType = ROBOT_MESSAGE_KEY = 7

int robotMessageCode

int robotMessageArgument

unsigned char titleSize

char array messageTitle

char array textMessage

LabelMessage

int messageSize

unsigned char messageType = ROBOT_MESSAGE = 20

uint64_t timestamp

char source

char robotMessageType = ROBOT_MESSAGE_PROGRAM_LABEL = 1

int id

char array textMessage

PopupMessage

int messageSize

unsigned char messageType = ROBOT_MESSAGE = 20

uint64_t timestamp

char source

char robotMessageType = ROBOT_MESSAGE_POPUP = 2

bool warning

bool error

unsigned char titleSize

char array messageTitle

char array textMessage

RequestValueMessage

int messageSize

unsigned char messageType = ROBOT_MESSAGE = 20

uint64_t timestamp

```
char source
char robotMessageType = ROBOT_MESSAGE_REQUEST_* = 0-8
unsigned int requestId
char array textMessage
```

TextMessage

```
int messageSize
unsigned char messageType = ROBOT_MESSAGE = 20
uint64_t timestamp
char source
char robotMessageType = ROBOT_MESSAGE_TEXT = 0
char array textMessage
```

VarMessage

```
int messageSize
unsigned char messageType = ROBOT_MESSAGE = 20
uint64_t timestamp
char source
char robotMessageType = ROBOT_MESSAGE_VARIABLE = 8
int code
int argument
unsigned char titleSize
char array messageTitle
char array messageText
```

Example of data recieved:

[Example](#)

3.0

[Retur til index](#)

Primary and secondary client

The robot state message contain several packages as seen below.

NOTE:

- Not every robot state message may necessarily contain all of the packages described.
- Therefore, it is a good idea to test the package type chars, to see what packages are included in the message.
- Not all package types are documented here.
- Only the message type "ROBOT_STATE" is documented here (messageType value is 16)

int messageSize (total size including robot mode data, joint data, cartesian info, kinematics info, masterboard data, tool data, configuration data)

unsigned char messageType = ROBOT_STATE = 16

This page describes the data sent from the robot controller:

[DataStreamFromURController](#)

Robot mode data

int packageSize

unsigned char packageType = ROBOT_MODE_DATA = 0

uint64_t timestamp

bool isRobotConnected

bool isRealRobotEnabled

bool isPowerOnRobot

bool isEmergencyStopped

bool isProtectiveStopped

bool isProgramRunning

bool isProgramPaused

unsigned char robotMode

unsigned char controlMode

double targetSpeedFraction

double speedScaling

Joint data

```
int packageSize
unsigned char packageType = JOINT_DATA = 1
for each joint:
double q_actual
double q_target
double qd_actual
float I_actual
float V_actual
float T_motor
float T_micro
unsigned char jointMode
end
```

The "jointMode" field is a code for the joint status (shown on the initialisation screen):

[JointModes](#)

Cartesian info

```
int packageSize
unsigned char = CARTESIAN_INFO = 4
double X
double Y
double Z
double Rx
double Ry
double Rz
```

Masterboard data

```
int packageSize
unsigned char packageType = MASTERBOARD_DATA = 3
int digitalInputBits
int digitalOutputBits
char analogInputRange0
```

char analogInputRange1
double analogInput0
double analogInput1
char analogOutputDomain0
char analogOutputDomain1
double analogOutput0
double analogOutput1
float masterBoardTemperature
float robotVoltage48V
float robotCurrent
float masterIOCurrent
unsigned char safetyMode
unsigned char InReducedMode
char euromap67InterfaceInstalled
(if euromap67 interface is installed, also the following:
int euromapInputBits
int euromapOutputBits
float euromapVoltage
float euromapCurrent)
uint32_t (Used by Universal Robots software only)
Tool data
int packageSize
unsigned char packageType = TOOL_DATA = 2
char analogInputRange2
char analogInputRange3
double analogInput2
double analogInput3
float toolVoltage48V
unsigned char toolOutputVoltage
float toolCurrent
float toolTemperature
unsigned char toolMode

Kinematics info

int packageSize

unsigned char packageType = KINEMATICS_INFO = 5

This package contains a checksum for the specific robot. It might be subject of change in the near future.

Configuration data

int packageSize

unsigned char packageType = CONFIGURATION_DATA = 6

for each joint:

double jointMinLimit

double jointMaxLimit

for each joint:

double jointMaxSpeed

double jointMaxAcceleration

double vJointDefault

double aJointDefault

double vToolDefault

double aToolDefault

double eqRadius

for each joint:

double DHa

for each joint:

double DHd

for each joint:

double DHalpha

for each joint:

double DHtheta

int masterboardVersion

int controllerBoxType

int robotType

int robotSubType

Force mode data

int packageSize

unsigned char = FORCE_MODE_DATA = 7

double X

double Y

double Z

double Rx

double Ry

double Rz

double robotDexterity

Additional info

int packageSize

unsigned char = ADDITIONAL_INFO = 8

bool teachButtonPressed

bool teachButtonEnabled

Calibration data

int packageSize

unsigned char packageType = CALIBRATION_DATA = 9

This package is used internally by Universal Robots software only and should be skipped. It might be subject of change in the near future.

Below is only for primary client

The "source" field is a code for the sender of the message:

[MessageSources](#)

VesionMessage - first package only

int messageSize

unsigned char messageType = ROBOT_MESSAGE = 20

uint64_t timestamp

char source

```
char robotMessageType = ROBOT_MESSAGE_VERSION = 3
```

```
char projectNameSize
```

```
char array projectName
```

```
unsigned char majorVersion
```

```
unsigned char minorVersion
```

```
int svnRevision
```

```
char array buildDate
```

Zero or more of the following messages:

SafetyModeMessage

```
int messageSize
```

```
unsigned char messageType = ROBOT_MESSAGE = 20
```

```
uint64_t timestamp
```

char source

```
char robotMessageType = ROBOT_MESSAGE_SAFETY_MODE = 5
```

```
int robotMessageCode
```

```
int robotMessageArgument
```

char safetyModeType

```
char array textMessage
```

The "safetyModeType" field can contain the following values:

SafetyModeTypes

RobotcommMessage

```
int messageSize
```

```
unsigned char messageType = ROBOT_MESSAGE = 20
```

```
uint64_t timestamp
```

char source

```
char robotMessageType = ROBOT_MESSAGE_ERROR_CODE = 6
```

```
int robotMessageCode
```

```
int robotMessageArgument
```

```
int warningLevel
```


char array textMessage

The "warningLevel" field can contain the following values:

[WarningLevels](#)

KeyMessage

int messageSize

unsigned char messageType = ROBOT_MESSAGE = 20

uint64_t timestamp

char source

char robotMessageType = ROBOT_MESSAGE_KEY = 7

int robotMessageCode

int robotMessageArgument

unsigned char titleSize

char array messageTitle

char array textMessage

LabelMessage

int messageSize

unsigned char messageType = ROBOT_MESSAGE = 20

uint64_t timestamp

char source

char robotMessageType = ROBOT_MESSAGE_PROGRAM_LABEL = 1

int id

char array textMessage

RequestValueMessage

int messageSize

unsigned char messageType = ROBOT_MESSAGE = 20

uint64_t timestamp

char source

char robotMessageType = ROBOT_MESSAGE_REQUEST_VALUE = 9

unsigned int requestId

unsigned int requestedType = 0-8

(*) bool warning

(*) bool error

(*) bool blocking

(*) unsigned char titleLength

(*) char array messageTitle

char array textMessage

(*) Fields only included in this package, if the 'requestedType' field contains the value 8. This is the 'PopupMessage' type.

TextMessage

int messageSize

unsigned char messageType = ROBOT_MESSAGE = 20

uint64_t timestamp

char source

char robotMessageType = ROBOT_MESSAGE_TEXT = 0

char array textMessage

RuntimeExceptionMessage

int messageSize

unsigned char messageType = ROBOT_MESSAGE = 20

uint64_t timestamp

char source

char robotMessageType = ROBOT_MESSAGE_RUNTIME_EXCEPTION = 10

char array textMessage

VarMessage

int messageSize

unsigned char messageType = PROGRAM_STATE_MESSAGE = 25

uint64_t timestamp

char robotMessageType = PROGRAM_STATE_MESSAGE_VARIABLE_UPDATE = 2

unsigned char titleSize

char array messageTitle

char array messageText

Deprecated: Use the much more efficient 'GlobalVariablesSetupMessage' and 'GlobalVariablesUpdateMessage' (described below).

GlobalVariablesSetupMessage

int messageSize

unsigned char messageType = PROGRAM_STATE_MESSAGE = 25

uint64_t timestamp

char robotMessageType = PROGRAM_STATE_MESSAGE_GLOBAL_VARIABLES_SETUP = 0

unsigned short startIndex

(*) char array variableNames

(*) Each new line (terminated with the '\n' character) in the array contains the name of a variable.

GlobalVariablesUpdateMessage

int messageSize

unsigned char messageType = PROGRAM_STATE_MESSAGE = 25

uint64_t timestamp

char robotMessageType = PROGRAM_STATE_MESSAGE_GLOBAL_VARIABLES_UPDATE = 1

unsigned short startIndex

for each variable: (terminated with the '\n' character)

unsigned char valueType

One of following data chunks based on the value of 'valueType':

valueType = 'NONE_VAL':

// No content -> has not been initialized yet

valueType = 'STRING_VAL':

unsigned short valueLength

char array value

valueType = 'POSE_VAL':

float x

float y

float z

float rx

float ry

float rz									
valueType = 'BOOL_VAL':									
bool value									
valueType = 'INT_VAL':									
int value									
valueType = 'FLOAT_VAL':									
float value									
valueType = 'LIST_VAL':									
unsigned short listLength									
for each item in the list:									
unsigned char valueType									
The data for that type									
The relevant values for the "valueType" field are:					ValueTypes				
The information for each variable is on a new line (terminated with the '\n' character).									
Example of data recieved:					Example				

3.1

[Retur til index](#)

Primary and secondary client

The robot state message contain several packages as seen below.

NOTE:

- Not every robot state message may necessarily contain all of the packages described.
- Therefore, it is a good idea to test the package type chars, to see what packages are included in the message.
- Not all package types are documented here.
- Only the message type "ROBOT_STATE" is documented here (messageType value is 16)

int messageSize (total size including robot mode data, joint data, cartesian info, kinematics info, masterboard data, tool data, configuration data)

unsigned char messageType = ROBOT_STATE = 16

This page describes the data sent from the robot controller:

[DataStreamFromURController](#)

Robot mode data

int packageSize

unsigned char packageType = ROBOT_MODE_DATA = 0

uint64_t timestamp

bool isRobotConnected

bool isRealRobotEnabled

bool isPowerOnRobot

bool isEmergencyStopped

bool isProtectiveStopped

bool isProgramRunning

bool isProgramPaused

unsigned char robotMode

unsigned char controlMode

double targetSpeedFraction

double speedScaling

Joint data

```
int packageSize
unsigned char packageType = JOINT_DATA = 1
for each joint:
double q_actual
double q_target
double qd_actual
float I_actual
float V_actual
float T_motor
float T_micro
unsigned char jointMode
end
```

The "jointMode" field is a code for the joint status (shown on the initialisation screen):

[JointModes](#)

Cartesian info

```
int packageSize
unsigned char = CARTESIAN_INFO = 4
double X
double Y
double Z
double Rx
double Ry
double Rz
double TCPOffsetX
double TCPOffsetY
double TCPOffsetZ
double TCPOffsetRx
double TCPOffsetRy
double TCPOffsetRz
```

Masterboard data

int packageSize

unsigned char packageType = MASTERBOARD_DATA = 3

int digitalInputBits

int digitalOutputBits

char analogInputRange0

char analogInputRange1

double analogInput0

double analogInput1

char analogOutputDomain0

char analogOutputDomain1

double analogOutput0

double analogOutput1

float masterBoardTemperature

float robotVoltage48V

float robotCurrent

float masterIOCurrent

unsigned char safetyMode

unsigned char InReducedMode

char euromap67InterfaceInstalled

(if euromap67 interface is installed, also the following:

int euromapInputBits

int euromapOutputBits

float euromapVoltage

float euromapCurrent)

uint32_t (Used by Universal Robots software only)

Tool data

int packageSize

unsigned char packageType = TOOL_DATA = 2

char analogInputRange2

char analogInputRange3

double analogInput2

double analogInput3	
float toolVoltage48V	
unsigned char toolOutputVoltage	
float toolCurrent	
float toolTemperature	
unsigned char toolMode	

Kinematics info

```
int packageSize
unsigned char packageType = KINEMATICS_INFO = 5
```

This package contains a checksum for the specific robot. It might be subject of change in the near future.

Configuration data

int packageSize			
unsigned char packageType = CONFIGURATION_DATA = 6			

```
for each joint:
```

double jointMinLimit

```
double jointMaxLimitt
```

```
for each joint:
```

```
double jointMaxSpeed
```

```
double jointMaxAcceleration
```

double vJointDefault

```
double aJointDefault
```

```
double vToolDefault
```

```
double aToolDefault
```

double eqRadius

```

for each joint:

```

double DHa

```

for each joint:

```

double DHd

```
for each joint:
```

double DHalp

for each joint:

double DHtheta

int masterboardVersion

int controllerBoxType

int robotType

int robotSubType

Force mode data

int packageSize

unsigned char = FORCE_MODE_DATA = 7

double X

double Y

double Z

double Rx

double Ry

double Rz

double robotDexterity

Additional info

int packageSize

unsigned char = ADDITIONAL_INFO = 8

bool teachButtonPressed

bool teachButtonEnabled

Calibration data

int packageSize

unsigned char packageType = CALIBRATION_DATA = 9

This package is used internally by Universal Robots software only and should be skipped. It might be subject of change in the near future.

VesionMessage - first package only

This is the first package sent on both the primary and secondary client interfaces. This package is not part of the robot state message.

int messageSize

unsigned char messageType = ROBOT_MESSAGE = 20

uint64_t timestamp

char source

char robotMessageType = ROBOT_MESSAGE_VERSION = 3

char projectNameSize

char array projectName

unsigned char majorVersion

unsigned char minorVersion

int svnRevision

char array buildDate

Below is only for primary client

The "source" field is a code for the sender of the message:

[MessageSources](#)

Zero or more of the following messages:

SafetyModeMessage

int messageSize

unsigned char messageType = ROBOT_MESSAGE = 20

uint64_t timestamp

char source

char robotMessageType = ROBOT_MESSAGE_SAFETY_MODE = 5

int robotMessageCode

int robotMessageArgument

char safetyModeType

char array textMessage

The "safetyModeType" field can contain the following values:

[SafetyModeTypes](#)

RobotcommMessage

```
int messageSize
unsigned char messageType = ROBOT_MESSAGE = 20
uint64_t timestamp
char source
char robotMessageType = ROBOT_MESSAGE_ERROR_CODE = 6
int robotMessageCode
int robotMessageArgument
int warningLevel
char array textMessage
```

The "warningLevel" field can contain the following values:

[WarningLevels](#)

KeyMessage

```
int messageSize
unsigned char messageType = ROBOT_MESSAGE = 20
uint64_t timestamp
char source
char robotMessageType = ROBOT_MESSAGE_KEY = 7
int robotMessageCode
int robotMessageArgument
unsigned char titleSize
char array messageTitle
char array textMessage
```

LabelMessage

```
int messageSize
unsigned char messageType = ROBOT_MESSAGE = 20
uint64_t timestamp
char source
char robotMessageType = ROBOT_MESSAGE_PROGRAM_LABEL = 1
int id
char array textMessage
```

RequestValueMessage

int messageSize

unsigned char messageType = ROBOT_MESSAGE = 20

uint64_t timestamp

char source

char robotMessageType = ROBOT_MESSAGE_REQUEST_VALUE = 9

unsigned int requestId

unsigned int requestedType = 0-8

(*) bool warning

(*) bool error

(*) bool blocking

(*) unsigned char titleLength

(*) char array messageTitle

char array textMessage

(*) Fields only included in this package, if the 'requestedType' field contains the value 8. This is the 'PopupMessage' type.

TextMessage

int messageSize

unsigned char messageType = ROBOT_MESSAGE = 20

uint64_t timestamp

char source

char robotMessageType = ROBOT_MESSAGE_TEXT = 0

char array textMessage

RuntimeExceptionMessage

int messageSize

unsigned char messageType = ROBOT_MESSAGE = 20

uint64_t timestamp

char source

char robotMessageType = ROBOT_MESSAGE_RUNTIME_EXCEPTION = 10

char array textMessage

VarMessage

int messageSize

unsigned char messageType = PROGRAM_STATE_MESSAGE = 25

uint64_t timestamp

char robotMessageType = PROGRAM_STATE_MESSAGE_VARIABLE_UPDATE = 2

unsigned char titleSize

char array messageTitle

char array messageText

Deprecated: Use the much more efficient 'GlobalVariablesSetupMessage' and 'GlobalVariablesUpdateMessage' (described below).

GlobalVariablesSetupMessage

int messageSize

unsigned char messageType = PROGRAM_STATE_MESSAGE = 25

uint64_t timestamp

char robotMessageType = PROGRAM_STATE_MESSAGE_GLOBAL_VARIABLES_SETUP = 0

unsigned short startIndex

(*) char array variableNames

(*) Each new line (terminated with the '\n' character) in the array contains the name of a variable.

GlobalVariablesUpdateMessage

int messageSize

unsigned char messageType = PROGRAM_STATE_MESSAGE = 25

uint64_t timestamp

char robotMessageType = PROGRAM_STATE_MESSAGE_GLOBAL_VARIABLES_UPDATE = 1

unsigned short startIndex

for each variable: (terminated with the '\n' character)

unsigned char valueType

One of following data chunks based on the value of 'valueType':

valueType = 'NONE_VAL':

// No content -> has not been initialized yet

valueType = 'STRING_VAL':

unsigned short valueLength:									
char array value									
valueType = 'POSE_VAL':									
float x									
float y									
float z									
float rx									
float ry									
float rz									
valueType = 'BOOL_VAL':									
bool value									
valueType = 'INT_VAL':									
int value									
valueType = 'FLOAT_VAL':									
float value									
valueType = 'LIST_VAL':									
unsigned short listLength									
for each item in the list:									
unsigned char valueType									
The data for that type									
The relevant values for the "valueType" field are:					ValueTypes				
The information for each variable is on a new line (terminated with the '\n' character).									
Example of data recieved:					Example				

3.2

[Retur til index](#)

Primary and secondary client

The robot state message contain several packages as seen below.

NOTE:

- Not every robot state message may necessarily contain all of the packages described.
- Therefore, it is a good idea to test the package type chars, to see what packages are included in the message.
- Not all package types are documented here.
- Only the message type "ROBOT_STATE" is documented here (messageType value is 16)

int messageSize (total size including robot mode data, joint data, cartesian info, kinematics info, masterboard data, tool data, configuration data)

unsigned char messageType = ROBOT_STATE = 16

This page describes the data sent from the robot controller:

[DataStreamFromURController](#)

Robot mode data

int packageSize

unsigned char packageType = ROBOT_MODE_DATA = 0

uint64_t timestamp

bool isRobotConnected

bool isRealRobotEnabled

bool isPowerOnRobot

bool isEmergencyStopped

bool isProtectiveStopped

bool isProgramRunning

bool isProgramPaused

unsigned char robotMode

unsigned char controlMode

double targetSpeedFraction

double speedScaling

double targetSpeedFractionLimit

Joint data

int packageSize

unsigned char packageType = JOINT_DATA = 1

for each joint:

double q_actual

double q_target

double qd_actual

float I_actual

float V_actual

float T_motor

float T_micro

unsigned char jointMode

end

The "jointMode" field is a code for the joint status (shown on the initialisation screen):

[JointModes](#)

Cartesian info

int packageSize

unsigned char = CARTESIAN_INFO = 4

double X

double Y

double Z

double Rx

double Ry

double Rz

double TCPOffsetX

double TCPOffsetY

double TCPOffsetZ

double TCPOffsetRx

double TCPOffsetRy

double TCPOffsetRz

Masterboard data

int packageSize

unsigned char packageType = MASTERBOARD_DATA = 3

int digitalInputBits

int digitalOutputBits

char analogInputRange0

char analogInputRange1

double analogInput0

double analogInput1

char analogOutputDomain0

char analogOutputDomain1

double analogOutput0

double analogOutput1

float masterBoardTemperature

float robotVoltage48V

float robotCurrent

float masterIOCurrent

unsigned char safetyMode

unsigned char InReducedMode

char euromap67InterfaceInstalled

(if euromap67 interface is installed, also the following:

int euromapInputBits

int euromapOutputBits

float euromapVoltage

float euromapCurrent)

uint32_t (Used by Universal Robots software only)

uint8_t operationalModeSelectorInput

uint8_t threePositionEnablingDeviceInput

Tool data

int packageSize

unsigned char packageType = TOOL_DATA = 2

for each joint:

double DHd

for each joint:

double DHalpha

for each joint:

double DHtheta

int masterboardVersion

int controllerBoxType

int robotType

int robotSubType

This information is sent when leaving initializing mode and/or if the kinematics configuration is changed.

Force mode data

int packageSize

unsigned char = FORCE_MODE_DATA = 7

unused double X

unused double Y

unused double Z

unused double Rx

unused double Ry

unused double Rz

double robotDexterity

Additional info

int packageSize

unsigned char = ADDITIONAL_INFO = 8

bool freedriveButtonPressed

bool freedriveButtonEnabled

bool IOEnabledFreedrive

Calibration data

int packageSize

unsigned char packageType = CALIBRATION_DATA = 9

This package is used internally by Universal Robots software only and should be skipped. It might be subject of change in the near future.

VersionMessage - first package only

This is the first package sent on both the primary and secondary client interfaces. This package is not part of the robot state message.

int messageSize

unsigned char messageType = ROBOT_MESSAGE = 20

uint64_t timestamp

char source

char robotMessageType = ROBOT_MESSAGE_VERSION = 3

char projectNameSize

char array projectName

unsigned char majorVersion

unsigned char minorVersion

int svnRevision

char array buildDate

Below is only for primary client

The "source" field is a code for the sender of the message:

[MessageSources](#)

Zero or more of the following messages:

SafetyModeMessage

int messageSize

unsigned char messageType = ROBOT_MESSAGE = 20

uint64_t timestamp

char source

char robotMessageType = ROBOT_MESSAGE_SAFETY_MODE = 5

int robotMessageCode

int robotMessageArgument

char safetyModeType
char array textMessage

The "safetyModeType" field can contain the following values:

[SafetyModeTypes](#)

RobotcommMessage

int messageSize
unsigned char messageType = ROBOT_MESSAGE = 20
uint64_t timestamp
char source
char robotMessageType = ROBOT_MESSAGE_ERROR_CODE = 6
int robotMessageCode
int robotMessageArgument
int warningLevel
char array textMessage

The "warningLevel" field can contain the following values:

[WarningLevels](#)

KeyMessage

int messageSize
unsigned char messageType = ROBOT_MESSAGE = 20
uint64_t timestamp
char source
char robotMessageType = ROBOT_MESSAGE_KEY = 7
int robotMessageCode
int robotMessageArgument
unsigned char titleSize
char array messageTitle
char array textMessage

LabelMessage

int messageSize
unsigned char messageType = ROBOT_MESSAGE = 20

```
uint64_t timestamp
char source
char robotMessageType = ROBOT_MESSAGE_PROGRAM_LABEL = 1
int id
char array textMessage
```

RequestValueMessage

```
int messageSize
unsigned char messageType = ROBOT_MESSAGE = 20
uint64_t timestamp
char source
char robotMessageType = ROBOT_MESSAGE_REQUEST_VALUE = 9
unsigned int requestId
unsigned int requestedType = 0-8
(*) bool warning
(*) bool error
(*) bool blocking
(*) unsigned char titleLength
(*) char array messageTitle
char array textMessage
```

(*) Fields only included in this package, if the 'requestedType' field contains the value 8. This is the 'PopupMessage' type.

TextMessage

```
int messageSize
unsigned char messageType = ROBOT_MESSAGE = 20
uint64_t timestamp
char source
char robotMessageType = ROBOT_MESSAGE_TEXT = 0
char array textMessage
```

RuntimeExceptionMessage

```
int messageSize
```

unsigned char messageType = ROBOT_MESSAGE = 20

uint64_t timestamp

char source

char robotMessageType = ROBOT_MESSAGE_RUNTIME_EXCEPTION = 10

char array textMessage

VarMessage

int messageSize

unsigned char messageType = PROGRAM_STATE_MESSAGE = 25

uint64_t timestamp

char robotMessageType = PROGRAM_STATE_MESSAGE_VARIABLE_UPDATE = 2

unsigned char titleSize

char array messageTitle

char array messageText

Deprecated: Use the much more efficient 'GlobalVariablesSetupMessage' and 'GlobalVariablesUpdateMessage' (described below).

GlobalVariablesSetupMessage

int messageSize

unsigned char messageType = PROGRAM_STATE_MESSAGE = 25

uint64_t timestamp

char robotMessageType = PROGRAM_STATE_MESSAGE_GLOBAL_VARIABLES_SETUP = 0

unsigned short startIndex

(*) char array variableNames

(*) Each new line (terminated with the '\n' character) in the array contains the name of a variable.

GlobalVariablesUpdateMessage

int messageSize

unsigned char messageType = PROGRAM_STATE_MESSAGE = 25

uint64_t timestamp

char robotMessageType = PROGRAM_STATE_MESSAGE_GLOBAL_VARIABLES_UPDATE = 1

unsigned short startIndex

for each variable: (terminated with the '\n' character)	
unsigned char valueType	
One of following data chunks based on the value of 'valueType':	
valueType = 'NONE_VAL':	
// No content -> has not been initialized yet	
valueType = 'STRING_VAL':	
unsigned short valueLength	
char array value	
valueType = 'POSE_VAL':	
float x	
float y	
float z	
float rx	
float ry	
float rz	
valueType = 'BOOL_VAL':	
bool value	
valueType = 'INT_VAL':	
int value	
valueType = 'FLOAT_VAL':	
float value	
valueType = 'LIST_VAL':	
unsigned short listLength	
for each item in the list:	
unsigned char valueType	
The data for that type	
The relevant values for the "valueType" field are: ValueTypes	
The information for each variable is on a new line (terminated with the '\n' character).	
Example of data recieved: Example	

3.3

[Retur til index](#)

Primary and secondary client

The following messages have been changed with respect to the previous major software release 3.2

Please consult SW3.2 documentation for all other packages.

VesionMessage - first package only

This is the first package sent on both the primary and secondary client interfaces. This package it not part of the robot state message.

int messageSize

unsigned char messageType = ROBOT_MESSAGE = 20

uint64_t timestamp

char source

char robotMessageType = ROBOT_MESSAGE_VERSION = 3

char projectNameSize

char array projectName

unsigned char majorVersion

[illegible]

3.4

[Retur til index](#)

Primary and secondary client

The following messages have been changed with respect to the previous major software release 3.3

Please consult SW3.3 documentation for all other packages.

RuntimeExceptionMessage

int messageSize

unsigned char messageType = ROBOT_MESSAGE = 20

uint64_t timestamp

char source

char robotMessageType = ROBOT_MESSAGE_RUNTIME_EXCEPTION = 10

uint32 lineNumber

uint32 columnNumber

char array textMessage

[Retur til index](#)

Secondary client communications interface

The secondary client communications interface is found at TCP port 30002.

Scheme

4 bytes (int)	Length of overall package
1 byte (uchar)	Robot MessageType
4 bytes (int)	Length of Sub-Package
1 byte (uchar)	Package-Type
n bytes	Content...
4 bytes	Length of Sub-Package
1 byte	Package-Type
n bytes	Content...
	...


Length of overall package: total length of package including itself

Robot MessageType: only value 16 ("Robot State")

Length of Sub-Package: total length of subpackage including itself

Package-Type:

Possible types are:




value 0 ("Robot Mode Data")
 value 1 ("Joint Data")
 value 2 ("Tool Data")
 value 3 ("Masterboard Data")
 value 4 ("Cartesian Info")
 value 5 ("Kinematics Info")
 value 6 ("Configuration Data")
 value 7 ("Force Mode Data")
 value 8 ("Additional Info")
 value 9 ("Calibration Data")
 value 10 ("Safety Data")

Robot State package types

Robot Mode Data (value 0)

Size in bytes	Data type	Meaning	Notes
4	integer	Package length (bytes)	46 bytes
1	uchar	Package type	Type is 0 ("Robot Mode Data")
8	uint64	Timestamp	
1	boolean	PhysicalRobotConnected	
1	boolean	RealRobotEnabled	
1	boolean	RobotPowerOn	
1	boolean	EmergencyStopped	
1	boolean	ProtectiveStopped	
1	boolean	ProgramRunning	
1	boolean	ProgramPaused	
1	uchar	Robot Mode	See table Robot Modes
1	uchar	ControlMode	See table Control Modes
8	double	TargetSpeedFraction	
8	double	SpeedScaling	
8	double	TargetSpeedFractionLimit	From 3.2



Robot Modes


Mode	Description
0	ROBOT_MODE_DISCONNECTED
1	ROBOT_MODE_CONFIRM_SAFETY
2	ROBOT_MODE_BOOTING
3	ROBOT_MODE_POWER_OFF
4	ROBOT_MODE_POWER_ON
5	ROBOT_MODE_IDLE
6	ROBOT_MODE_BACKDRIVE
7	ROBOT_MODE_RUNNING
8	ROBOT_MODE_UPDATING_FIRMWARE

Control Modes


Mode	Description
0	CONTROL_MODE_POSITION
1	CONTROL_MODE_TEACH
2	CONTROL_MODE_FORCE
3	CONTROL_MODE_TORQUE

Joint Data (value 1)

Size in bytes	Data type	Meaning	Notes
4	integer	Package length (bytes)	251 bytes
1	uchar	Package type	Type is 1 ("Joint Data")
			All following 8 values for each joint (6x):
8	double	q actual	Actual joint position
8	double	q target	Target joint position
8	double	qd actual	Actual joint speed
4	float	I actual	Actual joint current
4	float	V actual	Actual joint voltage
4	float	T motor	Joint motor temperature
4	float	T micro	Don't use, obsolete



1	uchar	Joint Mode	See table Joint Modes	
Joint Modes				
Mode (uchar)	Description			
236	JOINT_SHUTTING_DOWN_MODE			
237	JOINT_PART_D_CALIBRATION_MODE			
238	JOINT_BACKDRIVE_MODE			
239	JOINT_POWER_OFF_MODE			
245	JOINT_NOT_RESPONDING_MODE			
246	JOINT_MOTOR_INITIALISATION_MODE			
247	JOINT_BOOTING_MODE			
248	JOINT_PART_D_CALIBRATION_ERROR_MODE			
249	JOINT_BOOTLOADER_MODE			
250	JOINT_CALIBRATION_MODE			
252	JOINT_FAULT_MODE			
253	JOINT_RUNNING_MODE			
255	JOINT_IDLE_MODE			
Tool Data (value 2)				
Size in bytes	Data type	Meaning	Notes	
4	integer	Package length (bytes)	37 bytes	
1	uchar	Package type	Type is 2 ("Tool Data")	
1	char	AnalogInputRange2		
1	char	AnalogInputRange3		
8	double	AnalogInput2		
8	double	AnalogInput3		
4	float	ToolVoltage48V		
1	uchar	ToolOutputVoltage		
4	float	ToolCurrent		
4	float	ToolTemperature		
1	uchar	Tool Mode	(A subset of joint modes)	




Tool Modes	
Mode (uchar)	Description
249	TOOL_BOOTLOADER_MODE
253	TOOL_RUNNING_MODE
255	TOOL_IDLE_MODE

Mode (uchar)	Description
249	TOOL_BOOTLOADER_MODE
253	TOOL_RUNNING_MODE
255	TOOL_IDLE_MODE

[illegible]

Size in bytes	Data type	Meaning	Notes		
4	integer	Package length (bytes)	74 bytes (with Euromap: 88 bytes)		
1	uchar	Package type	Type is 3 ("Masterboard Data")		
4	integer	DigitalInputBits?			
4	integer	DigitalOutputBits?			
1	char	AnalogInputRange0?			
1	char	AnalogInputRange1?			
8	double	AnalogInput0?			
8	double	AnalogInput1?			
1	char	AnalogOutputDomain0?			
1	char	AnalogOutputDomain? 1			
8	double	AnalogOutput0?			
8	double	AnalogOutput1?			
4	float	MasterboardTemperature?			
4	float	RobotVoltage48V?			
4	float	RobotCurrent?			
4	float	MasterIOCurrent?			
1	uchar	Safetymode	See table SafetyMode		
1	uchar	InReducedMode?			
1	char	Euromap67Installed?			
4	integer	EuromapInputBits?	If Euromap67 is installed		
4	integer	EuromapOutputBits?	If Euromap67 is installed		
4	float	EuromapVoltage?	If Euromap67 is installed		
4	float	EuromapCurrent?	If Euromap67 is installed		
4	uint32		Used by Universal Robots software only		



1	uchar	OperationalModeSelectorInput	From 3.2		
1	uchar	ThreePositionEnablingDeviceInput	From 3.2		
SafetyMode					

State (uchar)	Description	Comment
1	SAFETY_MODE_NORMAL	
2	SAFETY_MODE_REDUCED	
3	SAFETY_MODE_PROTECTIVE_STOP	
4	SAFETY_MODE_RECOVERY	
5	SAFETY_MODE_SAFEGUARD_STOP	(SIO + SI1 + SBUS) Physical s-stop interface input
6	SAFETY_MODE_SYSTEM_EMERGENCY_STOP	(EA + EB + SBUS->Euromap67) Physical e-stop interface input activated
7	SAFETY_MODE_ROBOT_EMERGENCY_STOP	(EA + EB + SBUS->Screen) Physical e-stop interface input activated
8	SAFETY_MODE_VIOLATION	
9	SAFETY_MODE_FAULT	

Cartesian Info (value 4)					
--------------------------	--	--	--	--	--

Size in bytes	Data type	Meaning	Notes
4	integer	Package length (bytes)	101 bytes
1	uchar	Package type	type is 4 ("Cartesian Info")
8	double	X	Tool vector, X-value
8	double	Y	Tool vector, Y-value
8	double	Z	Tool vector, Z-value
8	double	Rx	Rx: Rotation vector representation of the tool orientation
8	double	Ry	Ry: Rotation vector representation of the tool orientation
8	double	Rz	Rz: Rotation vector representation of the tool orientation
8	double	TCPOffsetX?	TCP offset, X-value
8	double	TCPOffsetY?	TCP offset, Y-value
8	double	TCPOffsetZ?	TCP offset, Z-value
8	double	TCPOffsetRX?	TCP offset, Rx-value (Rotation vector representation of TCP orientatic
8	double	TCPOffsetRY?	TCP offset, Ry-value (Rotation vector representation of TCP orientatic
8	double	TCPOffsetRZ?	TCP offset, Rz-value (Rotation vector representation of TCP orientatic

[illegible]


Kinematics Info (value 5)

This package has a length of 225 bytes and contains a checksum for the specific robot.

It might be subject of change in the near future.

Configuration Data (value 6)

Size in bytes	Data type	Meaning	Notes
4	integer	Package length (bytes)	445 bytes
1	uchar	Package type	type is 6 ("Configuration Data")
			2 following values for each joint (6x):
8	double	JointMinLimit?	
8	double	JointMaxLimit?	
			2 following values for each joint (6x):
8	double	JointMaxSpeed?	
8	double	JointMaxAcceleration?	
8	double	VJointDefault?	Default speed limit
8	double	AJointDefault?	Default acceleration limit
8	double	VToolDefault?	Default tool speed limit
8	double	AToolDefault?	Default tool acceleration limit
8	double	EqRadius?	The characteristic size of the tool
			1 following value for each joint (6x):
8	double	DHa	DH parameter 'a'
			1 following value for each joint (6x):
8	double	DHd	DH parameter 'd'
			1 following value for each joint (6x):
8	double	DHalpha	DH parameter 'alpha'
			1 following value for each joint (6x):
8	double	DHtheta	DH parameter 'theta'



4	integer	MasterboardVersion?	
4	integer	ControllerBoxType?	
4	integer	RobotType?	
4	integer	RobotSubType?	
Force Mode Data (value 7)			
Size in bytes	Data type	Meaning	Notes
4	integer	Package length (bytes)	61 bytes
1	uchar	Package type	Type is 7 ("Force Mode Data")
8	double	X	Force mode frame, X-value
8	double	Y	Force mode frame, Y-value
8	double	Z	Force mode frame, Z-value
8	double	Rx	Force mode frame, Rx: Rotation vector
8	double	Ry	Force mode frame, Ry: Rotation vector
8	double	Rz	Force mode frame, Rz: Rotation vector
8	double	RobotDexterity?	TCP dexterity
Additional Info (value 8)			
Size in bytes	Data type	Meaning	Notes
4	integer	Package length (bytes)	8 bytes
1	uchar	Package type	Type is 8 ("Additional Info")
1	boolean	FreedriveButtonPressed	
1	boolean	FreedriveButtonEnabled	
1	boolean	IOEnabledFreedrive	
Calibration Data (value 9)			
This package has a length of 53 bytes. It is used internally by Universal Robots software only and should be skipped.			
It might be subject of change in the near future.			

Retur til index		
JOINT_SHUTTING_DOWN_MODE = 236;		
JOINT_PART_D_CALIBRATION_MODE = 237;		
JOINT_BACKDRIVE_MODE = 238;		
JOINT_POWER_OFF_MODE = 239;		
JOINT_NOT_RESPONDING_MODE = 245;		
JOINT_MOTOR_INITIALISATION_MODE = 246;		
JOINT_BOOTING_MODE = 247;		
JOINT_PART_D_CALIBRATION_ERROR_MODE = 248;		
JOINT_BOOTLOADER_MODE = 249;		
JOINT_CALIBRATION_MODE = 250;		
JOINT_FAULT_MODE = 252;		
JOINT_RUNNING_MODE = 253;		
JOINT_IDLE_MODE = 255;		

[Retur til index](#)

Each message sent has a "source" code for the sender of the message. The codes are:

Source is:

68: Euromap 2

67: Euromap 1

66: Teach Pendant 2

65: Teach Pendant 1

30: Safety Processor B

20: Safety Processor A

7: Controller

6: Tool

5: Wrist 3

4: Wrist 2

3: Wrist 1

2: Elbow

1: Shoulder

0: Base

-2: Robot Interface

-3: RTMachine

-4: Simulated Robot

-5: GUI

The message types are:

16: ROBOT_STATE

20: ROBOT_MESSAGE

22: HMC_MESSAGE

5: MODBUS_INFO_MESSAGE

Retur til index			
SAFETY_MODE_FAULT = 9;			
SAFETY_MODE_VIOLATION = 8;			
SAFETY_MODE_ROBOT_EMERGENCY_STOP = 7;			
SAFETY_MODE_SYSTEM_EMERGENCY_STOP = 6;			
SAFETY_MODE_SAFEGUARD_STOP = 5;			
SAFETY_MODE_RECOVERY = 4;			
SAFETY_MODE_PROTECTIVE_STOP = 3;			
SAFETY_MODE_REDUCED = 2;			
SAFETY_MODE_NORMAL = 1;			

Retur til index			
MESSAGE_WARNING_LEVEL_INFO = 1;			
MESSAGE_WARNING_LEVEL_WARNING = 2;			
MESSAGE_WARNING_LEVEL_VIOLATION = 3;			
MESSAGE_WARNING_LEVEL_FAULT = 4;			

Retur til index						
	Up to software 3.2		From software 3.3			
	NONE_VAL = 0;		NONE_VAL = 0,			
	STRING_VAL = 3;		CONST_STRING_VAL = 3,			
	LIST_VAL = 4;		VAR_STRING_VAL = 4,			
	POSE_VAL = 9;		LIST_VAL = 5,			
	BOOL_VAL = 11;		POSE_VAL = 10,			
	NUM_VAL = 12;		BOOL_VAL = 12,			
	INT_VAL = 13;		NUM_VAL = 13,			
	FLOAT_VAL = 14;		INT_VAL = 14,			
			FLOAT_VAL= 15,			

[Retur til index](#)

Example

Lets say the client has recieved this data:

Received 465 bytes.

Bytes: [0] [0] [1] [209] [16] [0] [0] [0] [29] [0] [0] [0] [0] [0] [0] [5] [7] [246] [1] [1] [1] [0] [0] [0] [0] [0] [63] [240] [0] [0] [0] [0] [0] [0] [0] [0]
[0] [251] [1] [64] [1] [78] [244] [77] [189] [249] [149] [64] [1] [78] [247] [89] [95] [104] [85] [0] [0] [0] [0] [0] [0] [0] [188] [220] [97] [3] [66] [62]
[0] [0] [66] [0] [102] [103] [66] [99] [153] [154] [253] [191] [246] [74] [170] [216] [242] [29] [102] [191] [246] [74] [178] [44] [92] [72] [137] [0] [0] [0] [0]
[0] [0] [0] [0] [192] [1] [106] [78] [66] [63] [153] [154] [66] [4] [204] [205] [66] [104] [0] [0] [253] [63] [253] [49] [202] [91] [202] [8] [64] [63] [253] [49]
[210] [233] [51] [16] [35] [0] [0] [0] [0] [0] [0] [0] [0] [191] [155] [135] [34] [66] [62] [0] [0] [65] [249] [153] [154] [66] [100] [0] [0] [253] [191] [220] [115]
[204] [104] [205] [239] [254] [191] [220] [118] [68] [109] [49] [34] [158] [0] [0] [0] [0] [0] [0] [0] [190] [60] [245] [109] [66] [63] [153] [154] [66] [25] [51]
[51] [66] [116] [204] [205] [253] [63] [242] [146] [224] [105] [231] [66] [209] [63] [242] [146] [65] [3] [193] [196] [156] [0] [0] [0] [0] [0] [0] [0] [190] [115]
[157] [190] [66] [62] [0] [0] [66] [21] [51] [51] [66] [119] [153] [154] [253] [191] [231] [207] [8] [215] [85] [22] [88] [191] [231] [206] [77] [130] [151] [190] [17]
[191] [146] [242] [158] [148] [114] [240] [57] [188] [224] [224] [96] [66] [68] [102] [103] [66] [37] [153] [154] [66] [127] [153] [154] [253] [0] [0] [0] [53] [4] [63]
[217] [153] [52] [224] [36] [238] [93] [191] [217] [153] [169] [67] [241] [211] [23] [63] [207] [255] [137] [8] [22] [253] [198] [63] [240] [0] [170] [111] [207] [54]
[176] [63] [243] [51] [88] [137] [58] [151] [217] [63] [201] [148] [119] [151] [70] [237] [237] [0] [0] [0] [29] [5] [64] [143] [64] [0] [0] [0] [0] [0] [64] [143] [64]
[0] [0] [0] [0] [0] [64] [143] [64] [0] [0] [0] [0] [0] [0] [0] [0] [61] [3] [0] [63] [0] [0] [0] [0] [63] [123] [129] [184] [27] [129] [184] [28] [63] [112] [225]
[14] [16] [225] [14] [17] [0] [0] [0] [0] [0] [0] [0] [0] [0] [0] [0] [0] [0] [0] [0] [66] [87] [51] [51] [66] [66] [0] [0] [62] [35] [215] [11] [61]
[241] [169] [253] [0] [0] [0] [37] [2] [0] [0] [63] [141] [83] [47] [180] [171] [196] [232] [63] [137] [46] [99] [102] [69] [149] [155] [66] [55] [51] [51] [0] [59]
[68] [155] [166] [66] [92] [0] [0] [253] [0]

So to start from the beginning:


[0],[0],[1],[209]: Length is $1 \cdot 256 + 209 = 465$

[16] Package type is "Robot State"

[0][0][0][29] First package length is 29

[0] Package type is 0: "Robot Mode Data"

[0] [0] [0] [0] [0] [5] [7] [246] Timestamp is 329718



[1] isRobotConnected True

[1] isRealRobotEnabled True

[1] isPowerOnRobot True

[0] isEmergencyStopped False

[0] isSecurityStopped False

[0] isProgramRunning False

[0] isProgramPaused False

[0] robot mode is 0

[63] [240] [0] [0] [0] [0] [0] [0] Speed fraction as a double

see http://en.wikipedia.org/wiki/Double-precision_floating-point_format

[0] [0] [0] [251] Second package length is 251

[1] Second package type is "joint data"

[64] [1] [78][244] [77] [189] [249] [149] Joint 0 position

[64] [1] [78] [247] [89] [95] [104] [85] Joint 0 target position

[0] [0] [0] [0] [0] [0] [0] [0] Joint 0 target speed

[188] [220] [97] [3] Joint 0 current

[66] [62] [0] [0] Joint 0 voltage

, network byte order

[66] [0] [102] [103]	Joint 0 motor temperature
[66] [99] [153] [154]	Joint 0 microprocessor temperature
[253]	Joint 0 joint mode
[191] [246] [74] [170] [216] [242] [29] [102]	Joint 1 position
... etc. ...	

Meaning	Type	Number of values	Size in bytes	Gnuplot columns	Notes
Message Size	integer	1	4		Total message length in bytes
Time	double	1	8	1	Time elapsed since the controller was started
q target	double	6	48	2 - 7	Target joint positions
qd target	double	6	48	8 - 13	Target joint velocities
qdd target	double	6	48	14 - 19	Target joint accelerations
I target	double	6	48	20 - 25	Target joint currents
M target	double	6	48	26 - 31	Target joint moments (torques)
q actual	double	6	48	32 - 37	Actual joint positions
qd actual	double	6	48	38 - 43	Actual joint velocities
I actual	double	6	48	44 - 49	Actual joint currents
Tool Accelerometer values	double	3	24	50 - 53	Tool x,y and z accelerometer values (software version 1.7)
Unused	double	15	120	54 - 67	Unused
TCP force	double	6	48	68 - 73	Generalised forces in the TCP
Tool vector	double	6	48	74 - 79	Cartesian coordinates of the tool: (x,y,z,rx,ry,rz), where rx, ry and rz is a rotation vector
TCP speed	double	6	48	80 - 85	Speed of the tool given in cartesian coordinates
Digital input bits	double	1	8	86	Current state of the digital inputs. NOTE: these are bits encoded as int64_t, e.g. a value of 1 means bit 0 is set
Motor temperatures	double	6	48	87 - 92	Temperature of each joint in degrees celcius
Controller Timer	double	1	8	93	Controller realtime thread execution time
Test value	double	1	8	94	A value used by Universal Robots software only
Robot Mode	double	1	8	95	Robot control mode (see PolyScopeProgramServer on the "How to" page)
Joint Modes	double	6	48	96-101	Joint control modes (see PolyScopeProgramServer on the "How to" page) (only from software version 1.7)
TOTAL		96	764		96 values in a 764 byte package (In software version there will be 101 values and 812 bytes)

r representation of the tool orientation
 e of 5 corresponds to bit 0 and bit 2 set high
 software version 1.8 and on)
 bytes)
 entries at leading up the 756th byte.

Return to Index									
Meaning	Type	Number of values	Size in bytes	Gnuplot col.	Notes				
Message Size	integer	1	4		Total message length in bytes				
Time	double	1	8	1	Time elapsed since the controller was started				
q target	double	6	48	2 - 7	Target joint positions				
qd target	double	6	48	8 - 13	Target joint velocities				
qdd target	double	6	48	14 - 19	Target joint accelerations				
I target	double	6	48	20 - 25	Target joint currents				
M target	double	6	48	26 - 31	Target joint moments (torques)				
q actual	double	6	48	32 - 37	Actual joint positions				
qd actual	double	6	48	38 - 43	Actual joint velocities				
I actual	double	6	48	44 - 49	Actual joint currents				
I control	double	6	48	50 - 55	Joint control currents				
Tool vector actual	double	6	48	56 - 61	Actual Cartesian coordinates of the tool: (x,y,z,rx,ry,rz)				
TCP speed actual	double	6	48	62 - 67	Actual speed of the tool given in Cartesian coordinate				
TCP force	double	6	48	68 - 73	Generalised forces in the TCP				
Tool vector target	double	6	48	74 - 79	Target Cartesian coordinates of the tool: (x,y,z,rx,ry,rz)				
TCP speed target	double	6	48	80 - 85	Target speed of the tool given in Cartesian coordinate				
Digital input bits	double	1	8	86	Current state of the digital inputs. NOTE: these are bit				
Motor temperatures	double	6	48	87 - 92	Temperature of each joint in degrees celsius				
Controller Timer	double	1	8	93	Controller realtime thread execution time				
Test value	double	1	8	94	A value used by Universal Robots software only				
Robot Mode	double	1	8	95	Robot mode	see	DataStreamFromURC		
Joint Modes	double	6	48	96-101	Joint control modes	see	DataStreamFromURC		
Safety Mode	double	1	8	102	Safety mode	see	DataStreamFromURC		
	double	6	48	103 - 108	Used by Universal Robots software only				
Tool Accelerometer values	double	3	24	109 - 111	Tool x,y and z accelerometer values (software version				
	double	6	48	112 - 117	Used by Universal Robots software only				
Speed scaling	double	1	8	118	Speed scaling of the trajectory limiter				
Linear momentum norm	double	1	8	119	Norm of Cartesian linear momentum				
	double	1	8	120	Used by Universal Robots software only				
	double	1	8	121	Used by Universal Robots software only				

), where rx, ry and rz is a rotation vector representation of the tool orientation
s

), where rx, ry and rz is a rotation vector representation of the tool orientation
s

ts encoded as int64_t, e.g. a value of 5 corresponds to bit 0 and bit 2 set high

[controller](#)
[controller](#) (only from software version 1.8 and on)
[controller](#)

1.7)

V main	double	1	8	122	Masterboard: Main voltage
V robot	double	1	8	123	Masterboard: Robot voltage (48V)
I robot	double	1	8	124	Masterboard: Robot current
V actual	double	6	48	125 - 130	Actual joint voltages
TOTAL		131	1044		131 values in a 1044 byte package

If it is experienced that less than 1044 bytes are received, the protocol for the actual received bytes also follows the structure listed above, only not containing the

entries at leading up the 1044th byte.

[Return to Index](#)

Meaning	Type	Number of values	Size in bytes	Gnuplot col.	Notes
Message Size	integer	1	4		Total message length in bytes
Time	double	1	8	1	Time elapsed since the controller was started
q target	double	6	48	2 - 7	Target joint positions
qd target	double	6	48	8 - 13	Target joint velocities
qdd target	double	6	48	14 - 19	Target joint accelerations
I target	double	6	48	20 - 25	Target joint currents
M target	double	6	48	26 - 31	Target joint moments (torques)
q actual	double	6	48	32 - 37	Actual joint positions
qd actual	double	6	48	38 - 43	Actual joint velocities
I actual	double	6	48	44 - 49	Actual joint currents
I control	double	6	48	50 - 55	Joint control currents
Tool vector actual	double	6	48	56 - 61	Actual Cartesian coordinates of the tool: (x,y,z,rx,ry,rz)
TCP speed actual	double	6	48	62 - 67	Actual speed of the tool given in Cartesian coordinate
TCP force	double	6	48	68 - 73	Generalised forces in the TCP
Tool vector target	double	6	48	74 - 79	Target Cartesian coordinates of the tool: (x,y,z,rx,ry,rz)
TCP speed target	double	6	48	80 - 85	Target speed of the tool given in Cartesian coordinate
Digital input bits	double	1	8	86	Current state of the digital inputs. NOTE: these are bit
Motor temperatures	double	6	48	87 - 92	Temperature of each joint in degrees celsius
Controller Timer	double	1	8	93	Controller realtime thread execution time
Test value	double	1	8	94	A value used by Universal Robots software only
Robot Mode	double	1	8	95	Robot mode see DataStreamFromURC
Joint Modes	double	6	48	96-101	Joint control modes see DataStreamFromURC
Safety Mode	double	1	8	102	Safety mode see DataStreamFromURC
	double	6	48	103 - 108	Used by Universal Robots software only
Tool Accelerometer values	double	3	24	109 - 111	Tool x,y and z accelerometer values (software version
	double	6	48	112 - 117	Used by Universal Robots software only
Speed scaling	double	1	8	118	Speed scaling of the trajectory limiter
Linear momentum norm	double	1	8	119	Norm of Cartesian linear momentum
	double	1	8	120	Used by Universal Robots software only
	double	1	8	121	Used by Universal Robots software only

), where rx, ry and rz is a rotation vector representation of the tool orientation
s

), where rx, ry and rz is a rotation vector representation of the tool orientation
s

ts encoded as int64_t, e.g. a value of 5 corresponds to bit 0 and bit 2 set high

[controller](#)
[controller](#) (only from software version 1.8 and on)
[controller](#)

1.7)

V main	double	1	8	122	Masterboard: Main voltage
V robot	double	1	8	123	Masterboard: Robot voltage (48V)
I robot	double	1	8	124	Masterboard: Robot current
V actual	double	6	48	125 - 130	Actual joint voltages
Digital outputs	double	1	8	131	Digital outputs
Program state	double	1	8	132	Program state
TOTAL		133	1060		133 values in a 1060 byte package

If it is experienced that less than 1060 bytes are received, the protocol for the actual received bytes also follows the structure listed above, only not containing th

the entries at leading up the 1060th byte.