



HSIO functions are defined by the BIOS source code,  
Cannot be changed in BIOS settings.

Before starting design, you should choose one of  
the available BIOS configurations on:  
<https://github.com/LattePandaTeam/LattePanda-Mu>  
Or contact techsupport for custom your BIOS

The default functions are defined as follows:

- HSI00: USB3.2 10Gbps
- HSI01: USB3.2 10Gbps
- HSI02: PCIe 3.0 x1
- HSI03: PCIe 3.0 x1

- HSI08: PCIe 3.0 x4 (Lane 0)
- HSI09: PCIe 3.0 x4 (Lane 1)
- HSI010: PCIe 3.0 x4 (Lane 2)
- HSI011: PCIe 3.0 x4 (Lane 3)

- HSI06: PCIe 3.0 x1

DDI/TCP functions are defined by the BIOS source code,  
Cannot be changed in BIOS settings.

Before starting design, you should choose one of  
the available BIOS configurations on:  
<https://github.com/LattePandaTeam/LattePanda-Mu>

The default functions are defined as follows:

- DDIA: eDP 1.4b (the 40Pin connector on the Mu)
- DDIB: HDMI 2.0
- TCP0: HDMI 2.0
- TCP1: USB TypeC (need external PD controller)



















