

SOFTWARE GUIDE

for LabEmbryoCam webserver v2.0



Contents

Setting up an experiment	2
Step-by-step overview	2
Guided walkthrough	2
Starting the webserver	2
Homing the motorised XYZ stage	2
Setting up camera and starting live stream	3
Using the manual controls to find and save desired positions	6
Set acquisition parameters and start acquisition	8

Setting up an experiment

Step-by-step overview

1. Starting the webserver
2. Homing the motorised XYZ stage
3. Setting up camera and starting live stream
4. Using manual controls to find and save desired positions
5. Set acquisition parameters and start acquisition

Guided walkthrough

Starting the webserver


Once you have powered on your system, you can start the LabEmbryoCam (LEC) webserver by double clicking the icon on the desktop or in the *Activities* panel:

Image required

A terminal window will automatically open followed by the FireFox browser with the webserver loaded. We can now proceed with getting the hardware set up for running an experiment.

Homing the motorised XYZ stage

The first step required in setting up any experiment with the LEC is to home the XYZ stage. This is essential to ensure that the correct origin is used when finding and creating positions. To do this, click the *Set Origin* button in the user interface - you may have to scroll down the page to find it:




Note

Before homing the stage, make sure there are no objects that could obstruct the movement of the stage. Also, make sure not to use the app whilst the stage is homing as this could interfere with the process.

Setting up camera and starting live stream

On startup of the LEC webserver the camera is already initiated, however the default settings typically need to be adjusted to record good quality video. Adjusting the camera settings can simply be achieved using the *Camera Settings* section of the user interface:




The following are descriptions for each camera setting:

- **Exposure:** The shutter speed at which the camera operates in milliseconds.
- **Contrast:** Contrast of the images acquired
- **Frame-rate:** The frame-rate at which videos are captured. Note that for high resolutions, such as 2048x2048, you will need to reduce exposure time below 10ms if you would like to achieve a frame-rate higher than 15-20fps. This is due to a hard limit set by the camera driver on raspberry pi.
- **Resolution:** Presets for resolution at which images will be captured.

For changes to the camera settings to take effect you must press the *Update* button at the bottom of the *Camera Settings* section.

On the right you will see section termed *Camera View*, here you can capture still images using the *Snap* button and start a live video stream using the *Start/Stop Stream* button:




Note that still image are interactive, so you can zoom in and out, and move the image to find an improved view. Before starting the next step, you may wish to start the live video stream for easily finding the animals or subjects you wish to record using the LEC.

Note


If you would like to change the camera settings you must exit the live stream before doing this so that your changes can take effect. Then when you have finished choosing your desired settings, press the Update Settings button before starting the live stream again.

Using the manual controls to find and save desired positions

The manual controls consist of the joystick (for controlling the X and Y movement of the stage) and also a pair of Z-axis buttons (for raising or lowering the Z axis). To enable the joystick and Z buttons, toggle the following switch in the user interface:



In conjunction with the camera live video stream, move the joystick and Z buttons to move the camera to a desired position. Once you have a position that you want, click the *Current* button in the xyz tab to record the current position:



This will add a position entry into the position list. Note that all columns and rows in the table are editable.

You can repeat this step until you have recorded all the positions you want. Once you have completed recording positions, the next step is to enter the parameters for the acquisition before starting the experiment.

The following are descriptions for each of the controls and components in the *XYZ controls and settings* section of the user interface:

- **Set Origin:** Press this button to home the stage at startup of the user interface
- **Manual Controls:** Click this switch to enable or disable the joystick and Z-axis buttons on the system.
- **Activate graph:** Enabling this switch will allow you to click on positions on the graph and then the stage will move to the select position. This can be an easy way to double-check all your positions are correct whilst you have a live stream open.


- **Dimension:** Enabling this switch can switch between 2D (as shown above) or 3D view, 3D view can be useful for checking the z axis positions.

- **Generate XY:** Options and parameters for generating multi-well positions based on the coordinates at position 'A1'.

- **Position list buttons:**


- **Current:** Press this button to retrieve the coordinates of the current position where the stage is at. A new entry will be added into the position list below where it can be edited further.

- **Replace:** Press this button to replace the coordinates of the selected position with those at the current position of the stage. This can be used to update a position if an animal has moved or gone out of focus. Note that you must select a position in the position list via clicking on the circle icon in the second column of the position list for the position you'd like to replace.

- **Position list table:** Position list where coordinates are recorded. The first column is for removing position entries from the list, simply click the  icon for the position you'd like to remove. The second column is to permit selection of specific position entries for updating their coordinates. Finally, columns X, Y, Z and *Label* are all editable similar to an excel spreadsheet.

Set acquisition parameters and start acquisition

The acquisition parameters can be found at the bottom of the page of the user interface in the *Acquisition* section:



Here are descriptions for each acquisition parameter:

- **Number of positions** - Whether you would like to capture footage for only the current position ('Single') or all the positions you have recorded ('Multiple').
- **Number of timepoints** - How many acquisition iterations you would like the system to complete. An iteration consists of capturing footage for the specified positions. Setting the acquisition interval allows us to set this process to complete every X minutes, where X would be the acquisition interval
- **Acquisition interval** - How long to wait between each timepoint in minutes.
- **Acquisition length** - How long to capture video for each position, at each timepoint.
- **Driver and Folder selection** - The full file path to the directory where you would like to save video. This can be selected using the *Select* button.

Once you have added in the your desired acquisition parameters, you can now start an acquisition using the *Start acquisition* button!