



Notes

1. Alternative Main Pin-20 to P1E4, instead of P2G4, MAY result in a cleaner TPS signal
2. "Handlebar switch right hand kill on-off and start", Hi Level #694605, from www.patternbikes.com
3. Map 1 : switch ON (right) : pin 19 LOW
4. Kill switch is active when it is in the RUN position ! The marking is wrong for the Tornado circuit.

Title			A
Tornado #922 AFR Tuner Wiring			
Size	Number	Revision	
A4		01	
Date:	20-Mar-2011	Sheet of	
File:	C:\Documents and Settings\errol\My Documents\Dropbox\Tornado\Wiring\AFR Tuner		

