

# USER GUIDE

## Trimble BD982 GNSS Receiver Module

Version 4.85  
Revision B  
October 2014



## Corporate Office

Trimble Navigation Limited  
Integrated Technologies  
510 DeGuigne Drive  
Sunnyvale, CA 94085  
USA  
[www.trimble.com/gnss-inertial](http://www.trimble.com/gnss-inertial)  
Email: [GNSSOEMSupport@trimble.com](mailto:GNSSOEMSupport@trimble.com)

## Legal Notices

© 2006–2014, Trimble Navigation Limited. All rights reserved.  
Trimble and the Globe & Triangle logo are trademarks of Trimble Navigation Limited, registered in the United States and in other countries. CMR+, EVEREST, Maxwell, and Zephyr are trademarks of Trimble Navigation Limited.  
Microsoft, Internet Explorer, Windows, and Windows Vista are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.  
All other trademarks are the property of their respective owners.  
Support for Galileo is developed under a license of the European Union and the European Space Agency (BD910/BD920/BD930/BD970/BD982/BX982).

## Release Notice

This is the October 2014 release (Revision B) of the BD982 GNSS Receiver Module User Guide. It applies to version 4.85 of the receiver firmware.

## LIMITED WARRANTY TERMS AND CONDITIONS

### Product Limited Warranty

Subject to the following terms and conditions, Trimble Navigation Limited (“Trimble”) warrants that for a period of one (1) year from date of purchase unless otherwise specified, this Trimble product (the “Product”) will substantially conform to Trimble’s publicly available specifications for the Product and that the hardware and any storage media components of the Product will be substantially free from defects in materials and workmanship.

### Product Software

Product software, whether built into hardware circuitry as firmware, provided as a standalone computer software product, embedded in flash memory, or stored on magnetic or other media, is licensed solely for use with or as an integral part of the Product and is not sold. If accompanied by a separate end user license agreement (“EULA”), use of any such software will be subject to the terms of such end user license agreement (including any differing limited warranty terms, exclusions, and limitations), which shall control over the terms and conditions set forth in this limited warranty.

### Software Fixes

During the limited warranty period you will be entitled to receive such Fixes to the Product software that Trimble releases and makes commercially available and for which it does not charge separately, subject to the procedures for delivery to purchasers of Trimble products generally. If you have purchased the Product from an authorized Trimble dealer rather than from Trimble directly, Trimble may, at its option, forward the software Fix to the Trimble dealer for final distribution to you. Minor Updates, Major Upgrades, new products, or substantially new software releases, as identified by Trimble, are expressly excluded from this update process and limited warranty. Receipt of software Fixes or other enhancements shall not serve to extend the limited warranty period.  
For purposes of this warranty the following definitions shall apply: (1) “Fix(es)” means an error correction or other update created to fix a previous software version that does not substantially conform to its Trimble specifications; (2) “Minor Update” occurs when enhancements are made to current features in a software program; and (3) “Major Upgrade” occurs when significant new features are added to software, or when a new product containing new features replaces the further development of a current product line. Trimble reserves the right to determine, in its sole discretion, what constitutes a Fix, Minor Update, or Major Upgrade.

### Warranty Remedies

If the Trimble Product fails during the warranty period for reasons covered by this limited warranty and you notify Trimble of such failure

during the warranty period, Trimble will repair OR replace the nonconforming Product with new, equivalent to new, or reconditioned parts or Product, OR refund the Product purchase price paid by you, at Trimble’s option, upon your return of the Product in accordance with Trimble’s product return procedures then in effect.

### How to Obtain Warranty Service

To obtain warranty service for the Product, please contact your local Trimble authorized dealer. Alternatively, you may contact Trimble to request warranty service by e-mailing your request to [GNSSOEMSupport@trimble.com](mailto:GNSSOEMSupport@trimble.com). Please be prepared to provide:

- your name, address, and telephone numbers
- proof of purchase
- a copy of this Trimble warranty
- a description of the nonconforming Product including the model number
- an explanation of the problem

The customer service representative may need additional information from you depending on the nature of the problem.

### Warranty Exclusions or Disclaimer

This Product limited warranty shall only apply in the event and to the extent that (a) the Product is properly and correctly installed, configured, interfaced, maintained, stored, and operated in accordance with Trimble’s applicable operator’s manual and specifications, and; (b) the Product is not modified or misused. This Product limited warranty shall not apply to, and Trimble shall not be responsible for, defects or performance problems resulting from (i) the combination or utilization of the Product with hardware or software products, information, data, systems, interfaces, or devices not made, supplied, or specified by Trimble; (ii) the operation of the Product under any specification other than, or in addition to, Trimble’s standard specifications for its products; (iii) the unauthorized installation, modification, or use of the Product; (iv) damage caused by: accident, lightning or other electrical discharge, fresh or salt water immersion or spray (outside of Product specifications); or exposure to environmental conditions for which the Product is not intended; (v) normal wear and tear on consumable parts (e.g., batteries); or (vi) cosmetic damage. Trimble does not warrant or guarantee the results obtained through the use of the Product, or that software components will operate error free.

**NOTICE REGARDING PRODUCTS EQUIPPED WITH TECHNOLOGY CAPABLE OF TRACKING SATELLITE SIGNALS FROM SATELLITE BASED AUGMENTATION SYSTEMS (SBAS) (WAAS/EGNOS, AND MSAS), OMNISTAR, GPS, MODERNIZED GPS OR GLONASS SATELLITES, OR FROM IALA BEACON SOURCES: TRIMBLE IS NOT RESPONSIBLE FOR THE OPERATION OR FAILURE OF OPERATION OF ANY SATELLITE BASED POSITIONING SYSTEM OR THE AVAILABILITY OF ANY SATELLITE BASED POSITIONING SIGNALS.**

THE FOREGOING LIMITED WARRANTY TERMS STATE TRIMBLE’S ENTIRE LIABILITY, AND YOUR EXCLUSIVE REMEDIES, RELATING TO THE TRIMBLE PRODUCT. EXCEPT AS OTHERWISE EXPRESSLY PROVIDED HEREIN, THE PRODUCT, AND ACCOMPANYING DOCUMENTATION AND MATERIALS ARE PROVIDED “AS-IS” AND WITHOUT EXPRESS OR IMPLIED WARRANTY OF ANY KIND, BY EITHER TRIMBLE OR ANYONE WHO HAS BEEN INVOLVED IN ITS CREATION, PRODUCTION, INSTALLATION, OR DISTRIBUTION, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, TITLE, AND NONINFRINGEMENT. THE STATED EXPRESS WARRANTIES ARE IN LIEU OF ALL OBLIGATIONS OR LIABILITIES ON THE PART OF TRIMBLE ARISING OUT OF, OR IN CONNECTION WITH, ANY PRODUCT. BECAUSE SOME STATES AND JURISDICTIONS DO NOT ALLOW LIMITATIONS ON DURATION OR THE EXCLUSION OF AN IMPLIED WARRANTY, THE ABOVE LIMITATION MAY NOT APPLY OR FULLY APPLY TO YOU.

### Limitation of Liability

TRIMBLE’S ENTIRE LIABILITY UNDER ANY PROVISION HEREIN SHALL BE LIMITED TO THE AMOUNT PAID BY YOU FOR THE PRODUCT. TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT SHALL TRIMBLE OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGE WHATSOEVER UNDER ANY CIRCUMSTANCE OR LEGAL THEORY RELATING IN ANYWAY TO THE PRODUCTS, SOFTWARE AND ACCOMPANYING DOCUMENTATION AND MATERIALS, (INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, LOSS OF DATA, OR ANY OTHER PECUNIARY LOSS), REGARDLESS OF WHETHER TRIMBLE HAS BEEN ADVISED OF THE POSSIBILITY OF ANY SUCH LOSS AND REGARDLESS OF THE COURSE OF DEALING WHICH DEVELOPS OR HAS DEVELOPED BETWEEN YOU AND TRIMBLE. BECAUSE SOME STATES AND JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF LIABILITY FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES, THE ABOVE LIMITATION MAY NOT APPLY OR FULLY APPLY TO YOU.

PLEASE NOTE: THE ABOVE TRIMBLE LIMITED WARRANTY PROVISIONS WILL NOT APPLY TO PRODUCTS PURCHASED IN THOSE JURISDICTIONS (E.G., MEMBER STATES OF THE EUROPEAN ECONOMIC AREA) IN WHICH PRODUCT WARRANTIES ARE THE RESPONSIBILITY OF THE LOCAL TRIMBLE AUTHORIZED DEALER FROM WHOM THE PRODUCTS ARE ACQUIRED. IN SUCH A CASE, PLEASE CONTACT YOUR LOCAL TRIMBLE AUTHORIZED DEALER FOR APPLICABLE WARRANTY INFORMATION.

#### Official Language

THE OFFICIAL LANGUAGE OF THESE TERMS AND CONDITIONS IS ENGLISH. IN THE EVENT OF A CONFLICT BETWEEN ENGLISH AND OTHER LANGUAGE VERSIONS, THE ENGLISH LANGUAGE SHALL CONTROL.

#### COCOM limits

This notice applies to the BD910, BD920, BD920-W, BD920-W3G, BD930, BD930-UHF, BD960, BD970, BD982, BX960, BX960-2, and BX982 receivers.

The U.S. Department of Commerce requires that all exportable GPS products contain performance limitations so that they cannot be used in a manner that could threaten the security of the United States. The following limitations are implemented on this product:

– Immediate access to satellite measurements and navigation results is disabled when the receiver velocity is computed to be greater than 1,000 knots, or its altitude is computed to be above 18,000 meters. The receiver GPS subsystem resets until the COCOM situation clears. As a result, all logging and stream configurations stop until the GPS subsystem is cleared.

#### Restriction of Use of Certain Hazardous Substances in Electrical and Electronic Equipment (RoHS)

Trimble products in this guide comply in all material respects with DIRECTIVE 2002/95/EC OF THE EUROPEAN PARLIAMENT AND OF THE COUNCIL of 27 January 2003 on the restriction of the use of certain hazardous substances in electrical and electronic equipment (RoHS Directive) and Amendment 2005/618/EC filed under C(2005) 3143, with exemptions for lead in solder pursuant to Paragraph 7 of the Annex to the RoHS Directive applied.

#### Waste Electrical and Electronic Equipment (WEEE)

For product recycling instructions and more information, please go to [www.trimble.com/ev.shtml](http://www.trimble.com/ev.shtml).

Recycling in Europe: To recycle Trimble WEEE (Waste Electrical and Electronic Equipment, products that run on electrical power.), Call +31 497 53 24 30, and ask for the “WEEE Associate”. Or, mail a request for recycling instructions to:

Trimble Europe BV  
c/o Menlo Worldwide Logistics  
Meerheide 45  
5521 DZ Eersel, NL



# Contents

<b>1</b>	<b>Introduction</b>	<b>6</b>
	About the BD982 GNSS receiver	7
	BD982 features	8
	Default settings	10
	Technical support	11
<b>2</b>	<b>Specifications</b>	<b>12</b>
	Performance specifications	13
	Physical specifications	14
	Electrical specifications	14
	Environmental specifications	15
	Communication specifications	15
	Receiver drawings	16
	Plan view	16
	Edge view	17
<b>3</b>	<b>Electrical System Integration</b>	<b>18</b>
	BD982 receiver pinouts	19
	40-pin header	19
	1PPS and ASCII time tag	22
	ASCII time tag	23
	Power input	24
	Antenna power output	25
	LED control lines	25
	Power switch and reset	26
	Event	26
	Ethernet	28
	Ethernet routing	28
	Serial port	31
	USB	32
	USB OTG reference design	32
	USB host-only reference design	33
	USB device-only reference design	33
	CAN	35
<b>4</b>	<b>Installation</b>	<b>36</b>
	Unpacking and inspecting the shipment	37
	Shipment carton contents	37
	Reporting shipping problems	37
	Installation guidelines	37
	Considering environmental conditions	37

Supported antennas .....	37
Mounting the antennas .....	38
Sources of electrical interference .....	38
Interface board evaluation kit .....	39
Routing and connecting the antenna cable .....	41
LED functionality and operation .....	42
<b>Troubleshooting receiver issues .....</b>	<b>44</b>
<b>Glossary .....</b>	<b>46</b>

# Introduction

## In this chapter:

- [About the BD982 GNSS receiver](#)
- [BD982 features](#)
- [Default settings](#)
- [Technical support](#)

This manual describes how to set up and use the Trimble BD982 GNSS receiver module. The BD982 receiver uses advanced navigation architecture to achieve real-time centimeter accuracies with minimal latencies.

Even if you have used other GNSS or GPS products before, Trimble recommends that you spend some time reading this manual to learn about the special features of this product. If you are not familiar with GNSS or GPS, visit the Trimble website ([www.trimble.com](http://www.trimble.com)).

## About the BD982 GNSS receiver

The receiver is used for a wide range of precise positioning and navigation applications. These uses include unmanned vehicles and port and terminal equipment automation, and any other application requiring reliable, centimeter-level positioning at a high update rate and low latency.

The receiver offers centimeter-level accuracy based on carrier phase RTK and submeter accuracy code-based solutions.

Automatic initialization and switching between positioning modes allow for the best position solutions possible. Low latency (less than 20 msec) and high update rates give the response time and accuracy required for precise dynamic applications.

You can configure the receiver as an autonomous base station (sometimes called a reference station) or as a rover receiver (sometimes called a mobile receiver). Streamed outputs from the receiver provide detailed information, including the time, position, heading, quality assurance (figure of merit) numbers, and the number of tracked satellites. The receiver also outputs a one pulse per second (1 PPS) strobe signal which lets remote devices precisely synchronize time.

Designed for reliable operation in all environments, the receiver provides a positioning interface to an office computer, external processing device, or control system. The receiver can be controlled through a serial, ethernet, USB, or CAN port using binary interface commands or the web interface.

## BD982 features

- Position antenna based on a 220-channel Trimble Maxwell™ 6 chip:
  - GPS: Simultaneous L1 C/A, L2E, L2C, L5
  - GLONASS: Simultaneous L1 C/A, L1 P, L2 C/A L2 P
  - SBAS: Simultaneous L1 C/A, L5
  - GALILEO: Simultaneous L1 BOC, E5A, E5B, E5AltBOC
  - BeiDou: Simultaneous B1, B2
  - QZSS: Simultaneous L1 C/A, L1 SAIF, L2C, L5
  - L-Band OmniSTAR VBS, HP, and XP
- Vector antenna based on a second 220-channel Maxwell 6 chip:
  - GPS: Simultaneous L1 C/A, L2E, L2C
  - GLONASS: Simultaneous L1 C/A, L1 P, L2 C/A, L2 P
  - BeiDou: Simultaneous B1
- Advanced Trimble Maxwell Custom Survey GNSS Technology
- Very low noise GNSS carrier phase measurements with <1 mm precision in a 1 Hz bandwidth
- Proven Trimble low elevation tracking technology
- 1 USB port
- 1 CAN port
- 1 LAN Ethernet port:
  - Supports links to 10BaseT/100BaseT networks
  - All functions are performed through a single IP address simultaneously—including web interface access and raw data streaming
- Network Protocols supported:
  - HTTP (web GUI)
  - NTP Server
  - NMEA, GSOE, CMR, and so on over TCP/IP or UDP
  - NTripCaster, NTripServer, NTripClient
  - mDNS/UPnP Service discovery
  - Dynamic DNS
  - Email alerts
  - Network link to Google Earth
  - Support for external modems through PPP
- 4 × RS-232 ports (baud rates up to 460,800)



- 1 Hz, 2 Hz, 5 Hz, 10 Hz, 20, and 50 Hz positioning and heading outputs (depending on the installed option)
- Up to 50 Hz raw measurement and position outputs
- Correction inputs/outputs: CMR, CMR+™, sCMRx, RTCM 2.1, 2.2, 2.3, 3.0. Note:
  - The functionality to input or output any of these corrections depends on the installed options.
  - Different manufacturers may have established different packet structures for their correction messages. Thus, the BD9xx receivers may not receive corrections from other manufacturers receivers, and other manufacturers receivers may not be able to receive corrections from BD9xx receivers.
- Navigation outputs:
  - ASCII: NMEA-0183: GBS; GGA; GLL; GNS; GRS; GSA; GST; GSV; HDT; LLQ; PTNL,AVR; PTNL,BPQ; PTNL,DG; PFUGDP; DTM; PTNL,GGK; PTNL,PJK; PTNL,PJT; PTNL,VGK; PTNL,VHD; RMC; ROT; VTG; ZDA.
  - Binary: Trimble GSOF.
- Control software: HTML Web browser (Google Chrome (recommended), Internet Explorer®, Mozilla Firefox, Apple Safari, Opera)
- 1 Pulse Per Second Output
- Event Marker Input Support
- LED drive support

## Default settings

All settings are stored in application files. The default application file, `Default.cfg`, is stored permanently in the receiver, and contains the factory default settings. Whenever the receiver is reset to its factory defaults, the current settings (stored in the current application file, `Current.cfg`) are reset to the values in the default application file.

These settings are defined in the default application file.

Function	Settings	Factory default
SV Enable	-	All SVs enabled
General Controls	Elevation mask	10°
	PDOP mask	99
	RTK positioning mode	Low Latency
	Motion	Kinematic
Ports	Baud rate	38,400
	Format	8-None-1
	Flow control	None
Input Setup	Station	Any
NMEA/ASCII (all supported messages)		All ports Off
Streamed Output		All types Off Offset=00
RT17/Binary		All ports Off
Reference Position	Latitude	0°
	Longitude	0°
	Altitude	0.00 m HAE
Antenna	Type	Unknown
	Height (true vertical)	0.00 m
	Measurement method	Antenna Phase Center
1PPS		Disabled

If a factory reset is performed, the above defaults are applied to the receiver. The receiver also returns to a DHCP mode, and security is enabled (with a default login of “admin” and the password of “password”). To perform a factory reset:

- From the web interface, select *Receiver Configuration / Reset* and then clear the *Clear All Receiver Settings* option.
- Send the Command 58h with a 03h reset value.
- Use the Configuration Toolbox utility and from the *Communications* menu, select *Reset Receiver*. Select both the *Erase Battery-Backed RAM* and *Erase File System* options.

## Technical support

If you have a problem and cannot find the information you need in the product documentation, send an email to [GNSSOEMSupport@trimble.com](mailto:GNSSOEMSupport@trimble.com).

Documentation, firmware, and software updates are available at: [www.trimble.com/gnss-inertial/GNSS-Positioning-and-Heading-Systems.aspx](http://www.trimble.com/gnss-inertial/GNSS-Positioning-and-Heading-Systems.aspx).

# Specifications

## In this chapter:

- [Performance specifications](#)
- [Physical specifications](#)
- [Electrical specifications](#)
- [Environmental specifications](#)
- [Communication specifications](#)
- [Receiver drawings](#)

This chapter details the specifications for the receiver.

Specifications are subject to change without notice.

## Performance specifications

Feature	Specification
Measurements	<ul style="list-style-type: none"> <li>Position antenna based on a 220-channel Maxwell 6 chip:               <ul style="list-style-type: none"> <li>GPS: Simultaneous L1 C/A, L2E, L2C, L5</li> <li>GLONASS: Simultaneous L1 C/A, L1 P, L2 C/A (GLONASS M Only), L2 P</li> <li>SBAS: Simultaneous L1 C/A, L5</li> <li>GALILEO: Simultaneous L1 BOC, E5A, E5B, E5AltBOC</li> <li>BeiDou: Simultaneous B1, B2</li> <li>QZSS: Simultaneous L1 C/A, L1 SAIF, L2C, L5</li> <li>L-Band OmniSTAR VBS, HP, and XP</li> </ul> </li> <li>Vector antenna based on a second 220-channel Maxwell 6 chip:               <ul style="list-style-type: none"> <li>GPS: Simultaneous L1 C/A, L2E, L2C</li> <li>GLONASS: Simultaneous L1 C/A, L1 P, L2 C/A, L2 P</li> <li>BeiDou: Simultaneous B1</li> </ul> </li> <li>Advanced Trimble Maxwell 6 Custom Survey GNSS Technology</li> <li>High precision multiple correlator for GNSS pseudorange measurements</li> <li>Unfiltered, unsmoothed pseudorange measurements data for low noise, low multipath error, low time domain correlation and high dynamic response</li> <li>Very low noise GNSS carrier phase measurements with &lt;1 mm precision in a 1 Hz bandwidth</li> <li>Signal-to-Noise ratios reported in dB-Hz</li> <li>Proven Trimble low elevation tracking technology</li> </ul>
Code differential GPS positioning accuracy <sup>1</sup>	0.25 m + 1 ppm Horizontal 0.50 m + 1 ppm Vertical
SBAS accuracy <sup>2</sup>	<5 m 3DRMS
RTK positioning accuracy (<30 km)	Horizontal: $\pm(8 \text{ mm} + 1 \text{ ppm})$ RMS Vertical: $\pm(15 \text{ mm} + 1 \text{ ppm})$ RMS Heading: 2 m baseline <0.09°; 10 m baseline <0.05°
Initialization time	Typically, less than 10 seconds

<sup>1</sup>Accuracy and reliability may be subject to anomalies such as multipath, obstructions, satellite geometry, and atmospheric conditions. Always follow recommended practices.

<sup>2</sup>Depends on WAAS, EGNOS, and MSAS system performance.

Feature	Specification
Initialization reliability <sup>1</sup>	Typically >99.9%

## Physical specifications

Feature	Specification
Dimensions (L x W x H)	100 mm x 84.9 mm x 11.6 mm
Vibration	MIL810F, tailored Random 6.2 gRMS operating Random 8 gRMS survival
Mechanical shock	MIL810D ±40 g operating ±75 g survival
I/O connector	40-pin header (Samtec TMM-120-03-L-D) (Rated for 1000 cycles)
Antenna connector	2 x MMCX receptacle (Huber-Suhner 82MMCX-50-0-1/111) (Rated for 500 cycles); mating connectors are MMCX plug (Suhner 11MMCX-50-2-1C) or right-angle plug (Suhner 16MMCX-50-2-1C, or 16MMCX-50-2-10)

## Electrical specifications

Feature	Specification
Voltage	3.3 V DC +5%/-3%
Power consumption	Typically, 2.1 W (L1/L2 GPS) Typically, 2.2 W (L1/L2 GPS and G1/G2 GLONASS) Typically, 3.1 W (L1/L2/L5 GPS, G1/G2 GLONASS, B1/B2 BeiDou, L1/E5 Galileo) Typically, 3.4 W (L1/L2/L5 GPS, G1/G2 GLONASS, B1/B2 BeiDou, L1/E5 Galileo, OmniSTAR/SPOT) <b>Note</b> – These values were characterized using v4.84 firmware.
Minimum required LNA gain	32.5 dB <b>Note</b> – This receiver is designed to operate with the Zephyr Model 2 antenna which has a gain of 50 dB. Higher-gain antennas have not been tested.

<sup>1</sup>May be affected by atmospheric conditions, signal multipath, and satellite geometry. Initialization reliability is continuously monitored to ensure highest quality.

## Environmental specifications

Feature	Specification
Temperature	Operating: -40°C to 75°C (-40°F to 167°F) Storage: -55°C to 85°C (-67°F to 185°F)
Vibration	MIL810F, tailored Random 6.2 gRMS operating Random 8 gRMS survival
Mechanical shock	MIL810D +/- 40 g operating +/- 75 g survival
Operating humidity	5% to 95% R.H. non-condensing, at +60°C (140°F)

## Communication specifications

Feature	Specification
Communications	<div>1 LAN port</div> <ul style="list-style-type: none"> <li>Supports links to 10BaseT/100BaseT networks.</li> <li>All functions are performed through a single IP address simultaneously – including web interface access and data streaming.</li> </ul> <div>4 x RS-232 ports Baud rates up to 460,800</div> <div>1 USB 2.0 port</div>
Receiver position update rate	1 Hz, 2 Hz, 5 Hz, 10 Hz, 20 Hz and 50 Hz positioning
Correction data input	CMR, CMR <sup>+</sup> , sCMRx, RTCM 2.0–2.3, RTCM 3.0, 3.1
Correction data output	CMR, CMR <sup>+</sup> , sCMRx, RTCM 2.0 DGPS (select RTCM 2.1), RTCM 2.1–2.3, RTCM 3.0
Data outputs	1PPS, NMEA, Binary GSOE, ASCII Time Tags

## Receiver drawings


The following drawings show the dimensions of the BD982 receiver. Refer to these drawings if you need to build mounting brackets and housings for the receiver.

Dimensions are shown in millimeters (mm).

### Plan view

① Primary/position antenna


② Secondary/vector antenna





## 2 Specifications

### Edge view



# Electrical System Integration

## In this chapter:

- [BD982 receiver pinouts](#)
- [1PPS and ASCII time tag](#)
- [ASCII time tag](#)
- [Power input](#)
- [Antenna power output](#)
- [LED control lines](#)
- [Power switch and reset](#)
- [Event](#)
- [Ethernet](#)
- [Serial port](#)
- [USB](#)
- [CAN](#)

## BD982 receiver pinouts

### 40-pin header

The 40-pin header (J1) has the following pinouts:

Pin	Signal name	Description	Integration notes
1	GND	Ground Digital ground	Ground Digital ground
2	RTK LED	RTK LED. Flashes when an RTK correction is present. This is similar to all BD9xx products, except for the requirement for an external resistor.	When used to drive an LED, a series resistor with a typical value of 300 Ohms is required. This pin supplies a maximum current of 4mA. For LEDs with Vf above 2.7 or current excess of 4mA, an external buffer is required.
3	POWER_ OFF	Powers the unit on and off.	Drive high with a 3.3 V to turn off, leave floating or ground to keep the unit on. Integrators should not drive TTL signals when the unit is not powered.
4	PPS (Pulse Per Second)	Pulse Per Second	This is 3.3 V TTL level, 4mA max drive capability. To drive 50 load to ground, an external buffer is required.
5	VCC Input DC Card Power	VCC Input DC Card power (3.3 V only)	VCC Input DC Card power (3.3 V only)
6	VCC Input DC Card Power	VCC Input DC Card power (3.3 V only)	VCC Input DC Card power (3.3 V only)
7	Event2, CAN1_Rx and COM3_Rx	Event2 – Event input CAN1_Rx - CAN Receive line COM3_Rx – COM3 Receive line	MUTUALLY EXCLUSIVE and TTL level. Connect Event2 to a TTL level signal to use as Event. Connect CAN1_Rx to RX line of a CAN driver to use as CAN. Connect COM3_Rx to a transceiver if RS-232 level is required.
8	Event1	Event1 – Input	Event1 (must be 3.3 V TTL level)
9	Power LED	POWER Indicator. High when unit is on, low when off. This is similar to all BD9xx products, except for the requirement for an external resistor. This allows user to use this as a control line.	When used to drive an LED, a series resistor with a typical value of 300 Ohms is required. This pin supplies a maximum current of 4mA. For LEDs with Vf above 2.7 or current excess of 4mA, an external buffer is required.
10	Satellite	Satellite LED. Rapid flash indicates <5	When used to drive an LED, a series resistor

Pin	Signal name	Description	Integration notes
	LED	satellites. Slow flash indicates >5 satellites.	with a typical value of 300 Ohms is required. This pin supplies a maximum current of 4mA. For LEDs with Vf above 2.7 or current excess of 4mA, an external buffer is required.
11	COM2_CTS	COM2 Clear to Send – TTL Level	Connect COM2_CTS to a transceiver if RS-232 level is required.
12	RESET_IN	RESET_IN – ground to reset	Drive low to reset the unit. Otherwise, leave unconnected.
13	COM2_RTS	COM 2 Request to Send – TTL Level	Request to Send for COM 2 connect to a transceiver if RS-232 level is required.
14	COM2_Rx	COM 2 Receive Data – TTL Level	Connect COM2_RX to a transceiver if RS-232 level is required.
15	NO CONNECT	Reserved	
16	COM2_Tx	COM 2 Transmit Data – TTL Level	Connect COM2_TX to a transceiver if RS-232 level is required
17	NO CONNECT	Reserved	
18	COM1_Rx	COM 1 Receive Data – RS-232 Level	
19	CAN1_Tx and COM3_Tx	CAN1_Tx - CAN Transmit line – COM3 Transmit line	MUTUALLY EXCLUSIVE and TTL level. Connect CAN1_Tx to TX line of a CAN driver to use as CAN. Connect COM3_Tx to a transceiver if RS-232 level is required.
20	COM1_Tx	COM 1 Transmit Data – RS-232 Level	
21	USB D (-)	USB D (-) Bi-directional USB interface data (-)	USB data for OTG mode (device and host).
22	USB D (+)	USB D (+) Bi-directional USB interface data (+)	USB data for OTG mode (device and host).
23	GND	Ground Digital ground	Ground Digital ground
24	GND	Ground Digital ground	Ground Digital ground
25	USB ID	USB OTG ID	Driving a low level puts unit into USB host mode. High level or no-connect puts unit in device mode. Pull-up is on unit and not required for integration.
26	USB Vbus	USB Vbus	In USB device operation, Vbus is only used for detection. In USB host mode, the unit supplies power per USB spec (500 mA at 5 V max).


Pin	Signal name	Description	Integration notes
27	GND	Ground Digital ground	Ground Digital ground
28	GND	Ground Digital ground	Ground Digital ground
29	GND	Ground Digital ground	Ground Digital ground
30	GND	Ground Digital ground	Ground Digital ground
31	GND	Ground Digital ground	Ground Digital ground
32	GND	Ground Digital ground	Ground Digital ground
33	ETH_TD+	Ethernet Transmit. Positive side of differential pair.	Connect straight to Ethernet connector. Magnetics are on-board unit.
34	ETH_RD+	Ethernet Receive. Positive side of differential pair.	Connect straight to Ethernet connector. Magnetics are on-board unit.
35	ETH_TD-	Ethernet Transmit. Negative side of differential pair.	Connect straight to Ethernet connector. Magnetics are on-board unit.
36	ETH_RD-	Ethernet Receive. Negative side of differential pair.	Connect straight to Ethernet connector. Magnetics are on-board unit.
37	COM4_Rx	COM 4 Receive data – RS-232 level	–
38	COM4_Tx	COM 4 Transmit data – RS-232 level	–
39	GND	Ground Digital ground	Ground Digital ground
40	GND	Ground Digital ground	Ground Digital ground

## 1PPS and ASCII time tag

The receiver can output a 1 pulse-per-second (1PPS) time strobe and an associated time tag message. The time tags are output on a user-selected port.

The leading edge of the pulse coincides with the beginning of each UTC second. The pulse is driven between nominal levels of 0.0 V and 3.3 V (see below). The leading edge is positive (rising from 0 V to 3.3 V). The receiver PPS out is a 3.3 V TTL level with a maximum source/sink current of 4 mA. If the system requires a voltage level or current source/sink level beyond these levels, you must have an external buffer. This line has ESD protection.

The illustration below shows the time tag relation to 1PPS wave form:



The pulse is about 8 microseconds wide, with rise and fall times of about 100 nsec. Resolution is approximately 40 nsec, where the 40 nsec resolution means that the PPS shifting mechanism in the receiver can align the PPS to UTC/GPS time only within  $\pm 20$  nsec, but the following external factor limits accuracy to approximately  $\pm 1$  microsecond:

- Antenna cable length

Each meter of cable adds a delay of about 2 nsec to satellite signals, and a corresponding delay in the 1PPS pulse.

## ASCII time tag

Each time tag is output about 0.5 second before the corresponding pulse. Time tags are in ASCII format on a user-selected serial port. The format of a time tag is:

UTC yy.mm.dd hh:mm:ss ab

**Where:**

- UTC is fixed text.
- yy.mm.dd is the year, month, and date.
- hh:mm:ss is the hour (on a 24-hour clock), minute, and second. The time is in UTC, not GPS.
- a is an integer number representing the position-fix type:
  - 1 = time solution only
  - 2 = 1D position and time solution
  - 3 = currently unused
  - 4 = 2D position and time solution
  - 5 = 3D position and time solution
- b is the number of GNSS satellites being tracked. If the receiver is tracking 9 or more satellites, b will always be displayed as 9.
- Each time tag is terminated by a *carriage return, line feed* sequence. A typical printout looks like:
 

```
UTC 02.12.21 20:21:16 56
UTC 02.12.21 20:21:17 56
UTC 02.12.21 20:21:18 56
```

**Note** – *If the receiver is not tracking satellites, the time tag is based on the receiver clock. In this case, a and b are represented by “??”. The time readings from the receiver clock are less accurate than time readings determined from the satellite signals.*

## Power input


Item	Description
Power requirement	<p>The unit operates at 3.3 V +5%/-3%.</p> <p>The 3.3 V should be able to supply 2 A of surge current.</p> <p><b>Additional integration notes —</b></p> <p>1) To fully protect against the unit resetting while shorting any antenna output, Trimble recommends that the 3.3 V input be rated at least 3.5 A. Power supplies under 3.5 A will lead to the 3.3 V rail drooping, triggering a reset to the system.</p> <p>2) Worst case operation requires a 3 A supply. Worst case operation is defined as: both antennas supplying 5 V at 100 mA, USB supplying 5 V at 250 mA, and actively using all RF bands.</p> <p>The typical power consumption based on band usage is:</p> <ul style="list-style-type: none"> <li>• L1/L2 = 2.08 W</li> <li>• L1/L2/G1/G2 = 2.24 W</li> <li>• L1/L2/G1/G2/SBAS = 2.27 W</li> <li>• L1/L2/G1/G2/SBAS/L5 = 2.54 W</li> <li>• L1/L2/G1/G2/SBAS/L5/Galileo = 2.79 W</li> <li>• L1/L2/G1/G2/SBAS/L5/Galileo + Omnistar = 3.10 W</li> </ul>
Power switch	Pin 3 is an optional power-off pin. When driven high with 3.3V, the receiver is powered off. This unit can be left floating or ground to keep the unit on. System integrators should not drive TTL signals when unit is not powered..
Over-voltage protection	The absolute maximum voltage is 3.6V.
Under-voltage protection	The absolute minimum voltage is 3.2 V below nominal.
Reverse voltage protection	The unit is protected down to -3.6 V.



## Antenna power output

Item	Description
Power output specification	The antenna supplies 100 mA at 5 V.
Short-circuit protection	The unit has an over-current / short circuit protection. Short circuits may cause the unit to reset.

## LED control lines

Item	Description
Driving LEDs	<p>The outputs are 3.3V TTL level with a maximum source/sink current of 4mA. An external series resistor must be used to limit the current. The value of the series resistor in Ohms is determined by:</p> $(3.3 - V_f) / (I_f) > R_s > (3.3 \text{ V} - V_f) / (.004)$ <p><math>R_s</math> = Series resistor</p> <p><math>I_f</math> = LED forward current, max typical <math>I_f</math> of the LED should be less than 3mA</p> <p><math>V_f</math> = LED forward voltage, max typical <math>V_f</math> of the LED should be less than 2.7V</p> <p>Most LEDs can be driven directly as shown in the circuit below:</p>  <p>LEDs that do not meet <math>I_f</math> and <math>V_f</math> specification must be driven with a buffer to ensure proper voltage level and source/sink current.</p>
Power LED	This active-high line indicates that the unit is powered on.
Satellite LED	<p>This active-high line indicates that the unit has acquired satellites.</p> <p>A rapid flash indicates that the unit has less than 5 satellites acquired while a slow flash indicates greater than 5 satellites acquired. This line will stay on if the unit is in monitor mode.</p>
RTK Correction	A slow flash indicates that the unit is receiving corrections. This will also flash when the unit is in monitor mode.

## Power switch and reset


Item	Description
Power switch	<p>The integrator may choose to power on or power off the unit. If a 3.3 V level signal is applied to pin 3, Power_Off pin, the unit will disconnect VCC. The system integrator must ensure that other TTL level pins remain unpowered when Power_Off is asserted. Powering TTL-level pins while the unit is powered off will cause excessive leakage current to be sunk by the unit.</p> <p>The integrator may choose to always have the unit powered on. This is accomplished by leaving the Power_Off pin floating or grounded.</p>
Reset switch	<p>Driving Reset_IN_L, Pin 12, low will cause the unit to reset. The unit will remain reset at least 140 mS after the Reset_In_L is deasserted. The unit remains powered while in reset.</p>

## Event

Item	Description
Event 1	<p>Pin 8 is dedicated as an Event_In pin.</p> <p>This is a TTL only input, it is not buffered or protected for any inputs outside of 0V to 3.3V. It does have ESD protection. If the system requires event to handle a voltage outside this range, the system integrator must condition the signal prior to connecting to the unit.</p>
Event 2	<p>Event 2 is multiplexed with COM3_RX and CAN_RX. The default setting is to have this line set to COM3_RX. The Event 2 must be enabled in order to use Event2.</p> <p>When using the 63494 Development interface board, the user must not connect anything to Port 3 and the CAN port when using Event 2. The Com3 level selection switch is ignored when Event 2 is selected.</p> <p>This is a TTL only input, it is not buffered or protected for any inputs outside of 0 V to 3.3 V. It does have ESD protection. If the system requires event to handle a voltage outside this range, the system integrator must condition the signal prior to connecting to the unit.</p>

Trimble recommends adding a Schmitt trigger and ESD protection to the Event\_In pin. This prevents any "ringing" on the input from causing multiple and incorrect events to be recognized.


### 3 Electrical System Integration




For more information, go to [www.trimble.com/OEM\\_ReceiverHelp/V4.85/default.html#AppNote\\_EventInput.html](http://www.trimble.com/OEM_ReceiverHelp/V4.85/default.html#AppNote_EventInput.html).

## Ethernet

Since the magnetics are on-board, the Ethernet interface can be implemented using only a RJ-45 connector, and termination discretes. See design example below:



Optional surge protection is provided by a Semtech SLVU2.8-4. To meet electrical isolation requirements, Trimble recommends using capacitors with a greater than 2 kV breakdown voltage.




## Ethernet routing


Minimize the distance from the RJ-45 to the receiver main connector to prevent issues with conducted emissions.

The sample routing below shows a four-layer stack up, with dual-side board placement. The routing shown ensures that the differential pairs are routed over solid internal planes.

### Top view



## Bottom view



## Serial port


Item	Description
COM 1 RS-232 level no flow control	COM 1 is already at RS-232 level and already has 8 kV contact discharge/15 kV air gap discharge ESD Protection. This is labeled Port 1 on the I/O board.
COM 2 TTL level with flow control	<p>COM 2 is at 0-3.3 V TTL. This port has RTS/CTS to support hardware flow control. If the integrator needs this port to be at RS-232 level, a proper transceiver powered by the same 3.3V that powers the receiver needs to be added.</p> <p>For development using the I/O board, this COM port is already connected to an RS-232 transceiver. This is labeled Port 2 on the I/O board.</p>
COM 3 TTL level no flow control	<p>COM 3 is at 0-3.3 V TTL and is multiplexed with CAN. The receive line is also multiplexed with Event 2. The integrator must have a BD982 receiver configured to use the serial port in order to use this port as a serial port.</p> <p>The functionality cannot be multiplexed in real time. If the integrator needs this port to be at RS-232 level, a proper transceiver powered by the same 3.3 V that powers the receiver needs to be added.</p> <p>For development using the I/O board, this com port is already connected to an RS-232 transceiver. This is labeled Port 3 on the I/O board. SW4, labeled COM3 HW Xciever Selection, must be set to RS-232. There should not be anything connected to TP5, labeled Event 2.</p>
COM 4 RS-232 level no flow control	COM 4 is on-board level translated to RS-232 voltages, with 8 kV contact discharge/15 kV air gap discharge ESD protection. This is labeled Port 4 on the I/O board.

## USB

The CPU of the receiver has an integrated PHY that supports both USB 2.0 Device and Host configuration at low speed, full speed, and high speed. In Host mode, the receiver supplies 5 V to a USB device, such as a memory stick. In Device mode, the receiver behaves like an external storage device to a computer.

### USB OTG reference design

To be OTG-compliant, the connector must be MICRO AB. An OTG-compliant cable has A and B ends. When the B-side of the cable is inserted, the ID pin is not connected (floating) and the receiver enters Device mode through a pull-up resistor. The A-side of the cable connects the ID pin to ground, which enables Host mode on the receiver.



To reduce EMI, place a USB 2.0 compliant common mode choke on the data lines. To ensure best EMI performance, locate the choke near the USB MICRO AB connector. Trimble recommends that you use an L-C-L type EMI filter for the output power.

For product robustness and protection, place ESD protection diodes on both the USB\_VBUS and USB\_OTG\_ID lines. The receiver has internal high-speed ESD protection on the USB data lines.

To ensure best USB high-speed performance, carefully consider PCB routing and placement practices:

- Place components so the trace length is minimized.
- Do not have stubs on data lines more than 0.200".
- Route data lines differentially but as parallel as possible.
- Data lines must be controlled to 90 Ohms differential impedance, and 45 Ohms single-ended




impedance.

- Route over continuous reference plane (either ground or power).

For more detailed information, refer to the *Intel High Speed USB Platform Design Guidelines*.

## USB host-only reference design

For USB host-only support, a type-A connector is required. Since the receiver does not support dynamic role switching, the ID pin should be grounded on the receiver. In Host mode, the receiver supplies nominal 5 V output at 500 mA to the USB device.




For recommendations about EMI, ESD protection, and layout considerations, refer to the section above.

## USB device-only reference design

For device-only operation, the USB\_OTG\_ID pin is left floating. For reference, the receiver has an internal 10K Ohm pull-up to 3.3 V. In this mode, the USB\_DEVICE\_VBUS is used only by receiver to detect if host power is connected.

### 3 Electrical System Integration




For recommendations about EMI, ESD protection, and layout considerations, refer to the section above.

## CAN

COM 3 is at 0-3.3 V TTL and is multiplexed with CAN. The receive line is also multiplexed with Event 2. The integrator must have a receiver configured to use the CAN port in order to use this port as a serial port. The functionality cannot be multiplexed in real time. The integrator must add a CAN transceiver in order to use the CAN Port.

For development using the I/O board, this com port is already connected to a CAN transceiver. This is labeled CAN on the I/O board. SW4, labeled COM3 HW Xceiver Selection, must be set to CAN. There shouldn't be anything connected to TP5, labeled Event 2.

The following figure shows a typical implementation with a 3.3 V CAN transceiver. It also shows a common mode choke as well as ESD protection. A 5 V CAN Transceiver can be used if proper level translation is added.



# Installation

## In this chapter:

- [Unpacking and inspecting the shipment](#)
- [Installation guidelines](#)
- [Interface board evaluation kit](#)
- [Routing and connecting the antenna cable](#)
- [LED functionality and operation](#)

## Unpacking and inspecting the shipment

Visually inspect the shipping cartons for any signs of damage or mishandling before unpacking the receiver. Immediately report any damage to the shipping carrier.

### Shipment carton contents

The shipment will include one or more cartons. This depends on the number of optional accessories ordered. Open the shipping cartons and make sure that all of the components indicated on the bill of lading are present.

### Reporting shipping problems

Report any problems discovered after you unpack the shipping cartons to both Trimble Customer Support and the shipping carrier.

## Installation guidelines

The receiver is designed to be standoff mounted. You must use the appropriate hardware and all of the mounting holes. Otherwise, you violate the receiver hardware warranty. For more information, refer to the drawings of the receiver.

### Considering environmental conditions

Install the receiver in a location situated in a dry environment. Avoid exposure to extreme environmental conditions. This includes:

- Water or excessive moisture
- Excessive heat greater than 75 °C (167 °F)
- Excessive cold less than –40 °C (–40 °F)
- Corrosive fluids and gases

Avoiding these conditions improves the receiver's performance and long-term product reliability.

### Supported antennas

The receiver tracks multiple GNSS frequencies; the Trimble Zephyr™ II antenna supports these frequencies.

Other antennas may be used with the receiver. However, ensure that the antenna you choose supports the frequencies you need to track.

For the BD982 receiver, the antenna must operate at 5 V with a greater than 32.5 dB signal at the board antenna port.

## Mounting the antennas

Choosing the correct location for the antenna is critical to the installation. Poor or incorrect placement of the antenna can influence accuracy and reliability and may result in damage during normal operation. Follow these guidelines to select the antenna location:

- If the application is mobile, place the antenna on a flat surface along the centerline of the vehicle.
- Choose an area with clear view to the sky above metallic objects.
- **Avoid** areas with high vibration, excessive heat, electrical interference, and strong magnetic fields.
- **Avoid** mounting the antenna close to stays, electrical cables, metal masts, and other antennas.
- **Avoid** mounting the antenna near transmitting antennas, radar arrays, or satellite communication equipment.

## Sources of electrical interference

Avoid the following sources of electrical and magnetic noise:

- gasoline engines (spark plugs)
- television and computer monitors
- alternators and generators
- electric motors
- propeller shafts
- equipment with DC-to-AC converters
- fluorescent lights
- switching power supplies

## Interface board evaluation kit

An evaluation kit is available for testing the receiver. This includes an I/O board that gives access to the following:

- Power input connector
- Power ON/OFF switch
- Four serial ports through DB9 connectors
- Ethernet through an RJ45 connector


**Note** – There are separate Ethernet jacks for the BD970 and BD982 boards.

- USB port through USB Type A and Type B receptacles
- CAN port through a DB9 connector
- Two event input pins
- 1PPS output on BNC connector
- CAN / Serial port 3 switch

**Note** – To switch between serial port 3 and CAN, you must configure the receiver using the web interface or binary commands. If you do not set an option bit to make CAN the default, the receiver defaults to serial.

- Three LEDs to indicate satellite tracking, receipt of corrections, and power

The following figure shows a typical I/O board setup:



The computer connection provides a means to set up and configure the receiver.

Included with the BD982 I/O board is a small plastic bag that contains four standoffs. Screw these into the I/O board to coincide with the four corner holes of the receiver when seated on the J3 connector.

Current or prospective customers may obtain schematic drawings or Gerber files of the evaluation I/O board by contacting [GNSSOEMSupport@trimble.com](mailto:GNSSOEMSupport@trimble.com).



## Routing and connecting the antenna cable

1. After mounting the antenna, route the antenna cable from the GPS antenna to the receiver.


Avoid the following hazards when routing the antenna cable:

- Sharp ends or kinks in the cable
- Hot surfaces (such as exhaust manifolds or stacks)
- Rotating or reciprocating equipment
- Sharp or abrasive surfaces
- Door and window jams
- Corrosive fluids or gases

2. After routing the cable, connect it to the receiver. Use tie-wraps to secure the cable at several points along the route. For example, to provide strain relief for the antenna cable connection use a tie-wrap to secure the cable near the base of the antenna.

**Note** – When securing the cable, start at the antenna and work towards the receiver.

3. When the cable is secured, coil any slack. Secure the coil with a tie-wrap and tuck it in a safe place.



- 1 BD982 GNSS receiver    2 MMCX connectors    3 GNSS antennas

**Note** – The MMCX connector at the end of antenna cable needs a CBL ASSY TNC-MMCX connector to interface with the receiver module.

## LED functionality and operation

The evaluation interface board comes with three LEDs to indicate satellite tracking, RTK receptions, and power. The initial boot-up sequence for a receiver lights all the three LEDs for about three seconds followed by a brief duration where all three LEDs are off. Thereafter, use the following table to confirm tracking of satellite signals or for basic troubleshooting.

For single antenna configurations, the following LED patterns apply:

Power LED	RTK Corrections LED	SV Tracking LED	Status
On (continuous)	Off	Off	The receiver is turned on, but not tracking satellites.
On (continuous)	Off	Blinking at 1 Hz	The receiver is tracking satellites, but no incoming RTK corrections are being received.
On (continuous)	Blinking at 1 Hz	Blinking at 1 Hz	The receiver is tracking satellites and receiving incoming RTK corrections.
On (continuous)	Off or blinking (receiving corrections)	Blinking at 5 Hz for a short while	Occurs after a power boot sequence when the receiver is tracking less than 5 satellites and searching for more satellites.
On (continuous)	Blinking at 1 Hz	Off	The receiver is receiving incoming RTK corrections, but not tracking satellites.
On (continuous)	Blinking at 5 Hz	Blinking at 1 Hz	The receiver is receiving Moving Base RTK corrections at 5 Hz.
On (continuous)	On (continuous)	Blinking at 1 Hz	The receiver is receiving Moving Base RTK corrections at 10 or 20 Hz (the RTK LED turns off for 100 ms if a correction is lost).
On (continuous)	On, blinking off briefly at 1 Hz	Blinking at 1 Hz	The receiver is in a base station mode, tracking satellites and transmitting RTK corrections.
On (continuous)	Blinking at 1 Hz	On (continuous)	The receiver is in Boot Monitor Mode. Use the WinFlash utility to reload application firmware onto the board. For more information, contact technical support.

For two antenna configurations, the following LED patterns apply:

Power LED	RTK Corrections LED	SV Tracking LED	Status
On (continuous)	Off	Off	The receiver is turned on, but not tracking satellites.
On (continuous)	Off	Blinking at 1 Hz then a high-frequency blinking burst every 5 seconds	The receiver is tracking satellites on the position antenna and the vector antenna. However, no incoming RTK corrections are

Power LED	RTK Corrections LED	SV Tracking LED	Status
			being received.
On (continuous)	Blinking at 1 Hz	Blinking at 1 Hz then a high-frequency blinking burst every 5 seconds	The receiver is tracking satellites on the position antenna and the vector antenna, and incoming RTK corrections are being received.
On (continuous)	Off or blinking (receiving corrections)	Blinking at 5 Hz for a short while	Occurs after a power boot sequence when the position antenna is searching for satellites.
On (continuous)	Off or blinking (receiving corrections)	Off, then a high-frequency blinking burst every 5 seconds	The receiver is tracking satellites on the vector antenna only. The position antenna is not tracking.
On (continuous)	Blinking at 1 Hz	Off	The receiver is receiving incoming RTK corrections, but not tracking satellites on either the position or vector antenna.
On (continuous)	Blinking at 5 Hz	Blinking at 1 Hz then a high-frequency blinking burst every 5 seconds	The position antenna is receiving Moving Base RTK corrections at 5 Hz.
On (continuous)	Continuously on	Blinking at 1 Hz then a high-frequency blinking burst every 5 seconds	The position antenna is receiving Moving Base RTK corrections at 10 or 20 Hz (the RTK LED turns off for 100 ms if a correction is lost).
On (continuous)	On, blinking off briefly at 1 Hz	Blinking at 1 Hz then a high-frequency blinking burst every 5 seconds	The position antenna is in a base station mode, tracking satellites and transmitting RTK corrections.
On (continuous)	Blinking at 1 Hz	On (continuous)	The receiver is in Boot Monitor Mode. Use the WinFlash utility to reload application firmware onto the board. For more information, contact technical support.

# Troubleshooting receiver issues

This section describes some possible receiver issues, possible causes, and how to solve them. Please read this section before you contact Technical Support.

Issue	Possible cause	Solution
The receiver does not turn on.	External power is too low.	Check that the input voltage is within limits.
The base station receiver is not broadcasting.	Port settings between reference receiver and radio are incorrect.	Check the settings on the radio and the receiver.
	Faulty cable between receiver and radio.	Try a different cable. Examine the ports for missing pins. Use a multimeter to check pinouts.
	No power to radio.	If the radio has its own power supply, check the charge and connections. Examine the ports for missing pins. Use a multimeter to check pinouts.
Rover receiver is not receiving radio.	The base station receiver is not broadcasting.	See the issue "The base station receiver is not broadcasting" above.
	Incorrect over air baud rates between reference and rover.	Connect to the rover receiver radio, and make sure that it has the same setting as the reference receiver.
	Incorrect port settings between roving external radio and receiver.	If the radio is receiving data and the receiver is not getting radio communications, check that the port settings are correct.
The receiver is not receiving satellite signals.	The GPS antenna cable is loose.	Make sure that the GPS antenna cable is tightly seated in the GPS antenna connection on the GPS antenna.
	The cable is damaged.	Check the cable for any signs of damage. A damaged cable can inhibit signal detection from the antenna at the receiver.
	The GPS antenna is not in clear line of sight to the sky.	Make sure that the GPS antenna is located with a clear view of the sky. Restart the receiver as a last resort (turn off and then turn it on again).

Issue	Possible cause	Solution
Communication to the receiver is lost and the LEDs are not behaving normally.	The internal firmware may be corrupt.	With the receiver in the I/O board, apply power while pressing the Boot Monitor button. Reload firmware using the WinFlash utility. Refer to the topic "Upgrading the receiver firmware" in the BD9xx Receiver WebHelp.

# Glossary

<b>1PPS</b>	Pulse-per-second. Used in hardware timing. A pulse is generated in conjunction with a time stamp. This defines the instant when the time stamp is applicable.
<b>almanac</b>	<p>A file that contains orbit information on all the satellites, clock corrections, and atmospheric delay parameters. The almanac is transmitted by a GNSS satellite to a GNSS receiver, where it facilitates rapid acquisition of GNSS signals when you start collecting data, or when you have lost track of satellites and are trying to regain GNSS signals.</p> <p>The orbit information is a subset of the <a href="#">ephemeris/ephemerides</a> data.</p>
<b>base station</b>	Also called <i>reference station</i> . In construction, a base station is a receiver placed at a known point on a jobsite that tracks the same satellites as an RTK rover, and provides a real-time <a href="#">differential correction</a> message stream through radio to the rover, to obtain centimeter level positions on a continuous real-time basis. A base station can also be a part of a virtual reference station network, or a location at which GNSS observations are collected over a period of time, for subsequent <a href="#">postprocessing</a> to obtain the most accurate position for the location.
<b>BeiDou</b>	<p>The BeiDou Navigation Satellite System (also known as BDS) is a Chinese satellite navigation system.</p> <p>The first BeiDou system (known as BeiDou-1), consists of four satellites and has limited coverage and applications. It has been offering navigation services mainly for customers in China and from neighboring regions since 2000.</p> <p>The second generation of the system (known as BeiDou-2) consists of satellites in a combination of geostationary, inclined geosynchronous, and medium earth orbit configurations. It became operational with coverage of China in December 2011. However, the complete Interface Control Document (which specifies the satellite messages) was not released until December 2012. BeiDou-2 is a regional navigation service which offers services to customers in the Asia-Pacific region.</p> <p>A third generation of the BeiDou system is planned, which will expand coverage globally. This generation is currently scheduled to be completed by 2020.</p>
<b>BINEX</b>	Binary EXchange format. BINEX is an operational binary format standard for GPS/ <a href="#">GLONASS</a> / <a href="#">SBAS</a> research purposes. It is designed to grow and allow encapsulation of all (or most) of the information currently allowed for in a range of other formats.
<b>broadcast server</b>	An Internet server that manages authentication and password control for a network of <a href="#">VRS</a> servers, and relays VRS corrections from the VRS server that you select.
<b>carrier</b>	A radio wave having at least one characteristic (such as frequency, amplitude, or phase) that can be varied from a known reference value by modulation.
<b>carrier frequency</b>	The frequency of the unmodulated fundamental output of a radio transmitter. The GPS L1 carrier frequency is 1575.42 MHz.
<b>carrier phase</b>	Is the cumulative phase count of the GPS or GLONASS carrier signal at a given time.
<b>cellular modems</b>	A wireless adaptor that connects a laptop computer to a cellular phone system for data transfer. Cellular modems, which contain their own antennas, plug into a PC Card slot or into the USB port of the computer and are available for a variety of

	wireless data services such as GPRS.
<b>CMR/CMR+</b>	Compact Measurement Record. A real-time message format developed by Trimble for broadcasting corrections to other Trimble receivers. CMR is a more efficient alternative to <a href="#">RTCM</a> .
<b>CMRx</b>	A real-time message format developed by Trimble for transmitting more satellite corrections resulting from more satellite signals, more constellations, and more satellites. Its compactness means more repeaters can be used on a site.
<b>covariance</b>	A statistical measure of the variance of two random variables that are observed or measured in the same mean time period. This measure is equal to the product of the deviations of corresponding values of the two variables from their respective means.
<b>datum</b>	<p>Also called <i>geodetic datum</i>. A mathematical model designed to best fit the geoid, defined by the relationship between an ellipsoid and, a point on the topographic surface, established as the origin of the datum. World geodetic datums are typically defined by the size and shape of an <a href="#">ellipsoid</a> and the relationship between the center of the ellipsoid and the center of the earth.</p> <p>Because the earth is not a perfect ellipsoid, any single datum will provide a better model in some locations than in others. Therefore, various datums have been established to suit particular regions.</p> <p>For example, maps in Europe are often based on the European datum of 1950 (ED-50). Maps in the United States are often based on the North American datum of 1927 (NAD-27) or 1983 (NAD-83).</p> <p>All GPS coordinates are based on the <a href="#">WGS-84</a> datum surface.</p>
<b>deep discharge</b>	Withdrawal of all electrical energy to the end-point voltage before the cell or battery is recharged.
<b>DGPS</b>	See <a href="#">real-time differential GPS</a> .
<b>differential correction</b>	<p>Differential correction is the process of correcting GNSS data collected on a <a href="#">rover</a> with data collected simultaneously at a <a href="#">base station</a>. Because the base station is on a known location, any errors in data collected at the base station can be measured, and the necessary corrections applied to the rover data.</p> <p>Differential correction can be done in real-time, or after the data is collected by <a href="#">postprocessing</a>.</p>
<b>differential GPS</b>	See <a href="#">real-time differential GPS</a> .
<b>DOP</b>	<p>Dilution of Precision. A measure of the quality of GNSS positions, based on the geometry of the satellites used to compute the positions. When satellites are widely spaced relative to each other, the DOP value is lower, and position precision is greater. When satellites are close together in the sky, the DOP is higher and GNSS positions may contain a greater level of error.</p> <p><a href="#">PDOP</a> (Position DOP) indicates the three-dimensional geometry of the satellites. Other DOP values include <a href="#">HDOP</a> (Horizontal DOP) and <a href="#">VDOP</a> (Vertical DOP), which indicate the precision of horizontal measurements (latitude and longitude) and vertical measurements respectively. PDOP is related to HDOP and VDOP as follows: <math>PDOP^2 = HDOP^2 + VDOP^2</math>.</p>
<b>dual-frequency GPS</b>	A type of receiver that uses both <a href="#">L1</a> and <a href="#">L2</a> signals from GPS satellites. A dual-

	frequency receiver can compute more precise position fixes over longer distances and under more adverse conditions because it compensates for ionospheric delays.
<b>EGNOS</b>	European Geostationary Navigation Overlay Service. A Satellite-Based Augmentation System (SBAS) that provides a free-to-air differential correction service for GNSS. EGNOS is the European equivalent of <a href="#">WAAS</a> , which is available in the United States.
<b>elevation</b>	The vertical distance from a geoid such as EGM96 to the antenna phase center. The geoid is sometimes referred to as Mean Sea Level.
<b>elevation mask</b>	The angle below which the receiver will not track satellites. Normally set to 10 degrees to avoid interference problems caused by buildings and trees, atmospheric issues, and multipath errors.
<b>ellipsoid</b>	An ellipsoid is the three-dimensional shape that is used as the basis for mathematically modeling the earth's surface. The ellipsoid is defined by the lengths of the minor and major axes. The earth's minor axis is the polar axis and the major axis is the equatorial axis.
<b>EHT</b>	Height above ellipsoid.
<b>ephemeris/ephemerides</b>	A list of predicted (accurate) positions or locations of satellites as a function of time. A set of numerical parameters that can be used to determine a satellite's position. Available as broadcast ephemeris or as postprocessed precise ephemeris.
<b>epoch</b>	The measurement interval of a GNSS receiver. The epoch varies according to the measurement type: for real-time measurement it is set at one second; for postprocessed measurement it can be set to a rate of between one second and one minute. For example, if data is measured every 15 seconds, loading data using 30-second epochs means loading every alternate measurement.
<b>feature</b>	A feature is a physical object or event that has a location in the real world, which you want to collect position and/or descriptive information (attributes) about. Features can be classified as surface or non-surface features, and again as points, lines/break lines, or boundaries/areas.
<b>firmware</b>	The program inside the receiver that controls receiver operations and hardware.
<b>GAGAN</b>	GPS Aided Geo Augmented Navigation. A regional SBAS system currently in development by the Indian government.
<b>Galileo</b>	Galileo is a GNSS system built by the European Union and the European Space Agency. It is complimentary to GPS and GLONASS.
<b>geoid</b>	The geoid is the equipotential surface that would coincide with the mean ocean surface of the Earth. For a small site this can be approximated as an inclined plane above the Ellipsoid.
<b>GHT</b>	Height above geoid.
<b>GIOVE</b>	Galileo In-Orbit Validation Element. The name of each satellite for the European Space Agency to test the Galileo positioning system.
<b>GLONASS</b>	Global Orbiting Navigation Satellite System. GLONASS is a Soviet space-based navigation system comparable to the American GPS system. The operational system consists of 21 operational and 3 non-operational satellites in 3 orbit planes.
<b>GNSS</b>	Global Navigation Satellite System.
<b>GPS</b>	Global Positioning System. GPS is a space-based satellite navigation system consisting of multiple satellites in six orbit planes.



<b>GSOF</b>	General Serial Output Format. A Trimble proprietary message format.
<b>HDOP</b>	Horizontal Dilution of Precision. HDOP is a <a href="#">DOP</a> value that indicates the precision of horizontal measurements. Other DOP values include VDOP (vertical DOP) and <a href="#">PDOP</a> (Position DOP).  Using a maximum HDOP is ideal for situations where vertical precision is not particularly important, and your position yield would be decreased by the vertical component of the PDOP (for example, if you are collecting data under canopy).
<b>height</b>	The vertical distance above the Ellipsoid. The classic Ellipsoid used in GPS is WGS-84.
<b>IBSS</b>	Internet Base Station Service. This Trimble service makes the setup of an Internet-capable receiver as simple as possible. The base station can be connected to the Internet (cable or wirelessly). To access the distribution server, the user enters a password into the receiver. To use the server, the user must have a Trimble Connected Community site license.
<b>L1</b>	The primary L-band carrier used by GPS and GLONASS satellites to transmit satellite data.
<b>L2</b>	The secondary L-band carrier used by GPS and GLONASS satellites to transmit satellite data.
<b>L2C</b>	A modernized code that allows significantly better ability to track the L2 frequency.
<b>L5</b>	The third L-band carrier used by GPS satellites to transmit satellite data. L5 will provide a higher power level than the other carriers. As a result, acquiring and tracking weak signals will be easier.
<b>Location RTK</b>	Some applications such as vehicular-mounted site supervisor systems do not require Precision RTK accuracy. Location RTK is a mode in which, once initialized, the receiver will operate either in 10 cm horizontal and 10 cm vertical accuracy, or in 10 cm horizontal and 2 cm vertical accuracy.
<b>Mountpoint</b>	Every single NTripSource needs a unique mountpoint on an NTripCaster. Before transmitting GNSS data to the NTripCaster, the NTripServer sends an assignment of the mountpoint.
<b>Moving Base</b>	Moving Base is an RTK positioning technique in which both reference and rover receivers are mobile. Corrections are sent from a “base” receiver to a “rover” receiver and the resultant baseline (vector) has centimeter-level accuracy.
<b>MSAS</b>	MTSAT Satellite-Based Augmentation System. A Satellite-Based Augmentation System (SBAS) that provides a free-to-air differential correction service for GNSS. MSAS is the Japanese equivalent of <a href="#">WAAS</a> , which is available in the United States.
<b>multipath</b>	Interference, similar to ghosts on an analog television screen, which occurs when GNSS signals arrive at an antenna having traversed different paths. The signal traversing the longer path yields a larger pseudorange estimate and increases the error. Multiple paths can arise from reflections off the ground or off structures near the antenna.
<b>NMEA</b>	National Marine Electronics Association. NMEA 0183 defines the standard for interfacing marine electronic navigational devices. This standard defines a number of 'strings' referred to as NMEA strings that contain navigational details such as positions. Most Trimble GNSS receivers can output positions as NMEA strings.
<b>NTrip Protocol</b>	Networked Transport of RTCM via Internet Protocol (NTrip) is an application-level

	protocol that supports streaming Global Navigation Satellite System (GNSS) data over the Internet. NTrip is a generic, stateless protocol based on the Hypertext Transfer Protocol (HTTP). The HTTP objects are extended to GNSS data streams.
<b>NTripCaster</b>	<p>The NTripCaster is basically an HTTP server supporting a subset of HTTP request/response messages and adjusted to low-bandwidth streaming data. The NTripCaster accepts request messages on a single port from either the NTripServer or the NTripClient. Depending on these messages, the NTripCaster decides whether there is streaming data to receive or to send.</p> <p>Trimble NTripCaster integrates the NTripServer and the NTripCaster. This port is used only to accept requests from NTripClients.</p>
<b>NTripClient</b>	An NTripClient will be accepted by and receive data from an NTripCaster, if the NTripClient sends the correct request message (TCP/UDP connection to the specified NTripCaster IP and listening port).
<b>NTripServer</b>	<p>The NTripServer is used to transfer GNSS data of an NTripSource to the NTripCaster. An NTripServer in its simplest setup is a computer program running on a PC that sends correction data of an NTripSource (for example, as received through the serial communication port from a GNSS receiver) to the NTripCaster.</p> <p>The NTripServer - NTripCaster communication extends HTTP by additional message formats and status codes.</p>
<b>NTripSource</b>	The NTripSources provide continuous GNSS data (for example, RTCM-104 corrections) as streaming data. A single source represents GNSS data referring to a specific location. Source description parameters are compiled in the source-table.
<b>OmniSTAR</b>	The OmniSTAR HP/XP service allows the use of new generation dual-frequency receivers with the OmniSTAR service. The HP/XP service does not rely on local reference stations for its signal, but utilizes a global satellite monitoring network. Additionally, while most current dual-frequency GNSS systems are accurate to within a meter or so, OmniSTAR with XP is accurate in 3D to better than 30 cm.
<b>Orthometric elevation</b>	The Orthometric Elevation is the height above the geoid (often termed the height above the 'Mean Sea Level').
<b>PDOP</b>	<p>Position Dilution of Precision. PDOP is a <b>DOP</b> value that indicates the precision of three-dimensional measurements. Other DOP values include VDOP (vertical DOP) and <b>HDOP</b> (Horizontal Dilution of Precision).</p> <p>Using a maximum PDOP value is ideal for situations where both vertical and horizontal precision are important.</p>
<b>postprocessing</b>	Postprocessing is the processing of satellite data after it is collected, in order to eliminate error. This involves using computer software to compare data from the rover with data collected at the base station.
<b>QZSS</b>	Quasi-Zenith Satellite System. A Japanese regional GNSS eventually consisting of three geosynchronous satellites over Japan.
<b>real-time differential GPS</b>	<p>Also known as <i>real-time differential correction</i> or <i>DGPS</i>. Real-time differential GPS is the process of correcting GPS data as you collect it. Corrections are calculated at a base station and then sent to the receiver through a radio link. As the rover receives the position it applies the corrections to give you a very accurate position in the field.</p> <p>Most real-time differential correction methods apply corrections to code phase</p>

	positions. While DGPS is a generic term, its common interpretation is that it entails the use of single-frequency code phase data sent from a GNSS base station to a rover GNSS receiver to provide sub-meter position accuracy. The rover receiver can be at a long range (greater than 100 kms (62 miles)) from the base station.
<b>rover</b>	A rover is any mobile GNSS receiver that is used to collect or update data in the field, typically at an unknown location.
<b>Roving mode</b>	Roving mode applies to the use of a rover receiver to collect data, stakeout, or control earthmoving machinery in real time using <a href="#">RTK</a> techniques.
<b>RTCM</b>	Radio Technical Commission for Maritime Services. A commission established to define a differential data link for the real-time differential correction of roving GNSS receivers. There are three versions of RTCM correction messages. All Trimble GNSS receivers use Version 2 protocol for single-frequency DGPS type corrections. Carrier phase corrections are available on Version 2, or on the newer Version 3 RTCM protocol, which is available on certain Trimble dual-frequency receivers. The Version 3 RTCM protocol is more compact but is not as widely supported as Version 2.
<b>RTK</b>	real-time kinematic. A <a href="#">real-time differential GPS</a> method that uses <a href="#">carrier phase</a> measurements for greater accuracy.
<b>SBAS</b>	Satellite-Based Augmentation System. SBAS is based on differential GPS, but applies to wide area ( <a href="#">WAAS/EGNOS/MSAS</a> ) networks of reference stations. Corrections and additional information are broadcast using geostationary satellites.
<b>sCMRx</b>	Scrambled CMRx. CMRx is a new Trimble message format that offers much higher data compression than Trimble's CMR/CMR+ formats.
<b>signal-to-noise ratio</b>	SNR. The signal strength of a satellite is a measure of the information content of the signal, relative to the signal's noise. The typical SNR of a satellite at 30° elevation is between 47 and 50 dBHz.
<b>skyplot</b>	The satellite skyplot confirms reception of a differentially corrected GNSS signal and displays the number of satellites tracked by the GNSS receiver, as well as their relative positions.
<b>SNR</b>	See <a href="#">signal-to-noise ratio</a> .
<b>Source-table</b>	The NTripCaster maintains a source-table containing information on available NTripSources, networks of NTripSources, and NTripCasters, to be sent to an NTripClient on request. Source-table records are dedicated to one of the following: <ul style="list-style-type: none"> <li>• data STReams (record type STR)</li> <li>• CASTers (record type CAS)</li> <li>• NETworks of data streams (record type NET)</li> </ul> <p>All NTripClients must be able to decode record type STR. Decoding types CAS and NET is an optional feature. All data fields in the source-table records are separated using the semicolon character.</p>
<b>triple frequency GPS</b>	A type of receiver that uses three carrier phase measurements ( <a href="#">L1</a> , <a href="#">L2</a> , and <a href="#">L5</a> ).
<b>UTC</b>	Universal Time Coordinated. A time standard based on local solar mean time at the Greenwich meridian.

<b>xFill</b>	Trimble xFill™ is a new service that extends RTK positioning for several minutes when the RTK correction stream is temporarily unavailable. The Trimble xFill service improves field productivity by reducing downtime waiting to re-establish RTK corrections in black spots. It can even expand productivity by allowing short excursions into valleys and other locations where continuous correction messages were not previously possible. Proprietary Trimble xFill corrections are broadcast by satellite and are generally available on construction sites globally where the GNSS constellations are also visible. It applies to any positioning task being performed with a single-base, Trimble Internet Base Station Service (IBSS), or VRS™ RTK correction source.
<b>variance</b>	A statistical measure used to describe the spread of a variable in the mean time period. This measure is equal to the square of the deviation of a corresponding measured variable from its mean. See also covariance.
<b>VDOP</b>	Vertical Dilution of Precision. VDOP is a DOP value (dimensionless number) that indicates the quality of GNSS observations in the vertical frame.
<b>VRS</b>	<p>Virtual Reference Station. A VRS system consists of GNSS hardware, software, and communication links. It uses data from a network of <a href="#">base stations</a> to provide corrections to each rover that are more accurate than corrections from a single base station.</p> <p>To start using VRS corrections, the rover sends its position to the VRS server. The VRS server uses the base station data to model systematic errors (such as ionospheric noise) at the rover position. It then sends <a href="#">RTCM</a> correction messages back to the rover.</p>
<b>WAAS</b>	<p>Wide Area Augmentation System. WAAS was established by the Federal Aviation Administration (FAA) for flight and approach navigation for civil aviation. WAAS improves the accuracy and availability of the basic GNSS signals over its coverage area, which includes the continental United States and outlying parts of Canada and Mexico.</p> <p>The WAAS system provides correction data for visible satellites. Corrections are computed from ground station observations and then uploaded to two geostationary satellites. This data is then broadcast on the L1 frequency, and is tracked using a channel on the GNSS receiver, exactly like a GNSS satellite.</p> <p>Use WAAS when other correction sources are unavailable, to obtain greater accuracy than autonomous positions. For more information on WAAS, refer to the FAA website at <a href="http://gps.faa.gov">http://gps.faa.gov</a>.</p> <p>The <a href="#">EGNOS</a> service is the European equivalent and <a href="#">MSAS</a> is the Japanese equivalent of WAAS.</p>
<b>WGS-84</b>	<p>World Geodetic System 1984. Since January 1987, WGS-84 has superseded WGS-72 as the <a href="#">datum</a> used by GPS.</p> <p>The WGS-84 datum is based on the <a href="#">ellipsoid</a> of the same name.</p>