

3.2.1.3 Display

The display clearly shows all main settings and signal generator states.

The display is divided into the following sections:

- Frequency and level display with info line
 - Frequency and level settings containing offset.
 - Status messages
 - Brief error messages.

To access an window with detailed information for a message, use the [INFO] key.
- Block diagram

The block diagram shows the current configuration and the signal flow in the generator with the aid of function blocks containing an on/off switch. Selecting a function block opens a list of associated setting menus. Active menus, info windows and graphs are displayed on top of the block diagram. The block diagram can be displayed in the foreground anytime with the [DIAGRAM] key.

For detailed information, see [Chapter 3.5.1.3, "Display"](#), on page 71.

3.2.1.4 Setup Keys

The keys to the right of the display set parameters, select views and control the windows.

Keys for Setting Parameters



These keys provide direct access to the settings in the header of the instrument for fast setting the RF signal.

For more information refer to chapter "Instrument Functions".

[FREQ]

Activates frequency entry.

[LEVEL]

Activates level entry.

[ON/OFF TOGGLE]

- Switches highlighted elements or a function block on and off.
- Switches between two or more settings, e.g. items of selection lists. At the end of a list, the cursor is set on the first entry again.