



Figure 3-2: Rear panel view


3.2.2.1 Description of the Connectors



[Fuses]

The R&S SMB is fully fused by two fuses IEC60127-T3.15H/250 V.

The fuses are accommodated in the fuse holders next to the power connector. Use only fuses of the mentioned type.



[AC supply and power switch]

When the R&S SMB is connected to the AC supply, it automatically sets itself to the correct range for the applied voltage (range: see type label). There is no need to set the voltage manually or change fuses.

The power switch can be set to two positions:

- **0**
The instrument is disconnected from the mains.
- **I**
The instrument is power-supplied. It is either ready for operation (STANDBY) or in operating mode, depending on the position of the [ON/STANDBY] switch on the instrument front.

See also data sheet and [Chapter 3.1.6, "Connecting to Power"](#), on page 24.



[USB IN]

USB (universal serial bus) interface of type B (device USB).

This interface can be used for remote control of the instrument.



[USB Connectors type A]

USB (universal serial bus) interfaces of type A (host USB).

- Connection of peripherals such as mouse, keyboard, etc.
- Connection of memory stick for file transmission
- Firmware update

See [Chapter 3.1.9, "Connecting USB Devices"](#), on page 25.


**[LAN Connector]**

Ethernet interface

- For integrating signal generators in a network
- Remote control of signal generator
- Remote access to the signal generator
- Firmware update

See also:


- [Chapter 3.1.7, "Connecting to LAN"](#), on page 24
- [Chapter 5.1.3, "LAN Interface"](#), on page 242

**[IEC 625/IEEE 488]**

IEC-bus (IEEE 488) interface for remote control of the instrument.

See also [Chapter A.1, "GPIB Bus Interface"](#), on page 508 and [Chapter 5.1.6, "GPIB Interface \(IEC/IEEE Bus Interface\)"](#), on page 246.

Note: In order to avoid electromagnetic interference (EMI) caused by open lines, always terminate any connected IEC-bus cable with an instrument or a controller.

**[Stereo R/L]**

Inputs for analog stereo modulation signals. External modulation sources or the internal LF generator can be used (stereo modulation is available with option R&S SMB-B5).

See also [Chapter 4.4.6, "Stereo Modulation"](#), on page 217.

**[S/P DIF]**

Input for digital stereo signals (stereo modulation is available with option R&S SMB-B5).

See also [Chapter 4.4.6, "Stereo Modulation"](#), on page 217.

**[SIGNAL VALID]**

Output of valid signal. This signal marks the valid signal times (valid level and frequency indication). The signal is generated automatically.

**[INSTR TRIG]**

Input for external trigger for sweeps and list mode.

See also [Chapter 4.3.7.4, "List Mode"](#), on page 192 and [Chapter 4.3.7.1, "Overview"](#), on page 178.

**[PULSE VIDEO]**

Output of internal pulse generator signal or external pulse signal fed in via the [PULSE EXT] connector (video signal).

See also [Chapter 4.4.5, "Pulse Modulation \(PM\)"](#), on page 214 .