

"Current Auto Number" Indicates the number which is used in the automatically generated file name.

**Note:** When initially switching on the instrument the number is reset to the lowest possible value. Starting with number 0 the output directory is scanned for already existing files. As long as files with the same name are existing the number is increased by 1. The number is automatically set so that the resulting file name will be unique within the selected path. The current number is not in the save/recall file but will be temporarily stored within the database. At following save operations the number is increased.

Remote command:

[:HCOPY:FILE\[:NAME\]:AUTO\[:FILE\]:NUMBER?](#) on page 302

"Resulting File Name" Indicates the automatically generated file name.

Remote command:

[:HCOPY:FILE\[:NAME\]:AUTO:FILE?](#) on page 302

### Save

Saves the hard copy.

Remote command:

[:HCOPY\[:EXECute\]](#) on page 301

## 4.2.6 Messages - Info Key

The [INFO] key opens a window containing a detailed description of every message displayed in the info bar, see ["Info Window"](#) on page 73 and [Chapter 9, "Status Information, Error Messages and Troubleshooting"](#), on page 499.

## 4.2.7 Help System - Help Key

The [HELP] key opens a browser window containing a context-sensitive description of the highlighted parameter.

