

**:SYSTem:MMEMory:PATH:USER?**

Queries the user directory, that means the directory the instrument stores user files on.

**Return values:**

<PathUser>                      string

**Example:**                      SYSTem:MMEMory:PATH:USER?  
                                      Response: "/var/user/"

**Usage:**                         Query only

**:SYSTem:WAIT <TimeMs>**

Delays the execution of the subsequent remote command by the specified time.

This function is useful, for example to execute an SCPI sequence automatically but with a defined time delay between some commands.

**Setting parameters:**

<TimeMs>                      integer  
                                      Wait time in ms  
                                      Range:        0 to 10000  
                                      \*RST:        0

**Example:**                      :SYSTem:WAIT 10000  
                                      // waits 10s before resetting the instrument  
                                      \*RST

**Usage:**                         Setting only

## 6.16 TEST Subsystem

The TEST system contains the commands for performing selftest routines, and for direct adjustment of the hardware assemblies (:TEST:DIReCt).

The self tests return a "0" if the test is performed successfully, otherwise a value other than "0" is returned. None of the commands of this system have an \*RST value.

### NOTICE

**Improper use can destroy the assembly**

The respective hardware assembly responds directly to the :TEST:DIReCt command; any safety mechanisms are bypassed. The command is intended for servicing purposes and should be used only by the Rohde & Schwarz service personnel.

:TEST<hw>:ALL:StARt.....	457
:TEST<hw>:ALL:RESult?.....	457
:TEST<hw>:DIReCt.....	457