

Enlarging the indication of the header section

- ▶ Press the [DIAGRAM] key twice to enlarge the indication of the header section.

Tip: Use the [REARR] key to toggle between the enlarged and normal sized dialogs.

Accessing the menu tree

- ▶ Press the [MENU] (CTRL+M) key to open the complete menu tree.

Calling the File or Setup dialog

- ▶ Use the [FILE] (CTRL+S) or [SETUP] (CTRL+E) keys to open the respective dialog.

Closing an active menu

- ▶ Press the [CLOSE] key to close an active menu.

Tip: If the cursor is at the highest menu level, you can also use the [ESC] key to close the active menu.

Accessing the header area

- ▶ Press the [FREQ] (CTRL+F) and [LEVEL] (CTRL+L) keys to activate the "Frequency" or "Level" entry fields in the header area.



Keyboard Shortcuts

Keyboard shortcuts (e.g. "Ctrl + D" for the displaying the block diagram in the foreground) provide direct access to all utility dialogs of the instrument (see [Chapter 3.5.1.9, "Legend of Front-Panel Controls"](#), on page 90).

3.5.1.5 Setting Parameters

The R&S SMB offers several and sometimes alternative possibilities for setting parameters. Operation is possible from the front panel, with the aid of a mouse and/or from a PC keyboard.



The examples within this description focus on the operation from the front panel.



For more information, refer to:

- [Chapter 3.5.1.9, "Legend of Front-Panel Controls"](#), on page 90 for an overview of key functions and a cross-reference between the front panel keys and the keyboard shortcuts
- section "Instrument Functions" for a detailed description of key functions.

Most of the parameters are set in the different menus. The R&S SMB provides alternative ways for accessing the dialogs. Turn the rotary knob and navigate to the corre-