



For information about the LXI standard, refer to the LXI website at <http://www.lxistandard.org>. See also "News from Rohde & Schwarz, article 2006/II - 190".

The R&S SMB provides an integrated "LXI Status" dialog for LXI status indication and reset of the LAN configuration ("LAN Configuration Initialize", LCI). To access the LXI status dialog, press the [Setup] key and select "Remote > LXI Status".

For further information, see [Chapter 4.2.3.12, "LXI Status"](#), on page 112.



### Firmware update

After a firmware update, shut down and restart the instrument in order to enable the full LXI functionality.

### Default state of the network settings

According to the LXI standard, an LCI must set the following parameters to a default state.

Parameter	Value
TCP/IP Mode	DHCP + Auto IP Address
Dynamic DNS	Enabled
ICMP Ping	Enabled
Password for LAN configuration	LxiWebIfc

The LCI for the R&S SMB also resets the following parameters:

Parameter	Value
Hostname	<Instrument-specific host name>
Description	Vector Signal Generator
Negotiation	Auto Detect
VXI-11 Discovery	Enabled

The LAN settings are configured using the instrument's "LXI Browser Interface".

#### 3.1.17.1 LXI Browser Settings

To access the instrument via the web browser:

- Type in the instrument's host name or IP address in the address field of the browser on your PC, for example "http://10.113.1.205".

**Note:** Do not add the missing zeros in the IP address, while opening the instrument home page.

The instrument home page (welcome page) opens.

Instrument Properties	
Instrument Model	R&S SMB
Manufacturer	Rohde & Schwarz GmbH & Co. KG
Serial Number	100011
Description	Rohde & Schwarz Signal Generator SMB100A 100011
LXI Version	1.4 LXI Core 2011
LXI Extended Features	instrument
DNS Host Name(s)	00:25:64:C3:31:82
MAC Address	10.113.1.150
IP Address	03.20.390.12
Firmware Revision	Wednesday, 2015/12/02, 11:54:06
Current Time	Operating System
Current Time source	TCPIP::10.113.1.150::inst0::INSTR
VISA resource string	TCPIP::10.113.1.150::hislip0::INSTR
Device Indicator	ACTIVE (press to toggle) 

**Status**  
No error

© 2015 ROHDE&SCHWARZ. All rights reserved.

The navigation pane of the browser interface contains the following elements:

- "LXI"
  - "Home" opens the instrument home page.  
The home page displays the device information required by the LXI standard, including the VISA resource string in read-only format.
  - "Device Indicator" activates or deactivates the LXI status indication.  
When activated, the LXI LEDs flash, both in the browser dialog and in the LXI dialog of the connected instrument. A green LXI status symbol indicates that a LAN connection has been established; a red symbol indicates that no LAN cable is connected.
  - "Lan Configuration" allows you to configure LAN parameters and to initiate a ping, see ["Ping Client"](#) on page 44.
  - "Status" displays information about the LXI status of the instrument.
  - "Utilities" provides access to the LXI event log functionality required by the LXI standard.
- "Instrument Control"
  - "Web Control" provides remote access to the instrument, see ["Web Control"](#) on page 45.
- "Diagnostics"
  - "SCPI Remote Trace" records messages exchanged via the remote control interface, see ["SCPI Remote Trace"](#) on page 46.
- "Help"
  - "Glossary" explains terms related to the LXI standard.