


- [www.rohde-schwarz.com](http://www.rohde-schwarz.com) opens the Rohde & Schwarz home page.
- Press the "INACTIVE (press to toggle)" button to activate the connection.



A green flashing status LED indicates the active connection. If the LAN connection fails, the LED turns red.

The status of the LAN connection is also indicated by the "LAN Status indicator" in the "LXI Status" dialog.

For further information, see section "LXI Status" in the Operating Manual.

### 3.1.17.2 LAN Configuration

The "LAN Configuration" web page provides access to the parameters required for identifying the R&S SMB in the network, and allows modification.



#### Password protection

Changing the LAN configuration is password-protected. The default password is *Lxi-WebIfc* (notice upper and lower case characters). This password cannot be changed in the current firmware version.

It comprises the following navigation entries.

- [IP Configuration](#)..... 42
- [Advanced LAN Configuration](#).....43
- [Ping Client](#).....44
- [Web Control](#)..... 45
- [SCPI Remote Trace](#).....46

#### IP Configuration

The "IP Configuration" page displays all mandatory LAN parameters.