


CNC ZEUS


GS2 AC Drive Interface

DB9S connector




DB9S connector

RJ11 connector



NOTE: Switches SW2 and SW3 on the GS2 drive unit must be set to RS232 for this connection. Additional drive parameters must also be changed for operation from RS232. Please refer to your GS2 AC DRIVE users manual.



RJ11 connector

Step SELECT

OFF	00	Isb
X1	01	
X10	10	
X100	11	



Axis SELECT

X	00	Isb
Y	01	
Z	10	
A	11	



A/B pulse generator

CNC ZEUS

Manual pulse generator



Note: Swapping A with B changes direction.




74HC86

Quad exclusive OR gate

Computer printer port 2

RAPID OVERRIDE


1%	00	Isb
25%	01	
50%	10	
100%	11	




**2 pole
4 position
Rotary switch**

FEED OVERRIDE

Hold	0000	80%	1000
10%	0001	90%	1001
20%	0010	100%	1010
30%	0011	110%	1011
40%	0100	120%	1100
50%	0101	130%	1101
60%	0110	140%	1110
70%	0111	150%	1111



**4 pole
16 position
Rotary switch**



CNC ZEUS

External feed override

