

X88	AC connector
31	Battery -
30	Battery +
B132	Camshaft position (CMP) sensor
X1	Data link connector (DLC)
A161	Digital multifunction display
A35	Engine control module (ECM)
B24	Engine coolant temperature (ECT) sensor
H63	Engine malfunction indicator lamp (MIL)
B75	Engine speed (RPM) sensor
Y104	Evaporative emission (EVAP) canister purge valve
Y28	Exhaust gas recirculation (EGR) solenoid
M12	Fuel pump
K20	Fuel pump relay
F	Fuse
F2	Fuse - Astra-F
F26	Fuse - Corsa-B/Tigra
B72	Heated oxygen sensor (HO2S)
Y99	Idle air control (IAC) valve
T1	Ignition coil
15	Ignition switch - ignition ON
50	Ignition switch - start signal
Y3	Injector
A5	Instrument panel - MIL light
B25	Intake air temperature (IAT) sensor
B69	Knock sensor (KS)
B83	Manifold absolute pressure (MAP) sensor
B30	Mass air flow (MAF) sensor
M73	Secondary air injection (AIR) pump
K152	Secondary air injection (AIR) pump relay
Y111	Secondary air injection (AIR) solenoid
P7	Tachometer
B147	Throttle position (TP) sensor
X79	Transmission connector
B33	Vehicle speed sensor (VSS)