


K143	AC compressor clutch relay
A63	AC control module
B138	Accelerator pedal position (APP) sensor
S337	Accelerator pedal position (APP) switch
A23	Alarm system control module
G1	Alternator
31	Battery -
30	Battery +
S13	Brake pedal position (BPP) switch
A31	Central locking control module
S258	Clutch pedal position (CPP) switch
B54	Crankshaft position (CKP) sensor
S80	Cruise control selector switch
X1	Data link connector (DLC)
K46	Engine control (EC) relay
A35	Engine control module (ECM)
B24	Engine coolant temperature (ECT) sensor
B4	Engine coolant temperature gauge sensor
H63	Engine malfunction indicator lamp (MIL)
Y28	Exhaust gas recirculation (EGR) solenoid
R64	Fuel filter heater
A150	Fuel injection pump
Y132	Fuel injection timing solenoid
M12	Fuel lift pump
K20	Fuel lift pump relay
Y159	Fuel quantity adjuster
B177	Fuel quantity adjuster position sensor
Y12	Fuel shut-off solenoid
B31	Fuel temperature sensor
B82	Fuel/water separator sensor
F	Fuse
X28-I	Fuse box/relay plate - engine bay
R5	Glow plug
A104	Glow plug control module
H25	Glow plug warning lamp
X	Ignition switch - accessories
15	Ignition switch - ignition ON
A162	Immobilizer control module
B141	Injector needle lift sensor
A5	Instrument panel
B25	Intake air temperature (IAT) sensor
B30	Mass air flow (MAF) sensor
K4	Starter motor relay
A57	Transmission control module (TCM)
S61	Transmission kick-down switch
S249	Transmission range (TR) switch
A19	Trip computer
B105	Turbocharger (TC) boost pressure sensor



AD72618

bl = blue	br = brown	el = cream	ge = yellow
gn = green	gr = grey	nf = neutral	og = orange
rs = pink	rt = red	sw = black	vi = violet
ws = white	hbl = light blue	hgn = light green	rbr = maroon
x = braided cable	y = high tension	z = non-cable connection	

NOTE: In certain diagrams (Citroen, Peugeot & Renault), colour codes are replaced by numbers which are used to identify a particular cable and not the colour. In this instance, the cables will be numbered at each end close to the harness connector.

