

K143	AC compressor clutch relay
X88	AC connector
A63	AC control module
31	Battery -
30	Battery +
S57	Closed throttle position (CTP) switch
B54	Crankshaft position (CKP) sensor
X1	Data link connector (DLC)
A35	Engine control module (ECM)
K46	Engine control relay
B24	Engine coolant temperature (ECT) sensor
H63	Engine malfunction indicator lamp (MIL)
Y104	Evaporative emission (EVAP) canister purge valve
M12	Fuel pump
K20	Fuel pump relay
F	Fuse
B72	Heated oxygen sensor (HO2S)
Y56	Idle speed control (ISC) actuator
A52	Ignition amplifier
T1	Ignition coil
15	Ignition switch - ignition ON
50	Ignition switch - start signal
A162	Immobilizer control module
Y3	Injector
B25	Intake air temperature (IAT) sensor
B69	Knock sensor (KS)
B83	Manifold absolute pressure (MAP) sensor
W3	Spare cable
P7	Tachometer
B147	Throttle position (TP) sensor
A57	Transmission control module (TCM)
A19	Trip computer
B33	Vehicle speed sensor (VSS)
S284	Wide open throttle (WOT) switch