

K143	AC compressor clutch relay
S51	AC evaporator temperature switch
31	Battery -
30	Battery +
S13	Brake pedal position (BPP) switch
R62	CO adjustment resistor
B54	Crankshaft position (CKP) sensor
X1	Data link connector (DLC)
A166	Distributor
A35	Engine control module (ECM)
K46	Engine control relay
B24	Engine coolant temperature (ECT) sensor
Y104	Evaporative emission (EVAP) canister purge valve
M12	Fuel pump
K20	Fuel pump relay
S313	Fuel temperature switch
F	Fuse
B72	Heated oxygen sensor (HO2S)
X60	Idle adjustment connector
Y99	Idle air control (IAC) valve
A52	Ignition amplifier
T1	Ignition coil
15	Ignition switch - ignition ON
50	Ignition switch - start signal
S39	Inertia fuel shut-off (IFS) switch
Y3	Injector
B25	Intake air temperature (IAT) sensor
B83	Manifold absolute pressure (MAP) sensor
W21	Octane coding plug
K46	Relay module (Scorpio/Granada 1992-94)
K4	Starter motor relay
P7	Tachometer
B147	Throttle position (TP) sensor
X79	Transmission connector
K106	Transmission kick-down relay
B33	Vehicle speed sensor (VSS)

