



X88	AC connector
A23	Alarm system control module
G1	Alternator
31	Battery -
30	Battery +
B132	Camshaft position (CMP) sensor
S258	Clutch pedal position (CPP) switch
B54	Crankshaft position (CKP) sensor
X1	Data link connector (DLC)
Y28	EGR system valve
A35	Engine control module (ECM)
K46	Engine control relay
K12	Engine coolant blower motor relay
B24	Engine coolant temperature (ECT) sensor
H63	Engine malfunction indicator lamp (MIL)
Y104	Evaporative emission (EVAP) canister purge valve
B127	Exhaust gas pressure sensor
M12	Fuel pump
K20	Fuel pump relay
F	Fuse
B72	Heated oxygen sensor (HO2S)
Y99	Idle air control (IAC) valve
T1	Ignition coil
15	Ignition switch - ignition ON
S39	Inertia fuel shut-off (IFS) switch
Y3	Injector
A5	Instrument panel
B25	Intake air temperature (IAT) sensor
B30	Mass air flow (MAF) sensor
S259	Neutral switch
W21	Octane adjuster
S231	Power steering pressure (PSP) switch
B147	Throttle position (TP) sensor
B33	Vehicle speed sensor (VSS)