

Bravo 1.4 182.A3.000

30

15

31

30020

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	

K143	AC compressor clutch relay
31	Battery -
30	Battery +
S57	Closed throttle position (CTP) switch
B54	Crankshaft position (CKP) sensor
X1	Data link connector (DLC)
A35	Engine control module (ECM)
K46	Engine control relay
B24	Engine coolant temperature (ECT) sensor
H63	Engine malfunction indicator lamp (MIL)
Y104	Evaporative emission (EVAP) canister purge valve
M12	Fuel pump
K20	Fuel pump relay
F	Fuse
X28	Fuse box/relay base
B72	Heated oxygen sensor (HO2S)
Y56	Idle speed control (ISC) actuator
T1	Ignition coil
15	Ignition switch - ignition ON
A162	Immobilizer control module
S39	Inertia fuel shut-off (IFS) switch
Y3	Injector
B25	Intake air temperature (IAT) sensor
B69	Knock sensor (KS)
B147	Throttle position (TP) sensor
B33	Vehicle speed sensor (VSS)

