

A163	AC compressor control module
A63	AC control module
V11	AC diode
31	Battery -
30	Battery +
B132	Camshaft position (CMP) sensor
S57	Closed throttle position (CTP) switch
B54	Crankshaft position (CKP) sensor
15	Cylinder head
X1	Data link connector (DLC)
A35	Engine control module (ECM)
B24	Engine coolant temperature (ECT) sensor
Y104	Evaporative emission (EVAP) canister purge valve
M12	Fuel pump
K20	Fuel pump relay
F	Fuse
B72	Heated oxygen sensor (HO2S)
Y56	Idle speed control (ISC) actuator
B151	Idle speed control (ISC) actuator position sensor
A52	Ignition amplifier
T1	Ignition coil
15	Ignition switch - ignition ON
A162	Immobilizer control module
Y3	Injector
A5	Instrument panel
A75	Instrumentation control module
B69	Knock sensor (KS)
B30	Mass air flow (MAF) sensor
S29	Starter motor inhibitor switch
P7	Tachometer
A177	Throttle control unit
B147	Throttle position (TP) sensor
A57	Transmission control module (TCM)
P9	Vehicle speedometer

